
# - AUTODOC CLUB

How to change rear anti roll bar links on **AUDI A5 B8 Sportback (8TA)** – replacement guide



### SIMILAR VIDEO TUTORIAL



This video shows the replacement procedure of a similar car part on another vehicle

## (i) Important!

This replacement procedure can be used for: AUDI A5 B8 Sportback (8TA) 2.0 TDI, AUDI A5 B8 Sportback (8TA) 3.0 TDI, AUDI A5 B8 Sportback (8TA) 3.0 TDI quattro, AUDI A5 B8 Sportback (8TA) 1.8 TFSI, AUDI A5 B8 Sportback (8TA) 3.0 TFSI quattro, AUDI A5 B8 Sportback (8TA) 2.0 TDI quattro, AUDI A5 B8 Sportback (8TA) 2.0 TFSI, AUDI A5 B8 Sportback (8TA) 2.0 TFSI quattro,

AUDI A5 B8 Sportback (8TA) 3.2 FSI quattro, AUDI A5 B8 Sportback (8TA) 2.7 TDI, AUDI A5 B8 Sportback (8TA) S5 quattro

The steps may slightly vary depending on the car design.

This tutorial was created based on the replacement procedure for a similar car part on: AUDI A4 B8 Saloon (8K2) 2.0 TFSI Flexfuel quattro



#### REPLACEMENT: ANTI ROLL BAR LINKS – AUDI A5 B8 SPORTBACK (8TA). TOOLS YOU NEED:



- Wire brush
- WD-40 spray
- Brake cleaner
- Copper grease
- Combination spanner #16
- Drive socket # 16

- Wheel impact socket #17
- Ratchet wrench
- Torque wrench
- Hydraulic transmission jack
- Wheel chock

**Buy tools** 



Replacement: anti roll bar links – AUDI A5 B8 Sportback (8TA). AUTODOC experts recommend:

- Replace the stabiliser links on AUDI A5 B8 Sportback (8TA) in pairs.
- The replacement procedure is identical for both stabiliser links on the same axle.
- All work should be done with the engine stopped.

## REPLACEMENT: ANTI ROLL BAR LINKS – AUDI A5 B8 SPORTBACK (8TA). USE THE FOLLOWING PROCEDURE:



Secure the wheels with chocks.



2

Loosen the wheel mounting bolts. Use wheel impact socket #17.



3

Raise the rear of the car and secure on supports.





Unscrew the wheel bolts.



#### AUTODOC recommends:

 Important! Hold the wheel while unscrewing the fastening bolts. AUDI A5 B8 Sportback (8TA)



Remove the wheel.



6

Clean the stabiliser link fasteners. Use a wire brush. Use WD-40 spray.



7

Unscrew the fastener connecting the stabilizer bar with the control arm. Use a drive socket #16. Use a ratchet wrench.





8

Unscrew the fasteners connecting the stabiliser link to the stabiliser bar. Use a combination spanner #16 (2 pieces).



9

Remove the stabilizer rod.



## Replacement: anti roll bar links – AUDI A5 B8 Sportback (8TA). Tip:

• Examine stabiliser bushes. Replace them if needed.

10

Clean the mounting seats of the stabiliser link. Use a wire brush. Use WD-40 spray.





11

Install a new rod, tighten the fasteners. Use a combination spanner #16 (2 pieces). Use a drive socket #16. Use a ratchet wrench.



12

Support the arm. Use a hydraulic transmission jack.



13

Tighten the fastener connecting the stabilizer bar with the control arm. Use a combination spanner #16. Use a drive socket #16. Use a torque wrench. Tighten it to 40 Nm torque.+90°



#### AUTODOC recommends:

• Important! Be sure to use new fasteners.



14

Tighten the fastener connecting the stabilizer link to the stabilizer bar. Use a combination spanner #16. Use a drive socket #16. Use a torque wrench. Tighten it to 40 Nm torque.+90°



#### AUTODOC recommends:

• Important! Be sure to use new fasteners.



Treat all joints of the stabiliser link. Use copper grease.



16

Remove the support from under the arm.





#### AUTODOC recommends:

 AUDI A5 B8 Sportback (8TA) – Do not lower the transmission jack sharply to avoid damaging components and mechanisms of the car.

17

Treat the surface where the brake disc contacts the wheel rim. Use copper grease.



18

Clean the brake disk surface. Use a brake cleaner.



Replacement: anti roll bar links – AUDI A5 B8 Sportback (8TA). Tip from AUTODOC experts:

• After applying the spray, wait a few minutes.

19

Install the wheel.





#### AUTODOC recommends:

- Warning! To avoid injury, hold the wheel while screwing in the fastening bolts on the car. AUDI A5 B8 Sportback (8TA)
- 20

Screw in the wheel bolts. Use wheel impact socket #17.



21

Lower the car and working in a cross order, tighten the wheel bolts. Use wheel impact socket #17. Use a torque wrench. Tighten it to 120 Nm torque.



22

Remove the jacks and chocks.






**VIEW MORE TUTORIALS** 



## AUTODOC – TOP QUALITY AND AFFORDABLE CAR PARTS ONLINE



#### A GREAT SELECTION OF SPARE PARTS FOR YOUR CAR

#### **ANTI ROLL BAR LINKS: A WIDE SELECTION**

## (i) **DISCLAIMER**:

The document contains only general recommendations that may be useful for you when you perform repair or replacement work. AUTODOC shall not be liable for any loss, injury, damage of property occurring in the repair or replacement process due to incorrect use or misinterpretation of the provided information.

AUTODOC shall not be liable for any possible mistakes and uncertainties in this guide. The information provided is for information purposes only and cannot replace advice from specialists.

AUTODOC shall not be liable for incorrect or hazardous usage of equipment, tools and car parts. AUTODOC strongly recommends to be careful and observe the safety rules when performing repair or replacement works. Remember: usage of low quality auto parts does not guarantee you the appropriate level of road safety.

© Copyright 2022 – All the contents of this website, in particular texts, photographs and graphics, are protected by copyright. All rights, including reproduction, publication, editing and translation rights, are reserved by AUTODOC GmbH.