



How to change rear  
wheel bearing on **AUDI**  
**TT Roadster (8N9)** –  
replacement guide

## SIMILAR VIDEO TUTORIAL



This video shows the replacement procedure of a similar car part on another vehicle

### **Important!**

This replacement procedure can be used for:

AUDI TT Roadster (8N9) 1.8 T

The steps may slightly vary depending on the car design.

This tutorial was created based on the replacement procedure for a similar car part on: AUDI A3 Hatchback (8L1) 1.8

REPLACEMENT: WHEEL BEARING – AUDI TT  
ROADSTER (8N9). TOOLS YOU MIGHT NEED:

- Wire brush
- WD-40 spray
- Brake cleaner
- Torx bit T30
- Combination spanner #13
- Combination spanner #15
- Drive socket # 13
- Torque wrench
- Copper grease
- Wheel impact socket #17
- Flat chisel
- Hammer
- 3-Arm Gear Puller
- 12-point socket # 32
- Rubber mallet
- Crow bar
- Wheel chock

[Buy tools](#)


Replacement: wheel bearing – AUDI TT Roadster (8N9). AUTODOC experts recommend:

- The replacement procedure is identical for the left and right wheel hubs on the same axle.
- All work should be done with the engine stopped.

## REPLACEMENT: WHEEL BEARING – AUDI TT ROADSTER (8N9). USE THE FOLLOWING PROCEDURE:

1

Secure the wheels with chocks.



2

Loosen the wheel mounting bolts. Use wheel impact socket #17.



3

Raise the rear of the car and secure on supports.

4

Unscrew the wheel bolts.



## AUTODOC recommends:

- Important! Hold the wheel while unscrewing the fastening bolts. AUDI TT Roadster (8N9)

5

Remove the wheel.



6

Spread the brake pads. Use a crowbar.




7

Unscrew the brake caliper fastening. Use a combination spanner #13. Use a combination spanner #15.



8

Remove the brake caliper.




## Replacement: wheel bearing – AUDI TT Roadster (8N9). Tip:

- Tie the caliper to the suspension or to the body with a wire without disconnecting from the brake hose to prevent depressurization of the brake system.
- Make sure that the brake caliper is not hanging on the brake hose.
- Don't press the brake pedal after the brake caliper has been removed. As a result, the piston can fall out from the brake cylinder, and brake fluid leakage and depressurization of the system may occur.

9

Remove the brake pads.



10

Unscrew the brake disc mounting bolts and remove it. Use Torx T30.



## Replacement: wheel bearing – AUDI TT Roadster (8N9). AUTODOC recommends:

- If necessary, use a rubber mallet.

11

Pry up and remove the wheel hub cap. Use a crowbar.



Replacement: wheel bearing – AUDI TT Roadster (8N9). Tip from AUTODOC experts:

- If necessary, use a flat chisel and a hammer.

12

Unscrew the wheel hub fastening nut. Use drive 12-point socket #32.




13

Clean the hub. Use WD-40 spray.



14

Remove the hub and the bearing together, since they are a sealed unit. Use 3-Arm Gear Puller.



**15**

Clean the guiding part of the stub axle. Use a wire brush.



### Replacement: wheel bearing – AUDI TT Roadster (8N9). Tip from AUTODOC:

- Be careful to avoid damaging the guiding part of the stub axle.

**16**


Clean the hub bearing mounting seat. Use a wire brush. Use WD-40 spray.

**17**

Apply special grease to the bearing assembly mounting seat.

**18**

Install the new wheel hub with a bearing.



19

Move the hub as far as it can go.



20

Screw the wheel hub lock nut.



21

Tighten the hub. Important! Be sure to use new fasteners. Use drive 12-point socket #32. Use a torque wrench. Tighten it to 70 Nm torque.+45°



#### AUTODOC recommends:

- The wheel bearing unit must not tilt on the axle pin.

22

Install the cap of the hub nut.



## Replacement: wheel bearing – AUDI TT Roadster (8N9). Tip from AUTODOC:

- The cap must always be replaced. When you install the previously used cap the sealing will be lost.

**23**

Apply some copper grease to the hub where it contacts the brake disk.

**24**

Install the brake disc.

**25**

Tighten the brake disc fastening. Use Torx T30. Use a torque wrench. Tighten it to 4 Nm torque.

**26**

Clean the brake disk surface. Use a brake cleaner.

## AUTODOC recommends:

- Replacement: wheel bearing – AUDI TT Roadster (8N9). After applying the spray, wait a few minutes.

27

Install the brake pads.



28

Install the brake caliper and fix it.



29

Tighten the brake caliper bracket. Use a combination spanner #15. Use a drive socket #13. Use a torque wrench. Tighten it to 35 Nm torque.



30

Clean the wheel rim mounting seat. Use a wire brush. Treat the contacting surface. Use copper grease.



31

Install the wheel.

**AUTODOC recommends:**

- Warning! To avoid injury, hold the wheel while screwing in the fastening bolts on the car. AUDI TT Roadster (8N9)


32

Screw in the wheel bolts. Use wheel impact socket #17.



33

Lower the car and working in a cross order, tighten the wheel bolts. Use a torque wrench. Tighten it to 120 Nm torque.



34

Remove the jacks and chocks.



Replacement: wheel bearing – AUDI TT Roadster (8N9). AUTODOC experts recommend:

- Without starting the engine, press the brake pedal several times until you feel significant resistance.

**WELL DONE!** 

[VIEW MORE TUTORIALS](#)

## AUTODOC – TOP QUALITY AND AFFORDABLE CAR PARTS ONLINE

AUTODOC MOBILE APP: GREAT DEALS AND CONVENIENT SHOPPING

**AUTODOC**

GET IT ON Google Play

Download on the App Store

Download

A GREAT SELECTION OF SPARE PARTS FOR YOUR CAR

WHEEL BEARING: A WIDE SELECTION

### DISCLAIMER:

The document contains only general recommendations that may be useful for you when you perform repair or replacement work. AUTODOC shall not be liable for any loss, injury, damage of property occurring in the repair or replacement process due to incorrect use or misinterpretation of the provided information.

AUTODOC shall not be liable for any possible mistakes and uncertainties in this guide. The information provided is for information purposes only and cannot replace advice from specialists.

AUTODOC shall not be liable for incorrect or hazardous usage of equipment, tools and car parts. AUTODOC strongly recommends to be careful and observe the safety rules when performing repair or replacement works. Remember: usage of low quality auto parts does not guarantee you the appropriate level of road safety.

© Copyright 2021 – All the contents of this website, in particular texts, photographs and graphics, are protected by copyright. All rights, including reproduction, publication, editing and translation rights, are reserved by AUTODOC GmbH.