## **+** AUTODOC CLUB


How to change serpentine belt on **BMW 5 Saloon (E34)** – replacement guide







#### SIMILAR VIDEO TUTORIAL



This video shows the replacement procedure of a similar car part on another vehicle

## i Important!

This replacement procedure can be used for: BMW 5 Saloon (E34) 520i 2.0 24V, BMW 5 Saloon (E34) 525i 2.5 24V, BMW 5 Saloon (E34) 525iX 2.5 24V

The steps may slightly vary depending on the car design.

This tutorial was created based on the replacement procedure for a similar car part on: BMW 3 Saloon (E36) 323i 2.5

CLUB.AUTODOC.CO.UK 1–7









### REPLACEMENT: SERPENTINE BELT - BMW 5 SALOON (E34). TOOLS YOU MIGHT NEED:



- Torque wrench
- Drive socket # 13
- Drive socket # 16

- Ratchet wrench
- Fender cover

**Buy tools** 

CLUB.AUTODOC.CO.UK 2-7







#### Replacement: serpentine belt – BMW 5 Saloon (E34). Tip from AUTODOC:

• All work should be done with the engine stopped.

# REPLACEMENT: SERPENTINE BELT – BMW 5 SALOON (E34). RECOMMENDED SEQUENCE OF STEPS:

- Open the hood.
- Use a fender protection cover to prevent damaging paintwork and plastic parts of the car.
- Lift the car using a jack or place it over an inspection pit.
- Pull aside the AC compressor belt tensioner pulley. Use a drive socket #13. Use a ratchet wrench.



Remove the AC compressor belt.



CLUB.AUTODOC.CO.UK 3-7







- 6 Return the tensioner pulley to its initial position.
- Pull aside the V-ribbed belt tensioner pulley. Use a drive socket #16. Use a ratchet wrench.



Remove the V-ribbed belt.



Replacement: serpentine belt – BMW 5 Saloon (E34). AUTODOC experts recommend:

- Check the condition of the tensioner pulley and idler pulley. Replace them if necessary.
- 9 Install the V-ribbed belt.



CLUB.AUTODOC.CO.UK 4–7







#### Replacement: serpentine belt – BMW 5 Saloon (E34). AUTODOC recommends:

• Make sure that the V-ribbed belt fits all pulleys snugly.

Return the tensioner pulley to its initial position. Use a drive socket #16. Use a ratchet wrench.



Pull aside the AC compressor belt tensioner pulley. Use a drive socket #13.



12 Install the AC compressor belt.

13



Return the tensioner pulley to its initial position.



CLUB.AUTODOC.CO.UK 5-7







Screw in the fastener of the AC compressor belt tensioner pulley. Use a drive socket #13. Use a torque wrench. Tighten it to 7 Nm torque.



- Lower the car.
- Run the engine for a few minutes. This is necessary in order to make sure that the component operates properly.
- Shut off the engine.
- 18 Remove the fender protection cover.
- Close the hood.



**VIEW MORE TUTORIALS** 

CLUB.AUTODOC.CO.UK 6–7





## AUTODOC — TOP QUALITY AND AFFORDABLE CAR PARTS ONLINE



A GREAT SELECTION OF SPARE PARTS FOR YOUR CAR

**SERPENTINE BELT: A WIDE SELECTION** 

### (i) DISCLAIMER:

The document contains only general recommendations that may be useful for you when you perform repair or replacement work. AUTODOC shall not be liable for any loss, injury, damage of property occurring in the repair or replacement process due to incorrect use or misinterpretation of the provided information.

AUTODOC shall not be liable for any possible mistakes and uncertainties in this guide. The information provided is for information purposes only and cannot replace advice from specialists.

AUTODOC shall not be liable for incorrect or hazardous usage of equipment, tools and car parts. AUTODOC strongly recommends to be careful and observe the safety rules when performing repair or replacement works. Remember: usage of low quality auto parts does not guarantee you the appropriate level of road safety.

© Copyright 2022 – All the contents of this website, in particular texts, photographs and graphics, are protected by copyright. All rights, including reproduction, publication, editing and translation rights, are reserved by AUTODOC GmbH.

CLUB.AUTODOC.CO.UK 7-7