




How to change front anti roll bar links on **FIAT Stilo Box Body / Estate (192)** – replacement guide

SIMILAR VIDEO TUTORIAL



This video shows the replacement procedure of a similar car part on another vehicle

Important!

This replacement procedure can be used for:

FIAT Stilo Box Body / Estate (192) 1.9 JTD (192DXE1A), FIAT Stilo Box Body / Estate (192) 1.9 JTD (192DXF1A), FIAT Stilo Box Body / Estate (192) 1.9 JTD (192DXG1B), FIAT Stilo Box Body / Estate (192) 1.4 (192DXH1B), FIAT Stilo Box Body / Estate (192) 1.6 (192DXB1A), FIAT Stilo Box Body / Estate (192) 1.9 JTD (192DXS1A), FIAT Stilo Box Body / Estate (192) 1.6 (192DXR1A), FIAT Stilo Box Body / Estate (192) 1.9 JTD (192DXT1B)

The steps may slightly vary depending on the car design.

This tutorial was created based on the replacement procedure for a similar car part on: FIAT BRAVO II (198) 1.6 D Multijet

REPLACEMENT: ANTI ROLL BAR LINKS – FIAT STILO
BOX BODY / ESTATE (192). TOOLS YOU MIGHT NEED:



- Wire brush
- WD-40 spray
- Copper grease
- HEX bit No.H5
- Combination spanner #17
- Drive socket # 10
- Drive socket # 17
- Wheel impact socket #17
- Ratchet wrench
- Torque wrench
- Phillips Screwdriver
- Hydraulic transmission jack
- Wheel chock

Buy tools

AUTODOC recommends:

- Replace the stabiliser links on FIAT Stilo Box Body / Estate (192) in pairs.
- The replacement procedure is identical for both stabiliser links on the same axle.
- All work should be done with the engine stopped.

REPLACEMENT: ANTI ROLL BAR LINKS – FIAT STILO BOX BODY / ESTATE (192). RECOMMENDED SEQUENCE OF STEPS:

1 Secure the wheels with chocks.




2 Loosen the wheel mounting bolts. Use wheel impact socket #17.



3 Raise the front of the car and secure on supports.


4 Unscrew the wheel bolts.




AUTODOC recommends:

- Warning! To avoid injury, hold the wheel while unscrewing the fastening bolts.
FIAT Stilo Box Body / Estate (192)

5 Remove the wheel.



6 Chock the opposite wheel. Use a hydraulic transmission jack.



7 Clean the stabiliser link fasteners. Use a wire brush. Use WD-40 spray.



- 8 Unscrew the fastener connecting the stabilizer link to the shock strut. Use a drive socket #17. Use a ratchet wrench.



- 9 Unscrew and remove the wheel arch cover fasteners. Use a drive socket #10. Use a ratchet wrench. Use a Phillips screwdriver.




- 10 Remove the wheel arch cover.




- 11 Clean the stabiliser link fasteners. Use a wire brush. Use WD-40 spray.



- 12** Unscrew the fasteners connecting the stabiliser link to the stabiliser bar. Use HEX No.H5. Use a combination spanner #17. Use a ratchet wrench.




- 13** Remove the stabilizer rod.



Replacement: anti roll bar links – FIAT Stilo Box Body / Estate (192).
Professionals recommend:


- Examine stabiliser bushes. Replace them if needed.

- 14** Install a new rod, tighten the fasteners.




15

Tighten the fastener connecting the stabilizer link to the stabilizer bar. Use a combination spanner #17. Use HEX No.H5. Use a torque wrench. Tighten it to 55 Nm torque.



16

Remove the hydraulic transmission jack.



Replacement: anti roll bar links – FIAT Stilo Box Body / Estate (192). Tip from AUTODOC experts:

- Lower the hydraulic transmission jack smoothly, without jerks, to avoid damaging assemblies and mechanisms.

17


Tighten the fastener connecting the stabilizer link to the shock strut. Use a combination spanner #17. Use HEX No.H5. Use a torque wrench. Tighten it to 55 Nm torque.



18 Install the wheel arch cover to its mounting seat.



19 Install and tighten the wheel arch cover fasteners. Use a drive socket #10. Use a ratchet wrench. Use a Phillips screwdriver.



20 Clean the wheel rim mounting seat. Use a wire brush. Treat the contacting surface. Use copper grease.

21 Install the wheel.



AUTODOC recommends:

- Important! Hold the wheel while screwing in the fastening bolts. FIAT Stilo Box Body / Estate (192)

22

Screw in the wheel bolts. Use wheel impact socket #17.



23

Lower the car and working in a cross order, tighten the wheel bolts. Use wheel impact socket #17. Use a torque wrench. Tighten it to 120 Nm torque.



24

Remove the jacks and chocks.



WELL DONE! 

VIEW MORE TUTORIALS

AUTODOC – TOP QUALITY AND AFFORDABLE CAR PARTS ONLINE

AUTODOC MOBILE APP: GREAT DEALS AND CONVENIENT SHOPPING



+ AUTODOC

GET IT ON
 **Google Play**

 **Download on the App Store**

Download

A GREAT SELECTION OF SPARE PARTS FOR YOUR CAR

ANTI ROLL BAR LINKS: A WIDE SELECTION

DISCLAIMER:

The document contains only general recommendations that may be useful for you when you perform repair or replacement work. AUTODOC shall not be liable for any loss, injury, damage of property occurring in the repair or replacement process due to incorrect use or misinterpretation of the provided information.

AUTODOC shall not be liable for any possible mistakes and uncertainties in this guide. The information provided is for information purposes only and cannot replace advice from specialists.

AUTODOC shall not be liable for incorrect or hazardous usage of equipment, tools and car parts. AUTODOC strongly recommends to be careful and observe the safety rules when performing repair or replacement works. Remember: usage of low quality auto parts does not guarantee you the appropriate level of road safety.

© Copyright 2023 – All the contents of this website, in particular texts, photographs and graphics, are protected by copyright. All rights, including reproduction, publication, editing and translation rights, are reserved by AUTODOC SE.