+ AUTODOC CLUB

How to change front lower arm on **FORD Fiesta Mk6 Saloon** – replacement guide







SIMILAR VIDEO TUTORIAL



This video shows the replacement procedure of a similar car part on another vehicle

(i) Important!

This replacement procedure can be used for: FORD Fiesta Mk6 Saloon 1.6 Ti, FORD Fiesta Mk6 Saloon 1.6

The steps may slightly vary depending on the car design.

This tutorial was created based on the replacement procedure for a similar car part on: FORD Fiesta Mk6 Hatchback (JA8, JR8) 1.6 TDCi

CLUB.AUTODOC.CO.UK 1–13







REPLACEMENT: FRONT LOWER ARM – FORD FIESTA MK6 SALOON. TOOLS YOU NEED:



- Wire brush
- WD-40 spray
- Brake cleaner
- Copper grease
- Combination spanner #13
- Drive socket # 15
- Wheel impact socket #19
- Ratchet wrench

- Torque wrench
- Tap wrench
- Flat chisel
- Hammer
- Rubber mallet
- Hydraulic transmission jack
- Wheel chock

Buy tools

CLUB.AUTODOC.CO.UK 2-13







Replacement: front lower arm – FORD Fiesta Mk6 Saloon. AUTODOC experts recommend:

- The replacement procedure is identical for the left and right lower control arms.
- Warning! Shut down the engine before starting any work FORD Fiesta Mk6 Saloon.

CARRY OUT REPLACEMENT IN THE FOLLOWING ORDER:

1

Secure the wheels with chocks.



Loosen the wheel mounting bolts. Use wheel impact socket #19.



Raise the front of the car and secure on supports.

CLUB.AUTODOC.CO.UK 3-13







4 Unscrew the wheel bolts.



AUTODOC recommends:

Warning! To avoid injury, hold the wheel while unscrewing the fastening bolts.
FORD Fiesta Mk6 Saloon

5 Remove the wheel.



Clean all joints of the arm. Use a wire brush. Use WD-40 spray.



Replacement: front lower arm – FORD Fiesta Mk6 Saloon. Tip:

• After applying the spray, wait a few minutes.

CLUB.AUTODOC.CO.UK 4–13







Unscrew the ball joint fastening to the steering knuckle. Use a combination spanner #13. Use a drive socket #15. Use a tap wrench.



8 Remove the fastening bolt.

10



Unscrew the front arm fastener. Use a drive socket #15. Use a tap wrench.



Unscrew the rear fastener connecting the control arm to the subframe. Use a drive socket #13. Use a tap wrench.



CLUB.AUTODOC.CO.UK 5-13







Remove the rear fastener of the control arm.



Release the fastener connecting the ball joint to the steering knuckle. Use a flat metal-working chisel. Use a hammer.



Disconnect the ball joint from the steering knuckle.



Remove the front fastener of the control arm.



Remove the arm.



CLUB.AUTODOC.CO.UK 6-13







Clean the mounting seats and the thread of the suspension arm. Use a wire brush. Use WD-40 spray.



17 Install a new arm. Use a rubber mallet.



Replacement: front lower arm – FORD Fiesta Mk6 Saloon. AUTODOC recommends:

- During the installation process, use only new bolts and nuts.
- Do not damage the ball joint cover.

18 Install the control arm fasteners.



Connect the ball joint to the steering knuckle.

CLUB.AUTODOC.CO.UK 7–13







Support the arm. Use a hydraulic transmission jack.



21 Install the fastening bolt.



Screw the fasteners of the ball joint. Use a combination spanner #13. Use a drive socket #15. Use a ratchet wrench.



Screw the front arm fastener. Use a drive socket #15. Use a ratchet wrench.



CLUB.AUTODOC.CO.UK 8-13







Screw the rear fastener connecting the control arm to the subframe. Use a drive socket #15. Use a ratchet wrench.



Tighten the rear fastener connecting the arm to the body subframe. Use a drive socket #15. Use a torque wrench. Tighten it to 65 Nm torque.+180°



AUTODOC recommends:

- Important! Be sure to use new fasteners.
- Tighten the front fastener connecting the control arm to the subframe. Use a drive socket #15. Use a torque wrench. Tighten it to 65 Nm torque.+180°



CLUB.AUTODOC.CO.UK 9-13







AUTODOC recommends:

• Important! Be sure to use new fasteners.





Remove the support from under the arm.



AUTODOC recommends:

 Replacement: front lower arm – FORD Fiesta Mk6 Saloon. Lower the transmission jack smoothly, without jerks, to avoid damaging components and mechanisms.

CLUB.AUTODOC.CO.UK 10-13







Treat all joints of the arm. Use copper grease.



Treat the surface where the brake disc contacts the wheel rim. Use copper grease.



Clean the brake disk surface. Use a brake cleaner.



AUTODOC recommends:

• After applying the spray, wait a few minutes.

32 Install the wheel.



CLUB.AUTODOC.CO.UK 11-13







Replacement: front lower arm – FORD Fiesta Mk6 Saloon. Tip from AUTODOC:

• To avoid injury, hold up the wheel when screwing in the fastening bolts.





Lower the car and working in a cross order, tighten the wheel bolts. Use wheel impact socket #19. Use a torque wrench. Tighten it to 110 nm torque.



Remove the jacks and chocks.





VIEW MORE TUTORIALS


CLUB.AUTODOC.CO.UK 12-13







AUTODOC — TOP QUALITY AND AFFORDABLE CAR PARTS ONLINE



A GREAT SELECTION OF SPARE PARTS FOR YOUR CAR

CONTROL ARM: A WIDE SELECTION

(i) DISCLAIMER:

The document contains only general recommendations that may be useful for you when you perform repair or replacement work. AUTODOC shall not be liable for any loss, injury, damage of property occurring in the repair or replacement process due to incorrect use or misinterpretation of the provided information.

AUTODOC shall not be liable for any possible mistakes and uncertainties in this guide. The information provided is for information purposes only and cannot replace advice from specialists.

AUTODOC shall not be liable for incorrect or hazardous usage of equipment, tools and car parts. AUTODOC strongly recommends to be careful and observe the safety rules when performing repair or replacement works. Remember: usage of low quality auto parts does not guarantee you the appropriate level of road safety.

© Copyright 2023 – All the contents of this website, in particular texts, photographs and graphics, are protected by copyright. All rights, including reproduction, publication, editing and translation rights, are reserved by AUTODOC SE.

CLUB.AUTODOC.CO.UK 13-13