



How to change front ball
joint on **VW Lupo 6X1** –
replacement guide

VIDEO TUTORIAL




Important!

This replacement procedure can be used for:

VW Polo Hatchback (6N1) 1.3, VW Polo Hatchback (6N1) 1.6, VW Polo Hatchback (6N1) 1.0, VW Polo Hatchback (6N1) 1.9 D, VW Polo Hatchback (6N1) 1.4, VW Polo Hatchback (6N1) 1.4 16V, VW Polo Hatchback (6N1) 1.7 SDI, VW Lupo (6X1, 6E1) 1.0, VW Lupo (6X1, 6E1) 1.4 16V, VW Lupo (6X1, 6E1) 1.7 SDI, VW Polo Hatchback (6N1) 1.6 16V GTI, VW Lupo (6X1, 6E1) 1.2 TDI 3L, VW POLO Box (86CF) 1.0, VW POLO Box (86CF) 1.3, VW POLO Box (86CF) 1.4 D, (+ 13)

The steps may slightly vary depending on the car design.

REPLACEMENT: BALL JOINT – VW LUPO 6X1. TOOLS YOU'LL NEED:



- Wire brush
- WD-40 spray
- Brake cleaner
- Copper grease
- Combination spanner #17
- Drive socket # 13
- Drive socket # 19
- Wheel impact socket #17
- Ratchet wrench
- Torque wrench
- Ball joint puller
- Crow bar
- Hammer
- Wheel chock

BUY TOOLS


Replacement: ball joint – VW Lupo 6X1. AUTODOC experts recommend:

- The replacement procedure is identical for the left and right ball joints.
- All work should be done with the engine stopped.

REPLACEMENT: BALL JOINT – VW LUPO 6X1. TAKE THE FOLLOWING STEPS:


1

Secure the wheels with chocks.



2

Loosen the wheel mounting bolts. Use wheel impact socket #17.



3

Raise the front of the car and secure on supports.



4

Unscrew the wheel bolts.



AUTODOC recommends:

- Warning! To avoid injury, hold the wheel while unscrewing the fastening bolts. VW Lupo 6X1

5

Remove the wheel.




6


Clean the fastener connecting the tie rod end to the steering knuckle. Use a wire brush. Use WD-40 spray.

7


Unscrew the end fastening nut to the steering knuckle. Use a drive socket #19. Use a ratchet wrench.




8 Disconnect the tie rod end from the steering knuckle. Use a ball joint puller.




9 Clean all joints of the arm. Use a wire brush. Use WD-40 spray.




10 Unscrew the ball joint fastening to the steering knuckle. Use a combination spanner #17. Use a ratchet wrench.



11 Disconnect the ball joint from the steering knuckle. Use a crowbar. Use a hammer.




- 12** Unscrew the fastener connecting the ball joint to the suspension control arm. Use a drive socket #13. Use a ratchet wrench.




- 13** Disconnect the spherical joint from the arm.


- 14** Remove the ball joint.



- 15** Clean the ball joint mounting seat. Use a wire brush. Use WD-40 spray.



- 16** Install a new ball joint.




Replacement: ball joint – VW Lupo 6X1. AUTODOC recommends:

- Do not damage the ball joint cover.


17

Attach the ball joint to the control arm.



18

Tighten the ball joint fastener. Use a drive socket #13. Use a torque wrench. Tighten it to 20 Nm torque.+90°




AUTODOC recommends:


- Important! Be sure to use new fasteners.

19

Connect the ball joint to the steering knuckle.



20 Tighten the ball joint fastener. Use a combination spanner #17. Use a torque wrench. Tighten it to 35 nm torque.




21 Connect the tie rod end to the steering knuckle.


22 Tighten the fastening nut connecting the tie rod end to the steering knuckle. Use a drive socket #19. Use a torque wrench. Tighten it to 35 nm torque.



23 Treat the fastener connecting the tie rod end to the steering knuckle. Treat the fasteners of the ball joint. Use copper grease.



24 Treat the surface where the brake disc contacts the wheel rim. Use copper grease.



25

Clean the brake disk surface. Use a brake cleaner.




AUTODOC recommends:

- Replacement: ball joint – VW Lupo 6X1. After applying the spray, wait a few minutes.

26

Install the wheel.




Replacement: ball joint – VW Lupo 6X1. Professionals recommend:

- To avoid injury, hold up the wheel when screwing in the fastening bolts.

27

Screw in the wheel bolts. Use wheel impact socket #17.




28

Lower the car and working in a cross order, tighten the wheel bolts. Use wheel impact socket #17. Use a torque wrench. Tighten it to 110 Nm torque.

**29**

Remove the jacks and chocks.

**WELL DONE!** [VIEW MORE TUTORIALS](#)

AUTODOC – TOP QUALITY AND AFFORDABLE CAR PARTS ONLINE

AUTODOC MOBILE APP: GREAT DEALS AND CONVENIENT SHOPPING



+ AUTODOC

GET IT ON
Google Play

Download on the
App Store

Download

A GREAT SELECTION OF SPARE PARTS FOR YOUR CAR

BUY SPARE PARTS FOR VW

BALL JOINT: A WIDE SELECTION

CHOOSE CAR PARTS FOR VW LUPO 6X1

BALL JOINT FOR VW: BUY NOW

BALL JOINT FOR VW LUPO 6X1: THE BEST DEALS & OFFERS

DISCLAIMER:

The document contains only general recommendations that may be useful for you when you perform repair or replacement work. AutoDoc shall not be liable for any loss, injury, damage of property occurring in the repair or replacement process due to incorrect use or misinterpretation of the provided information.

AutoDoc shall not be liable for any possible mistakes and uncertainties in this guide. The information provided is for information purposes only and cannot replace advice from specialists.

AutoDoc shall not be liable for incorrect or hazardous usage of equipment, tools and car parts. AutoDoc strongly recommends to be careful and observe the safety rules when performing repair or replacement works. Remember: usage of low quality auto parts does not guarantee you the appropriate level of road safety.

© Copyright 2023 – All the contents of this website, in particular texts, photographs and graphics, are protected by copyright. All rights, including reproduction, publication, editing and translation rights, are reserved by Autodoc SE.