



How to change ignition
coil on **MINI Convertible**
(R52) – replacement
guide

SIMILAR VIDEO TUTORIAL



This video shows the replacement procedure of a similar car part on another vehicle

Important!


This replacement procedure can be used for:

MINI Convertible (R52) 1.6 One, MINI Convertible (R52) 1.6 Cooper, MINI Convertible (R52) 1.6 Cooper S, MINI Convertible (R52) 1.6 John Cooper Works

The steps may slightly vary depending on the car design.

This tutorial was created based on the replacement procedure for a similar car part on: MINI Hatchback (R50, R53) 1.6 Cooper

REPLACEMENT: IGNITION COIL – MINI CONVERTIBLE
(R52). TOOLS YOU'LL NEED:



- High-temperature anti-seize lubricant
- Drive socket # 10
- Ratchet wrench
- Flat screwdriver
- Fender cover

[Buy tools](#)

Replacement: ignition coil – MINI Convertible (R52). AUTODOC recommends:

- The replacement procedure is the same for the ignition coils of all cylinders.
- All work should be done with the engine stopped.

REPLACEMENT: IGNITION COIL – MINI CONVERTIBLE (R52). TAKE THE FOLLOWING STEPS:


- 1 Open the hood.
- 2 Use a fender protection cover to prevent damaging paintwork and plastic parts of the car.
- 3 Remove the spark plug wire connectors from the spark plug wells. Disconnect the spark plug wires from the ignition coil.



Replacement: ignition coil – MINI Convertible (R52). AUTODOC experts recommend:

- Be careful to avoid damaging spark plug wires.
- Remember the sequence of the spark plug wires connectors.

4 Detach the connector from the ignition coil. Use a flat screwdriver.



5 Unscrew the ignition coil bracket. Use a drive socket #10. Use a ratchet wrench.



6 Remove the ignition coil.



7 Treat the ignition coil tips. Use high-temperature grease. Use a flat screwdriver.



8 Install a new ignition coil.



9 Tighten the ignition coil fastening. Use a drive socket #10. Use a torque wrench. Tighten it to 12 Nm torque.



10 Install the spark plug wire connectors into the spark plug wells. Connect the spark plug wires to the ignition coil.



Replacement: ignition coil – MINI Convertible (R52). Tip:

- Follow the installation sequence.

11 Plug in the ignition coil connector.



12 Run the engine for a few minutes. This is necessary in order to make sure that the component operates properly.

13 Shut off the engine.

14 Remove the fender protection cover.

15

Close the hood.

WELL DONE! 

[VIEW MORE TUTORIALS](#)

AUTODOC – TOP QUALITY AND AFFORDABLE CAR PARTS ONLINE

AUTODOC MOBILE APP: GREAT DEALS AND CONVENIENT SHOPPING

AUTODOC

GET IT ON
Google Play

Download on the
App Store

Download

A GREAT SELECTION OF SPARE PARTS FOR YOUR CAR

IGNITION COIL: A WIDE SELECTION

(i) DISCLAIMER:

The document contains only general recommendations that may be useful for you when you perform repair or replacement work. AUTODOC shall not be liable for any loss, injury, damage of property occurring in the repair or replacement process due to incorrect use or misinterpretation of the provided information.

AUTODOC shall not be liable for any possible mistakes and uncertainties in this guide. The information provided is for information purposes only and cannot replace advice from specialists.

AUTODOC shall not be liable for incorrect or hazardous usage of equipment, tools and car parts. AUTODOC strongly recommends to be careful and observe the safety rules when performing repair or replacement works. Remember: usage of low quality auto parts does not guarantee you the appropriate level of road safety.

© Copyright 2021 – All the contents of this website, in particular texts, photographs and graphics, are protected by copyright. All rights, including reproduction, publication, editing and translation rights, are reserved by AUTODOC GmbH.