




How to change wheel  
bearing on a car –  
replacement tutorial

## VIDEO TUTORIAL



### WHEEL BEARING REPAIR

## REQUIRED TOOLS:



- Flat screwdriver
- Tap wrench
- Wheel impact socket
- Impact socket
- Ceramic grease
- Brake cleaner
- Jack
- Line stoppers
- Circlip pliers

**BUY TOOLS**

Please note!

- The wheel bearing allows the wheel hub to be mounted, aligned, and rotate freely on the axle
- A typical sign of wheel bearing failure is a humming noise that gets louder when turning

1

Lift up the car using a jack, jack stands, and wheel chocks; Or use a car lift



2

Remove the wheel and any parts of the brake system that obstruct access to the bearing



3

Familiarise yourself with the bearing's design



There are several types of wheel hub bearings

- Single row ball bearings and tapered roller bearings (GEN-0)
- Dual row bearings (GEN-1)
- Bearings equipped with a flange with mounting holes (GEN-2)
- Wheel hub assembly (GEN-3)


4

The wheel hub bearing assembly (GEN-3) on the drive axle is attached to the steering knuckle



5

In order to access its fasteners you need to disconnect the CV axle




AUTODOC experts recommend:


- The CV axle fastener is easier to unscrew with the car on its wheels

**6**


Depending on the car design it may be necessary to dismantle the complete steering knuckle

**7**


It needs to be disconnected from the suspension strut, control arms, and steering components

**8**


Disconnect the ball joint and the CV axle

**9**


Move the CV axle aside

**10**

Use a jack to support the steering knuckle or attach it to the ball joint



**11** Clean all fasteners




**AUTODOC recommends:**

- Tap the fasteners with a hammer to make them easier to unscrew

**12** Unscrew the wheel hub bearing fastener



**13** Remove the bearing from its seat on the steering knuckle




**Please note!**

- If removal is difficult, additional tools may be required




14 Clean the mounting seats



15 Proceed carefully, especially if there is an ABS sensor




16 Be sure to use new fasteners



17 Coat the mounting surface of the bearing with a corrosion inhibitor




18 Tighten the bolts one by one, crosswise



19

A GEN-2 (flange) bearing is normally fitted in the wheel hub, which is mounted to the axle




**Important!**

- A special puller may be needed to remove the bearing from the axle


20

Clean the hub bearing mounting seat




21

When installing this type of bearing, you should only exert force on the inner ring






**22** If the bearing is mounted on one of the drive wheels, it is necessary to dismount the wheel hub bearing assembly




**23** In this case, the bearing is attached to the steering knuckle. The wheel hub needs to be pressed out of it




**24** Replacing the double row bearing (GEN-1) requires dismantling the steering knuckle



**25** In order to dismantle this assembly, first push the wheel hub from the other side to press it out, and after gaining access to the bearing, press that out, too



**26** Use the press to apply the necessary force and proceed with precision




**27** Position the steering knuckle on its load-bearing points to prevent deformation



**28** When pressing the wheel hub out from the inner bearing ring, only apply pressure on the wheel hub




**29** Determine the diameter of the wheel hub and use the appropriate sized driver



Please note!

- If the inner ring remains on the wheel hub axle, you will need a special puller in order to remove it


**30** To press the bearing outer ring out of the steering knuckle, use the appropriate sized driver or the old inner ring



**31** When pressing the wheel hub into the bearing, apply pressure only against the inner ring



**32** Clean the work area, the mounting seats of the bearing, fasteners, and snap ring




- 33** One side of the bearing may contain an ABS sensor magnetic ring In that case, install it in the correct position, with the magnetic ring facing the ABS sensor



- 34** Make sure the bearing is level before pressing it in. Use a driver with the appropriate diameter or the old outer ring



- 35** Press the bearing all the way in



- 36** Press the inner ring on the wheel hub axle




**Please note!**

- If no press is available, the replacement can be carried out with a slide hammer or a puller


**37** Use appropriate sized drivers and a puller to remove the bearing from the steering knuckle



**38** Single row bearings (GEN-0) are normally installed in pairs in one wheel hub



**39** To press out the bearing rings, you need drivers with the appropriate diameter



**40** Apply a suitable lubricant liberally to the bearings and their seats



**41** The bearings need to be adjusted to the correct preload during installation



### Caution!

- Insufficient preload may cause play in the bearing
- Excessive preload may cause the bearing to overheat during operation
- The preload should be checked again and if necessary adjusted after driving 50 to 100 km



# AUTODOC – TOP QUALITY AND AFFORDABLE CAR PARTS ONLINE

**AUTODOC MOBILE APP: GREAT DEALS AND CONVENIENT SHOPPING**



**+ AUTODOC**

GET IT ON  **Google Play**

 **Download on the App Store**

**Download**

**A GREAT SELECTION OF SPARE PARTS FOR YOUR CAR**

**WHEEL BEARING: A WIDE SELECTION**

## **DISCLAIMER:**

The document contains only general recommendations that may be useful for you when you perform repair or replacement work. AUTODOC shall not be liable for any loss, injury, damage of property occurring in the repair or replacement process due to incorrect use or misinterpretation of the provided information.

AUTODOC shall not be liable for any possible mistakes and uncertainties in this guide. The information provided is for information purposes only and cannot replace advice from specialists.

AUTODOC shall not be liable for incorrect or hazardous usage of equipment, tools and car parts. AUTODOC strongly recommends to be careful and observe the safety rules when performing repair or replacement works. Remember: usage of low quality auto parts does not guarantee you the appropriate level of road safety.

© Copyright 2023 – All the contents of this website, in particular texts, photographs and graphics, are protected by copyright. All rights, including reproduction, publication, editing and translation rights, are reserved by AUTODOC SE.