



How to change rear
wheel bearing on **Skoda**
Octavia 1Z5 –
replacement guide

VIDEO TUTORIAL

** Important!**

This replacement procedure can be used for:

SKODA Octavia II Combi (1Z5) 1.6 LPG, SKODA OCTAVIA (1Z3) 1.6 LPG, SKODA SUPERB (3T4) 1.8 TSI, SKODA SUPERB (3T4) 1.8 TSI 4x4, SKODA SUPERB Estate (3T5) 1.8 TSI, SKODA SUPERB Estate (3T5) 1.8 TSI 4x4, SKODA SUPERB (3T4) 2.0 TSI, SKODA SUPERB (3T4) 1.6 TDI, SKODA SUPERB Estate (3T5) 2.0 TSI, SKODA SUPERB Estate (3T5) 1.6 TDI, SKODA YETI (5L) 1.6 TDI, SKODA Octavia II Combi (1Z5) 1.4, SKODA OCTAVIA (1Z3) 1.8 TSI, SKODA Octavia II Combi (1Z5) 1.8 TSI, SKODA OCTAVIA (1Z3) 2.0 TDI, (+ 45)

The steps may slightly vary depending on the car design.

REPLACEMENT: WHEEL BEARING – SKODA OCTAVIA
1Z5. TOOLS YOU MIGHT NEED:



- Wire brush
- All-purpose cleaning spray
- WD-40 spray
- Brake cleaner
- Copper grease
- Combination spanner #13
- Combination spanner #15
- Drive socket # 13
- XZN socket bit # 14
- XZN socket bit # 16
- Torx bit T30
- Wheel impact socket #17
- Ratchet wrench
- Torque wrench
- Tap wrench
- Hammer
- Rubber mallet
- Impact screwdriver
- Crow bar
- Wheel chock

BUY TOOLS

Replacement: wheel bearing – Skoda Octavia 1Z5. AUTODOC experts recommend:

- Do not re-use the bearing assembly of your Skoda Octavia 1Z5 car.
- The wheel hub bearing replacement procedure is identical for both wheels on the same axle.
- All work should be done with the engine stopped.

REPLACEMENT: WHEEL BEARING – SKODA OCTAVIA 1Z5. USE THE FOLLOWING PROCEDURE:

1

Secure the wheels with chocks.




2

Loosen the wheel mounting bolts. Use wheel impact socket #17.



3

Raise the rear of the car and secure on supports.




4 Unscrew the wheel bolts.




AUTODOC recommends:

- To avoid injury, hold up the wheel when unscrewing the bolts.


5 Remove the wheel.



6 Clean the brake caliper fasteners. Use a wire brush. Use WD-40 spray.



7 Unscrew the brake caliper fastening. Use a combination spanner #13. Use a combination spanner #15.



8

Spread the brake pads. Use a crowbar.



9


Remove the brake caliper. Use a crowbar.




Replacement: wheel bearing – Skoda Octavia 1Z5. Professionals recommend:

- Tie the caliper to the suspension or to the body with a wire without disconnecting from the brake hose to prevent depressurization of the brake system.
- Make sure that the brake caliper is not hanging on the brake hose.
- Don't press the brake pedal after the brake caliper has been removed. As a result, the piston can fall out from the brake cylinder, and brake fluid leakage and depressurization of the system may occur.
- Check the brake caliper bracket, brake caliper guide pins and boots. Clean them. Replace, if necessary.


10 Remove the brake pads. Use a crowbar.




11 Clean the brake caliper bracket fasteners. Use a wire brush. Use WD-40 spray.




12 Unscrew the caliper bracket fastening. Use XZN #14. Use a tap wrench. Use a ratchet wrench.




13 Remove the caliper bracket.




14 Clean the brake disc fasteners. Use a wire brush. Use WD-40 spray.




15 Unscrew the brake disc fastening. Use Torx T30. Use an impact screwdriver.



16 Remove the brake disc.




17 Remove the hub bearing protection cap. Use a crowbar. Use a hammer.




Replacement: wheel bearing – Skoda Octavia 1Z5. Tip from AUTODOC:

- Some cars are not equipped with wheel hub caps.

18 Unscrew the wheel hub axle nut. Use XZN #16. Use a tap wrench.




19 Remove the fastening bolt.




20 Remove the hub and the bearing together, since they are a sealed unit.



21 Clean the hub bearing mounting seat. Use all-purpose cleaning spray.




22 Install the new wheel hub with a bearing.



23 Install the fastening bolt.



24 Tighten the hub. Use XZN #16. Use a torque wrench. Tighten it to 180 Nm torque.+180°




Replacement: wheel bearing – Skoda Octavia 1Z5. Tip:

- The wheel bearing unit must not tilt on the axle pin.
- Important! Be sure to use new fasteners.

25 Install the hub bearing protection cap. Use a rubber mallet.




26 Treat the hub where it contacts the brake disk. Use copper grease.



27 Install the brake disc.



28 Tighten the brake disc fastening. Use Torx T30. Use a torque wrench. Tighten it to 4 nm torque.




29 Clean the brake caliper bracket from dirt and dust. Use a wire brush. Use a brake cleaner.




AUTODOC recommends:

- Replacement: wheel bearing – Skoda Octavia 1Z5. After applying the spray, wait a few minutes.

30 Install the brake caliper bracket.




31 Tighten the brake caliper bracket. Use XZN #14. Use a torque wrench. Tighten it to 90 Nm torque.+90°



AUTODOC recommends:

- Important! Be sure to use new fasteners.


32 Install the brake pads.




- 33** Install the brake caliper and fix it. Use a combination spanner #13. Use a combination spanner #15. Use a drive socket #13. Use a torque wrench. Tighten it to 35 Nm torque.



- 34** Treat the surface where the brake disc contacts the wheel rim. Use copper grease.




- 35** Clean the brake disk surface. Use a brake cleaner.



Replacement: wheel bearing – Skoda Octavia 1Z5. Tip from AUTODOC experts:

- After applying the spray, wait a few minutes.


36 Install the wheel.




AUTODOC recommends:

- Important! Hold the wheel while screwing in the fastening bolts. Skoda Octavia 1Z5

37 Screw in the wheel bolts. Use wheel impact socket #17.



38 Lower the car and working in a cross order, tighten the wheel bolts. Use wheel impact socket #17. Use a torque wrench. Tighten it to 120 Nm torque.



39

Remove the jacks and chocks.



WELL DONE! 

VIEW MORE TUTORIALS

AUTODOC – TOP QUALITY AND AFFORDABLE CAR PARTS ONLINE

AUTODOC MOBILE APP: GREAT DEALS AND CONVENIENT SHOPPING



+ AUTODOC

GET IT ON
Google Play

Download on the
App Store

Download

A GREAT SELECTION OF SPARE PARTS FOR YOUR CAR

BUY SPARE PARTS FOR SKODA

WHEEL BEARING: A WIDE SELECTION

CHOOSE CAR PARTS FOR SKODA OCTAVIA 1Z5

WHEEL BEARING FOR SKODA: BUY NOW

**WHEEL BEARING FOR SKODA OCTAVIA 1Z5: THE BEST
DEALS & OFFERS**

DISCLAIMER:

The document contains only general recommendations that may be useful for you when you perform repair or replacement work. AUTODOC shall not be liable for any loss, injury, damage of property occurring in the repair or replacement process due to incorrect use or misinterpretation of the provided information.

AUTODOC shall not be liable for any possible mistakes and uncertainties in this guide. The information provided is for information purposes only and cannot replace advice from specialists.

AUTODOC shall not be liable for incorrect or hazardous usage of equipment, tools and car parts. AUTODOC strongly recommends to be careful and observe the safety rules when performing repair or replacement works. Remember: usage of low quality auto parts does not guarantee you the appropriate level of road safety.

© Copyright 2023 – All the contents of this website, in particular texts, photographs and graphics, are protected by copyright. All rights, including reproduction, publication, editing and translation rights, are reserved by AUTODOC SE.