+ AUTODOC CLUB


How to change track rod end on **Toyota RAV4 II** – replacement guide







VIDEO TUTORIAL



i Important!

This replacement procedure can be used for:

TOYOTA RAV 4 II (CLA2_, XA2_, ZCA2_, ACA2_) 1.8 (ZCA25_, ZCA26_), TOYOTA RAV 4 II (CLA2_, XA2_, ZCA2_, ACA2_) 2.0 D 4WD (CLA20_, CLA21_), TOYOTA RAV 4 II (CLA2_, XA2_, ZCA2_, ACA2_) 2.4 4WD, TOYOTA RAV 4 II (CLA2_, XA2_, ZCA2_, ACA2_) 2.4 4WD (ACA23, ACA22), TOYOTA RAV 4 II (CLA2_, XA2_, ZCA2_, ACA2_) 2.0, TOYOTA RAV 4 II (CLA2_, XA2_, ZCA2_, ACA2_) 2.4

The steps may slightly vary depending on the car design.

CLUB.AUTODOC.CO.UK 1–11







REPLACEMENT: TRACK ROD END - TOYOTA RAV4 II. LIST OF THE TOOLS YOU'LL NEED:



- Wire brush
- WD-40 spray
- Brake cleaner
- Copper grease
- Combination spanner #22
- Drive socket # 17
- Wheel impact socket #17

- Ratchet wrench
- Torque wrench
- Nippers
- Vernier caliper
- Ball joint puller
- Wheel chock

BUY TOOLS

CLUB.AUTODOC.CO.UK 2-11





<u>O</u>

Replacement: track rod end – Toyota RAV4 II. AUTODOC experts recommend:

- Replace tie rod ends in pairs.
- The replacement procedure is identical for the right and left tie rod ends.
- All work should be done with the engine stopped.

REPLACEMENT: TRACK ROD END – TOYOTA RAV4 II. TAKE THE FOLLOWING STEPS:

Secure the wheels with chocks.



- Loosen the wheel mounting bolts. Use wheel impact socket #17.
- Raise the front of the car and secure on supports.



CLUB.AUTODOC.CO.UK 3-11







4 Unscrew the wheel bolts.



Replacement: track rod end – Toyota RAV4 II. AUTODOC recommends:

- To avoid injury, hold up the wheel when unscrewing the bolts.
- Remove the wheel.
- When deinstalling, mark or measure the precise position of the ball joint on the track rod, or count the number of turns in order to prevent misalignment afterward. Use a vernier caliper.



Loosen the lock nut securing the tie rod end to the tie rod. Use a combination spanner #22.



CLUB.AUTODOC.CO.UK 4-11







Remove the cotter pin fixing the tie rod end fastening. Use nippers.



- Clean the fastener connecting the tie rod end to the steering knuckle. Use a wire brush. Use WD-40 spray.
- When deinstalling, mark or measure the precise position of the ball joint on the track rod, or count the number of turns in order to prevent misalignment afterward. Use a vernier caliper.



- Unscrew the end fastening nut to the steering knuckle. Use a drive socket #17. Use a ratchet wrench.
- Disconnect the tie rod end from the steering knuckle. Use a ball joint puller.



Screw the end out of the tie rod.



CLUB.AUTODOC.CO.UK 5-11







Clean the mounting seats of the tie rod end. Use a wire brush. Use WD-40 spray.



Screw on a new tie rod end.



Replacement: track rod end – Toyota RAV4 II. Professionals recommend:

 While installing the steering rod end remember to make the same number of turns or to leave the same length of thread showing as per your measurements.

Connect the tie rod end to the steering knuckle.



CLUB.AUTODOC.CO.UK 6-11







Screw on the fastening nut that connects the tie rod end to the steering knuckle. Use a drive socket #17. Use a ratchet wrench.



Tighten the fastening nut connecting the tie rod end to the steering knuckle. Use a drive socket #17. Use a torque wrench. Tighten it to 49 nm torque.



Install the cotter pin fixing the tie rod end fastening. Use nippers.



- When deinstalling, mark or measure the precise position of the ball joint on the track rod, or count the number of turns in order to prevent misalignment afterward. Use a vernier caliper.
- Tighten the tie rod end locknut. Use a combination spanner #22. Use a torque wrench. Tighten it to 74 nm torque.



CLUB.AUTODOC.CO.UK 7-11







Treat the surface where the brake disc contacts the wheel rim. Use copper grease.



Clean the brake disk surface. Use a brake cleaner.



AUTODOC recommends:

 Replacement: track rod end – Toyota RAV4 II. After applying the spray, wait a few minutes.

24

Install the wheel.



Replacement: track rod end – Toyota RAV4 II. Tip from AUTODOC:

• To avoid injury, hold up the wheel when screwing in the fastening bolts.

CLUB.AUTODOC.CO.UK 8-11







25 Screw in the wheel bolts. Use wheel impact socket #17.



Lower the car and working in a cross order, tighten the wheel bolts. Use wheel impact socket #17. Use a torque wrench. Tighten it to 103 nm torque.



Replacement: track rod end – Toyota RAV4 II. Tip from AUTODOC experts:

· Check and adjust wheel alignment if necessary.

Remove the jacks and chocks.






VIEW MORE TUTORIALS

CLUB.AUTODOC.CO.UK 9-11





AUTODOC — TOP QUALITY AND AFFORDABLE CAR PARTS ONLINE



A GREAT SELECTION OF SPARE PARTS FOR YOUR CAR

BUY SPARE PARTS FOR TOYOTA

TRACK ROD END: A WIDE SELECTION

CLUB.AUTODOC.CO.UK 10-11







CHOOSE CAR PARTS FOR TOYOTA RAV4 II

TRACK ROD END FOR TOYOTA: BUY NOW

TRACK ROD END FOR TOYOTA RAV4 II: THE BEST DEALS & OFFERS

i DISCLAIMER:

The document contains only general recommendations that may be useful for you when you perform repair or replacement work. AUTODOC shall not be liable for any loss, injury, damage of property occurring in the repair or replacement process due to incorrect use or misinterpretation of the provided information.

AUTODOC shall not be liable for any possible mistakes and uncertainties in this guide. The information provided is for information purposes only and cannot replace advice from specialists.

AUTODOC shall not be liable for incorrect or hazardous usage of equipment, tools and car parts. AUTODOC strongly recommends to be careful and observe the safety rules when performing repair or replacement works. Remember: usage of low quality auto parts does not guarantee you the appropriate level of road safety.

© Copyright 2022 – All the contents of this website, in particular texts, photographs and graphics, are protected by copyright. All rights, including reproduction, publication, editing and translation rights, are reserved by AUTODOC GmbH.

CLUB.AUTODOC.CO.UK 11-11