



How to change spark
plugs on **SEAT Ibiza IV
Hatchback (6J5, 6P1)** –
replacement guide

SIMILAR VIDEO TUTORIAL



This video shows the replacement procedure of a similar car part on another vehicle


Important!

This replacement procedure can be used for:
SEAT Ibiza IV Hatchback (6J5, 6P1) 1.6

The steps may slightly vary depending on the car design.

This tutorial was created based on the replacement procedure for a similar car part on: SEAT Ibiza III Hatchback (6L) 1.4 16V

REPLACEMENT: SPARK PLUGS – SEAT IBIZA IV HATCHBACK (6J5, 6P1). LIST OF THE TOOLS YOU'LL NEED:



- Electronic spray
- Copper grease
- Torque wrench
- Drive socket # 10
- Spark plug socket # 16
- Ratchet wrench
- Flat Screwdriver
- Crow bar
- Microfibre towel
- Fender cover

Buy tools

Replacement: spark plugs – SEAT Ibiza IV Hatchback (6J5, 6P1). Tip from AUTODOC experts:


- The replacement procedure is the same for all spark plugs.
- All work should be done with the engine stopped.

REPLACEMENT: SPARK PLUGS – SEAT IBIZA IV HATCHBACK (6J5, 6P1). USE THE FOLLOWING PROCEDURE:

1 Open the bonnet.

2 Use a fender protection cover to prevent damaging paintwork and plastic parts of the car.

3 On the right side, detach the PCV valve hose from the engine cover.



4 Remove the engine cover assembled with the air filter housing.




AUTODOC recommends:

- Replacement: spark plugs – SEAT Ibiza IV Hatchback (6J5, 6P1). Do not use excessive force when removing the part as this may damage it.


5

Cover the throttle body with a microfibre towel to prevent dust and dirt from getting into the system.




6

Unscrew the oil filler neck.




7

Remove the oil filler neck.




8

Cover the oil filler opening with a microfibre towel to prevent dirt and foreign objects from getting into the system.




9

Undo the plastic locking tabs of the ignition coil connector. Use a flat screwdriver.



10

Unscrew the fastener of the chassis (ground) terminal of the ignition coils. Use a drive socket #10. Use a ratchet wrench.



11


Take out the ignition coil from the spark plug well. Use a crowbar.




Replacement: spark plugs – SEAT Ibiza IV Hatchback (6J5, 6P1). Tip from AUTODOC:

- Remember the sequence of steps for ignition coil demounting.


12 Unplug the connectors from the ignition coils.




13 Clean dirt, dust and debris from inside the spark plug wells.




14 Unscrew the spark plugs. Use the spark plug socket #16. Use a ratchet wrench.



15 Take out the spark plugs. Use the spark plug socket #16.



16 Apply a thin layer of special grease on the thread surface of new spark plugs. Use copper grease.




17

Install the new spark plugs into their mounting seats. Use the spark plug socket #16.



18

Screw new spark plugs and tighten them. Use the spark plug socket #16. Use a torque wrench. Tighten it to 25 nm torque.



Replacement: spark plugs – SEAT Ibiza IV Hatchback (6J5, 6P1). AUTODOC experts recommend:


- Don't tighten the plugs with excessive force. Exceeding tightening torque can damage the thread connection.
- Be careful when working with a spark plug wrench. Its skewing can cause damage to the threaded connection.

19


Treat the ignition coil connector with electronic spray. The spray will protect the electrical contacts from corrosion, oxidation, and will reduce the contact resistance.



20 Plug in the connectors of the ignition coils.



21 Install the ignition coils to the spark plug wells. Make sure you hear a click indicating that it is locked in place.




AUTODOC recommends:

- Replacement: spark plugs – SEAT Ibiza IV Hatchback (6J5, 6P1). Follow the installation steps.

22 Lock the connector.




23 Tighten the chassis (ground) terminal of the ignition coils. Use a drive socket #10. Use a ratchet wrench.



24


Remove the microfibre towel from the oil filler opening.

**25**


Install the oil filler neck. Screw in the oil filler neck.

**26**

Remove the microfibre towel from the throttle body.

**27**

Install the engine cover and secure it.




Replacement: spark plugs – SEAT Ibiza IV Hatchback (6J5, 6P1).
Professionals recommend:

- Do not apply excessive force when installing the part. Otherwise you may damage the fasteners.
- Make sure the engine cover is properly seated. It should not be displaced with respect to the guiding fasteners and the throttle body air intake hose.

28

On the right side, attach the PCV valve hose to the engine cover.



29

Remove the fender protection cover.

30

Close the hood.

31

Run the engine for a few minutes. This is necessary in order to make sure that the component operates properly.

32

Shut off the engine.

WELL DONE! 

[VIEW MORE TUTORIALS](#)

AUTODOC – TOP QUALITY AND AFFORDABLE CAR PARTS ONLINE

AUTODOC MOBILE APP: GREAT DEALS AND CONVENIENT SHOPPING



+ AUTODOC

GET IT ON
Google Play

Download on the
App Store

Download

A GREAT SELECTION OF SPARE PARTS FOR YOUR CAR

SPARK PLUGS: A WIDE SELECTION

DISCLAIMER:

The document contains only general recommendations that may be useful for you when you perform repair or replacement work. AUTODOC shall not be liable for any loss, injury, damage of property occurring in the repair or replacement process due to incorrect use or misinterpretation of the provided information.

AUTODOC shall not be liable for any possible mistakes and uncertainties in this guide. The information provided is for information purposes only and cannot replace advice from specialists.

AUTODOC shall not be liable for incorrect or hazardous usage of equipment, tools and car parts. AUTODOC strongly recommends to be careful and observe the safety rules when performing repair or replacement works. Remember: usage of low quality auto parts does not guarantee you the appropriate level of road safety.

© Copyright 2022 – All the contents of this website, in particular texts, photographs and graphics, are protected by copyright. All rights, including reproduction, publication, editing and translation rights, are reserved by AUTODOC GmbH.