- AUTODOC CLUB

How to change front brake pads on **SEAT TOLEDO I (IL)** – replacement guide



SIMILAR VIDEO TUTORIAL



This video shows the replacement procedure of a similar car part on another vehicle

(i) Important!

This replacement procedure can be used for: SEAT TOLEDO I (1L) 1.6 i, SEAT TOLEDO I (1L) 1.9 D, SEAT TOLEDO I (1L) 1.9 TD, SEAT TOLEDO I (1L) 1.8 i

The steps may slightly vary depending on the car design.

This tutorial was created based on the replacement procedure for a similar car part on: VW GOLF III (1H1) 1.9 D



REPLACEMENT: BRAKE PADS – SEAT TOLEDO I (1L). LIST OF THE TOOLS YOU'LL NEED:



- Wire brush
- Nylon cleaning brush
- WD-40 spray
- Brake cleaner
- Anti-squeal paste
- Copper grease
- Torque wrench

- HEX bit No.H7.
- Wheel impact socket #17
- Ratchet wrench
- Brake caliper wind back tool
- Crow bar
- Wheel chock

Buy tools

+ AUTODOC CLUB



Replacement: brake pads - SEAT TOLEDO I (1L). AUTODOC recommends:

- Perform the replacement of brake pads in complete set for each axis. This provides effective braking.
- The replacement procedure is identical for all brake pads on the same axle.
- All work should be done with the engine stopped.

CARRY OUT REPLACEMENT IN THE FOLLOWING ORDER:



Open the hood. Unscrew the brake fluid reservoir cap.



2

Secure the wheels with chocks.

3

Loosen the wheel mounting bolts. Use wheel impact socket #17.



+ AUTODOC CLUB





Raise the front of the car and secure on supports.



5

Unscrew the wheel bolts.



AUTODOC recommends:

• Warning! To avoid injury, hold the wheel while unscrewing the fastening bolts. SEAT TOLEDO I (1L)

6

Remove the wheel.



7

Remove the dust boot caps of the brake caliper guide pins. Use a crowbar.





8

Clean the brake caliper fasteners. Use a wire brush. Use WD-40 spray.



9

Unscrew the brake caliper fastening. Use HEX No.H7. Use a ratchet wrench.



10

Spread the brake pads. Use a crowbar.



11

Remove the brake caliper.





Replacement: brake pads – SEAT TOLEDO I (1L). Professionals recommend:

- Tie the caliper to the suspension or to the body with a wire without disconnecting from the brake hose to prevent depressurization of the brake system.
- Make sure that the brake caliper is not hanging on the brake hose.
- Don't press the brake pedal after the brake caliper has been removed. As a result, the piston can fall out from the brake cylinder, and brake fluid leakage and depressurization of the system may occur.
- Check the brake caliper bracket, brake caliper guide pins and boots. Clean them. Replace, if necessary.



Remove the brake pads. Use a crowbar.



AUTODOC recommends:

 Measure the brake disc thickness. Upon reaching the wear limit the part must be replaced.



13

Clean the brake caliper bracket from dirt and dust. Use a wire brush. Use a brake cleaner.



AUTODOC recommends:

• After applying the spray, wait a few minutes.

14

Treat the brake pads in the area where their surface comes into contact with the brake caliper bracket. Use antisqueal paste.



Replacement: brake pads – SEAT TOLEDO I (1L). Tip:

• Make sure the disc surface is clean before installing the pads.



Install new brake pads.





AUTODOC recommends:

• Make sure the pads are installed with linings facing the disc.

16

Treat the brake caliper piston. Use a nylon cleaning brush. Use a brake cleaner.



AUTODOC recommends:

• After applying the spray, wait a few minutes.

17

Press in the brake caliper piston. Use brake caliper wind back tool.



18

Install the brake caliper and fix it. Use HEX No.H7. Use a torque wrench. Tighten it to 25 Nm torque.



+ AUTODOC CLUB



19

Install the dust boot caps of the brake caliper guide pins.



20

Treat the surface where the brake disc contacts the wheel rim. Use copper grease.



21

Clean the brake disk surface. Use a brake cleaner.



Replacement: brake pads – SEAT TOLEDO I (1L). AUTODOC experts recommend:

• After applying the spray, wait a few minutes.

22

Install the wheel.





AUTODOC recommends:

• To avoid injury, hold up the wheel when screwing in the fastening bolts.

23

Screw in the wheel bolts. Use wheel impact socket #17.



24

Lower the car and working in a cross order, tighten the wheel bolts. Use wheel impact socket #17. Use a torque wrench. Tighten it to 110 Nm torque.



25

Remove the jacks and chocks.



AUTODOC recommends:

• Check the brake fluid level in the expansion tank and refill if necessary.





Tighten the brake fluid reservoir cap. Close the hood.



Replacement: brake pads – SEAT TOLEDO I (1L). Tip from AUTODOC:

- Without starting the engine, press the brake pedal several times until you feel significant resistance.
- Slow down smoothly for first 150-200 km after the brake pads replacement. Avoid unneccessary and sharp braking to a stop.



VIEW MORE TUTORIALS



AUTODOC – TOP QUALITY AND AFFORDABLE CAR PARTS ONLINE



A GREAT SELECTION OF SPARE PARTS FOR YOUR CAR

BRAKE PADS: A WIDE SELECTION

i DISCLAIMER:

The document contains only general recommendations that may be useful for you when you perform repair or replacement work. AUTODOC shall not be liable for any loss, injury, damage of property occurring in the repair or replacement process due to incorrect use or misinterpretation of the provided information.

AUTODOC shall not be liable for any possible mistakes and uncertainties in this guide. The information provided is for information purposes only and cannot replace advice from specialists.

AUTODOC shall not be liable for incorrect or hazardous usage of equipment, tools and car parts. AUTODOC strongly recommends to be careful and observe the safety rules when performing repair or replacement works. Remember: usage of low quality auto parts does not guarantee you the appropriate level of road safety.

© Copyright 2023 – All the contents of this website, in particular texts, photographs and graphics, are protected by copyright. All rights, including reproduction, publication, editing and translation rights, are reserved by AUTODOC SE.