



How to change rear
wheel bearing on
TOYOTA Auris Estate
(_E18_) – replacement
guide

SIMILAR VIDEO TUTORIAL



This video shows the replacement procedure of a similar car part on another vehicle

Important!

This replacement procedure can be used for:

TOYOTA Auris Estate (_E18_) 1.8 Hybrid (ZWE186_), TOYOTA Auris Estate (_E18_) 1.2 (NRE185_)

The steps may slightly vary depending on the car design.

This tutorial was created based on the replacement procedure for a similar car part on: TOYOTA RAV 4 III (ACA3_, ACE_, ALA3_, GSA3_, ZSA3_) 2.4 (ACA33)

REPLACEMENT: WHEEL BEARING – TOYOTA AURIS ESTATE (_E18_). TOOLS YOU MIGHT NEED:



- Wire brush
- WD-40 spray
- Copper grease
- Drive socket # 17
- Drive socket # 18
- Drive socket # 30
- Wheel impact socket #21
- Ratchet wrench
- Torque wrench
- Flat chisel
- Tap wrench
- Hammer
- Pin punch
- Hub slide hammer puller
- Crow bar
- Wheel chock

Buy tools

Replacement: wheel bearing – TOYOTA Auris Estate (_E18_). AUTODOC recommends:

- Do not re-use the bearing assembly of your TOYOTA Auris Estate (_E18_) car.
- The wheel hub bearing replacement procedure is identical for both wheels on the same axle.
- All work should be done with the engine stopped.

REPLACEMENT: WHEEL BEARING – TOYOTA AURIS ESTATE (_E18_). TAKE THE FOLLOWING STEPS:

1

Clean the wheel hub fastener. Use WD-40 spray.



2

Unstake the fastener of the driveshaft. Use a pin punch. Use a hammer.



3 Loosen the fastener of the driveshaft. Use a drive socket #30. Use a tap wrench.



4 Secure the wheels with chocks.

5 Loosen the wheel mounting bolts. Use wheel impact socket #21.

6 Raise the rear of the car and secure on supports.



7 Unscrew the wheel bolts.




AUTODOC recommends:

- Important! Hold the wheel while unscrewing the fastening bolts. TOYOTA Auris Estate (_E18_)


8 Remove the wheel.




9 Unscrew the fastener connecting the drive shaft to the wheel hub. Use a drive socket #30. Use a tap wrench.




10 Treat the splines of the driveshaft CV joint. Use WD-40 spray.




11 Remove the drive shaft. Use a pin punch. Use a hammer.




12 Spread the brake pads. Use a crowbar.




13 Clean the brake caliper bracket fasteners. Use a wire brush. Use WD-40 spray.



14 Unscrew the caliper bracket fastening. Use a drive socket #17. Use a tap wrench.



15 Remove the caliper bracket.



Replacement: wheel bearing – TOYOTA Auris Estate (_E18_). Professionals recommend:

- Tie the caliper to the suspension or to the body with a wire without disconnecting from the brake hose to prevent depressurization of the brake system.

16 Clean the brake disc fasteners. Use a wire brush. Use WD-40 spray.



17 Remove the brake disc.




18 Clean the fasteners of the wheel hub bearing. Use WD-40 spray.

19 Unscrew the hub bearing mounting. Use a drive socket #17. Use a tap wrench.



20 Remove the hub and the bearing together, since they are a sealed unit. Use the hub slide hammer puller.



21

Clean the hub bearing mounting seat. Use a wire brush. Use WD-40 spray.



22

Install the new wheel hub with a bearing.



23

Tighten the wheel hub bearing fasteners. Use a drive socket #17. Use a ratchet wrench.



24


Tighten the fastener of the wheel hub bearing. Use a drive socket #17. Use a torque wrench. Tighten it to 90 nm torque.




25 Mount the drive shaft into the wheel hub.




26 Treat the splines of the driveshaft CV joint. Use copper grease.



27 Screw the nut of the drive shaft. Use a drive socket #30. Use a tap wrench.




28 Treat the hub where it contacts the brake disk. Use copper grease.




29 Install the brake disc.



30 Clean the mounting seats of the caliper and its bracket. Use a wire brush. Use WD-40 spray.




31 Install the brake caliper bracket.



32 Tighten the brake caliper bracket. Use a drive socket #18. Use a torque wrench. Tighten it to 88 nm torque.



33 Clean the brake disk surface. Use a wire brush.



34

Treat the surface where the brake disc contacts the wheel rim. Use copper grease.



35

Install the wheel.




Replacement: wheel bearing – TOYOTA Auris Estate (_E18_). AUTODOC experts recommend:

- To avoid injury, hold up the wheel when screwing in the fastening bolts.

36

Screw in the wheel bolts. Use wheel impact socket #21.




37

Lower the car.




38 Tighten the drive shaft nut. Use a drive socket #30. Use a torque wrench. Tighten it to 216 nm torque.




39 Restake the fastener of the driveshaft. Use a flat metal-working chisel. Use a hammer.



40 Tighten the wheel bolts using a criss-cross pattern. Use a torque wrench. Tighten it to 103 Nm torque.



41 Remove the jacks and chocks.



WELL DONE! 

VIEW MORE TUTORIALS

AUTODOC – TOP QUALITY AND AFFORDABLE CAR PARTS ONLINE

AUTODOC MOBILE APP: GREAT DEALS AND CONVENIENT SHOPPING



+ AUTODOC

GET IT ON
Google Play

 Download on the
App Store

Download

A GREAT SELECTION OF SPARE PARTS FOR YOUR CAR

WHEEL BEARING: A WIDE SELECTION

DISCLAIMER:

The document contains only general recommendations that may be useful for you when you perform repair or replacement work. AUTODOC shall not be liable for any loss, injury, damage of property occurring in the repair or replacement process due to incorrect use or misinterpretation of the provided information.

AUTODOC shall not be liable for any possible mistakes and uncertainties in this guide. The information provided is for information purposes only and cannot replace advice from specialists.

AUTODOC shall not be liable for incorrect or hazardous usage of equipment, tools and car parts. AUTODOC strongly recommends to be careful and observe the safety rules when performing repair or replacement works. Remember: usage of low quality auto parts does not guarantee you the appropriate level of road safety.

© Copyright 2023 – All the contents of this website, in particular texts, photographs and graphics, are protected by copyright. All rights, including reproduction, publication, editing and translation rights, are reserved by AUTODOC SE.