

How to change serpentine belt on VW Golf IV Convertible (1E) – replacement guide





SIMILAR VIDEO TUTORIAL



This video shows the replacement procedure of a similar car part on another vehicle

i Important!

This replacement procedure can be used for: VW Golf IV Convertible (1E) 1.9 TDI

The steps may slightly vary depending on the car design.

This tutorial was created based on the replacement procedure for a similar car part on: VW Golf V Hatchback (1K1) 1.6

CLUB.AUTODOC.CO.UK 1–7





REPLACEMENT: SERPENTINE BELT – VW GOLF IV CONVERTIBLE (1E). TOOLS YOU NEED:



- Drive socket # 12
- Combination spanner #16

Ratchet wrench

Buy tools

CLUB.AUTODOC.CO.UK 2-7





Replacement: serpentine belt – VW Golf IV Convertible (1E). AUTODOC recommends:

• All work should be done with the engine stopped.

REPLACEMENT: SERPENTINE BELT – VW GOLF IV CONVERTIBLE (1E). RECOMMENDED SEQUENCE OF STEPS:

- Open the hood.
- Use a fender protection cover to prevent damaging paintwork and plastic parts of the car.
- 3 Secure the wheels with chocks.
- Lift the car using a jack or place it over an inspection pit.



5 Undo the fasteners of the oil pan lower cover. Use a drive socket #12.



CLUB.AUTODOC.CO.UK 3-7









6 Remove the oil pan cover.



Pull aside the V-ribbed belt tensioner pulley. Use a combination spanner #16.



Remove the V-ribbed belt.

9



Return the tensioner pulley to its initial position.



Replacement: serpentine belt – VW Golf IV Convertible (1E). Tip from AUTODOC:

 Check the condition of the tensioner pulley and idler pulley. Replace them if necessary.

CLUB.AUTODOC.CO.UK 4–7







10

Install the V-ribbed belt.



Replacement: serpentine belt – VW Golf IV Convertible (1E). AUTODOC experts recommend:

- Make sure that the V-ribbed belt fits all pulleys snugly.
- Pull aside the V-ribbed belt tensioner pulley. Use a combination spanner #16.
- Place the V-ribbed belt on the tensioner pulley.



Return the tensioner pulley to its initial position.



Switch on the ignition. This is necessary in order to make sure that the component operates properly.

CLUB.AUTODOC.CO.UK 5-7







15

Reinstall the oil pan lower cover.



Tighten the fasteners of the oil pan lower cover. Use a drive socket #12. Use a ratchet wrench.



- 17 Remove the jacks and chocks.
- 18 Remove the fender protection cover.
- Close the hood.



VIEW MORE TUTORIALS

CLUB.AUTODOC.CO.UK 6–7





AUTODOC — TOP QUALITY AND AFFORDABLE CAR PARTS ONLINE



A GREAT SELECTION OF SPARE PARTS FOR YOUR CAR

SERPENTINE BELT: A WIDE SELECTION

(i) DISCLAIMER:

The document contains only general recommendations that may be useful for you when you perform repair or replacement work. AUTODOC shall not be liable for any loss, injury, damage of property occurring in the repair or replacement process due to incorrect use or misinterpretation of the provided information.

AUTODOC shall not be liable for any possible mistakes and uncertainties in this guide. The information provided is for information purposes only and cannot replace advice from specialists.

AUTODOC shall not be liable for incorrect or hazardous usage of equipment, tools and car parts. AUTODOC strongly recommends to be careful and observe the safety rules when performing repair or replacement works. Remember: usage of low quality auto parts does not guarantee you the appropriate level of road safety.

© Copyright 2022 – All the contents of this website, in particular texts, photographs and graphics, are protected by copyright. All rights, including reproduction, publication, editing and translation rights, are reserved by AUTODOC GmbH.

CLUB.AUTODOC.CO.UK 7-7