




How to change
distributor rotor on **VW**
LT 28-35 I Minibus –
replacement guide

SIMILAR VIDEO TUTORIAL



This video shows the replacement procedure of a similar car part on another vehicle

Important!


This replacement procedure can be used for:

VW LT 28-35 I Minibus 2.0, VW LT 28-35 I Minibus 2.4, VW LT 28-35 I Minibus 2.4 i

The steps may slightly vary depending on the car design.

This tutorial was created based on the replacement procedure for a similar car part on: VW Golf II Hatchback (19E, 1G1) 1.6

REPLACEMENT: DISTRIBUTOR ROTOR – VW LT 28-35 I
MINIBUS. TOOLS YOU MIGHT NEED:



- Electronic spray
- Fender cover
- Crow bar

[Buy tools](#)

Replacement: distributor rotor – VW LT 28-35 I Minibus. AUTODOC experts recommend:


- Follow the terms, recommendations and requirements of the part operation provided by the manufacturer.
- Thoroughly inspect the ignition distributor assembly. Replace any worn parts.
- Please note: all work on the car – VW LT 28-35 I Minibus – should be done with the engine switched off.

CARRY OUT REPLACEMENT IN THE FOLLOWING ORDER:


1 Open the hood.

2 Use a fender protection cover to prevent damaging paintwork and plastic parts of the car.

3 Make marks on the distributor cap to indicate the installation order of the spark plug wires.



4 Disconnect the spark plug wires from the distributor cap.



Replacement: distributor rotor – VW LT 28-35 I Minibus. Tip from AUTODOC:

- Be careful to avoid damaging spark plug wires.


5

Release the distributor cap clips. Use a crowbar.



6

Remove the distributor cap.




AUTODOC recommends:

- Replacement: distributor rotor – VW LT 28-35 I Minibus. Do not use excessive force when removing the part as this may damage it.

7

Remove the ignition distributor rotor.




Replacement: distributor rotor – VW LT 28-35 I Minibus. Professionals recommend:

- Do not apply excessive force when removing the part. Otherwise you may damage it.

8

Install a new ignition distributor rotor.




AUTODOC recommends:

- When installing, do not use excessive force to avoid damage to the part.

9

Install the distributor cap.



AUTODOC recommends:

- When installing, do not use excessive force to avoid damage to the part.

10 Fasten the distributor cap clips.



11 Treat the spark plug wire connectors. Use dielectric grease.



12 Connect the spark plug wires to the distributor cap.



Replacement: distributor rotor – VW LT 28-35 I Minibus. AUTODOC recommends:

- Follow the installation sequence.

13 Run the engine for a few minutes. This is necessary in order to make sure that the component operates properly.

14 Shut off the engine.

15 Remove the fender protection cover.

16

Close the hood.

WELL DONE! 

[VIEW MORE TUTORIALS](#)

AUTODOC – TOP QUALITY AND AFFORDABLE CAR PARTS ONLINE

AUTODOC MOBILE APP: GREAT DEALS AND CONVENIENT SHOPPING

AUTODOC

GET IT ON
Google Play

Download on the
App Store

Download

A GREAT SELECTION OF SPARE PARTS FOR YOUR CAR

DISTRIBUTOR ROTOR: A WIDE SELECTION

(i) DISCLAIMER:

The document contains only general recommendations that may be useful for you when you perform repair or replacement work. AUTODOC shall not be liable for any loss, injury, damage of property occurring in the repair or replacement process due to incorrect use or misinterpretation of the provided information.

AUTODOC shall not be liable for any possible mistakes and uncertainties in this guide. The information provided is for information purposes only and cannot replace advice from specialists.

AUTODOC shall not be liable for incorrect or hazardous usage of equipment, tools and car parts. AUTODOC strongly recommends to be careful and observe the safety rules when performing repair or replacement works. Remember: usage of low quality auto parts does not guarantee you the appropriate level of road safety.

© Copyright 2022 – All the contents of this website, in particular texts, photographs and graphics, are protected by copyright. All rights, including reproduction, publication, editing and translation rights, are reserved by AUTODOC GmbH.