VIDEO TUTORIAL

ⓘ Important!

This replacement procedure can be used for:
CITROËN C2 (JM_) 1.4, CITROËN C3 I (FC_, FN_) 1.4 i, CITROËN C3 I (FC_, FN_) 1.4 i Bivalent, CITROËN C3 Pluriel (HB_) 1.4

The steps may slightly vary depending on the car design.

REQUIRED TOOLS:

- Drive socket # 7
- Drive socket # 10
- Ratchet wrench
- Phillips screwdriver
- Microfibre towel
- Fender cover

AUTODOC recommends:

- Follow the terms, recommendations and requirements of the part operation provided by the manufacturer.
- All work should be done with the engine stopped.

CARRY OUT REPLACEMENT IN THE FOLLOWING ORDER:

1

Open the bonnet.

2

Use a fender protection cover to prevent damaging paintwork and plastic parts of the car.

3

Detach the air intake hose clamp. Use a drive socket #7. Use a ratchet wrench.

4

Disconnect the crankcase ventilation hose from the air duct.

5

Unscrew the filter housing fastening bolts. Use a drive socket #10. Use a ratchet wrench.

6

Remove the air filter housing.

7

Cover the air intake hose with a microfibre towel to prevent dust and dirt from getting into the system.

8

Undo the fastening screws of the air filter cover. Use a Phillips screwdriver.

9

Take off the filter lid.

10

Remove the filter element from the filter housing.

11

Clean the air filter cover and housing.

AUTODOC recommends:

- Before cleaning the air filter cover and housing, cover the air duct parts, mass airflow sensor (if available), throttle valve with a clean cloth.

12

Insert a new filter element into the filter housing. Make sure that the filter edge fits tight to the housing.

AUTODOC recommends:

- Check out the correct location of the filter element. Do not skew.
- Take care to only use quality filters.
- During installation, make sure to prevent dust and dirt from getting into the air filter housing.

13

Reinstall the air filter cover. Fasten it.

14

Screw in the fastening screws of the air filter cover. Use a Phillips screwdriver.

15

Remove the microfibre towel from the air intake hose.

16

Reinstall the air filter housing.

17

Screw the filter housing fastening bolts. Use a drive socket #10. Use a ratchet wrench.

18

Connect the crankcase ventilation hose to the air duct.

19

Fasten the clamp on the air intake hose. Use a drive socket #7. Use a ratchet wrench.

20

Remove the fender protection cover.

21

Close the hood.

DID YOU FIND THESE INSTRUCTIONS HELPFUL?

YES NO

BECOME A MEMBER OF AUTODOC CLUB!

AUTODOC — TOP QUALITY AND AFFORDABLE CAR PARTS ONLINE

AUTODOC MOBILE APP: GREAT DEALS AND CONVENIENT SHOPPING

A GREAT SELECTION OF SPARE PARTS FOR YOUR CAR



BUY SPARE PARTS FOR CITROEN

AIR FILTERS: A WIDE SELECTION



CHOOSE CAR PARTS FOR CITROEN C3 1

AIR FILTERS FOR CITROEN: BUY NOW

CITROËN



AIR FILTERS FOR CITROEN C3 1: THE BEST DEALS & OFFERS

Disclaimer:

The document contains only general recommendations that may be useful for you when you perform repair or replacement work. AutoDoc shall not be liable for any loss, injury, damage of property occurring in the repair or replacement process due to incorrect use or misinterpretation of the provided information.

AutoDoc shall not be liable for any possible mistakes and uncertainties in this guide. The information provided is for information purposes only and cannot replace advice from specialists.

AutoDoc shall not be liable for incorrect or hazardous usage of equipment, tools and car parts. AutoDoc strongly recommends to be careful and observe the safety rules when performing repair or replacement works. Remember: usage of low quality auto parts does not guarantee you the appropriate level of road safety.

© Copyright 2018 – All the contents of this website, in particular texts, photographs and graphics, are protected by copyright. All rights, including reproduction, publication, editing and translation rights, are reserved by Autodoc GmbH.