



VIDEO TUTORIAL


Important!

This replacement procedure can be used for:

VW PASSAT (3B2) 1.9 TDI, VW PASSAT (3B3) 1.9 TDI, VW PASSAT Variant (3B5) 1.9 TDI, VW PASSAT Variant (3B6) 1.9 TDI

The steps may slightly vary depending on the car design.

REPLACEMENT: COIL SPRINGS – VW PASSAT B5 VARIANT. TOOLS YOU NEED:



- Wire brush
- WD-40 spray
- Brake cleaner
- Copper grease
- Drive socket # 16
- Combination spanner #16
- Wheel impact socket #17
- Ratchet wrench
- Torque wrench
- Hydraulic transmission jack
- Wheel chock

Replacement: coil springs – VW Passat B5 Variant. AUTODOC recommends:

- Both shock absorbers of the rear suspension should be replaced simultaneously.
- The replacement procedure is identical for the left and right shock absorbers of the rear suspension.
- Please note: all work on the car – VW Passat B5 Variant – should be done with the engine switched off.

CARRY OUT REPLACEMENT IN THE FOLLOWING ORDER:

1



Secure the wheels with chocks.

2



Loosen the wheel mounting bolts. Use wheel impact socket #17.

3



Raise the rear of the car and secure on supports.

4



Unscrew the wheel bolts.

AUTODOC recommends:

- Important! Hold the wheel while unscrewing the fastening bolts. VW Passat B5 Variant

5



Remove the wheel.

6




Clean the shock absorber fasteners. Use a wire brush. Use WD-40 spray.

7



Support the rear suspension beam. Use a hydraulic transmission jack.

8



Unscrew the lower fastener of the shock absorber. Use a combination spanner #16. Use a drive socket #16. Use a ratchet wrench.

9



Remove the fastening bolt.

10



Remove the mounting from under the rear axle beam.

AUTODOC recommends:

- Replacement: coil springs – VW Passat B5 Variant. Lower the transmission jack smoothly, without jerks, to avoid damaging components and mechanisms.

11



Support the rear suspension beam. Use a hydraulic transmission jack.

12

Unscrew the lower fastener of the shock absorber. Use a combination spanner #16. Use a drive socket #16. Use a ratchet wrench.

13

Remove the fastening bolt.

14



Remove the mounting from under the rear axle beam.

AUTODOC recommends:

- VW Passat B5 Variant – Do not lower the transmission jack sharply to avoid damaging components and mechanisms of the car.

15



Take out the spring.

16



Clean the coil spring mounting seats. Use a wire brush. Use WD-40 spray.

17



Install the coil spring together with the rubber mounts into the mounting seats.

18



Support the rear suspension beam. Use a hydraulic transmission jack.

19



Tighten the lower fastener of the shock absorber. Use a combination spanner #16. Use a drive socket #16. Use a torque wrench. Tighten it to 80 Nm torque.

20

Remove the mounting from under the rear axle beam.

AUTODOC recommends:

- Replacement: coil springs – VW Passat B5 Variant. Lower the transmission jack smoothly, without jerks, to avoid damaging components and mechanisms.

21

Support the rear suspension beam. Use a hydraulic transmission jack.

22


Tighten the lower fastener of the shock absorber. Use a combination spanner #16. Use a drive socket #16. Use a torque wrench. Tighten it to 80 Nm torque.

23



Treat the shock absorber fasteners. Use copper grease.

24



Remove the mounting from under the rear axle beam.

AUTODOC recommends:

- VW Passat B5 Variant – Do not lower the transmission jack sharply to avoid damaging components and mechanisms of the car.

25



Treat the surface where the brake disc contacts the wheel rim. Use copper grease.

26



Clean the brake disk surface. Use a brake cleaner.

AUTODOC recommends:

- Replacement: coil springs – VW Passat B5 Variant. After applying the spray, wait a few minutes.

27



Install the wheel.

AUTODOC recommends:

- Warning! To avoid injury, hold the wheel while screwing in the fastening bolts on the car. VW Passat B5 Variant

28



Screw in the wheel bolts. Use wheel impact socket #17.

29



Lower the car and working in a cross order, tighten the wheel bolts. Use a torque wrench. Tighten it to 120 nm torque.

30



Remove the jacks and chocks.

**DID YOU FIND THESE INSTRUCTIONS
HELPFUL?**

YES

NO



BECOME A MEMBER OF AUTODOC CLUB!

AUTODOC — TOP QUALITY AND AFFORDABLE CAR PARTS ONLINE

AUTODOC MOBILE APP: GREAT DEALS AND CONVENIENT SHOPPING



AUTODOC
APP

Download

 Google play

 App Store


A GREAT SELECTION OF SPARE PARTS FOR YOUR CAR



BUY SPARE PARTS FOR VW




COIL SPRINGS: A WIDE SELECTION



CHOOSE CAR PARTS FOR VW PASSAT B5 VARIANT



COIL SPRINGS FOR VW: BUY NOW



COIL SPRINGS FOR VW PASSAT B5 VARIANT: THE BEST DEALS & OFFERS



i Disclaimer:

The document contains only general recommendations that may be useful for you when you perform repair or replacement work. AutoDoc shall not be liable for any loss, injury, damage of property occurring in the repair or replacement process due to incorrect use or misinterpretation of the provided information.

AutoDoc shall not be liable for any possible mistakes and uncertainties in this guide. The information provided is for information purposes only and cannot replace advice from specialists.

AutoDoc shall not be liable for incorrect or hazardous usage of equipment, tools and car parts. AutoDoc strongly recommends to be careful and observe the safety rules when performing repair or replacement works. Remember: usage of low quality auto parts does not guarantee you the appropriate level of road safety.

© Copyright 2018 – All the contents of this website, in particular texts, photographs and graphics, are protected by copyright. All rights, including reproduction, publication, editing and translation rights, are reserved by Autodoc GmbH.