

How to change front windshield wipers on **VW Caddy 3 Kombi** – replacement guide





VIDEO TUTORIAL



(i) Important!


This replacement procedure can be used for:

VW Touran I (1T3) 1.2 TSI, VW Caddy III Van (2KA, 2KH, 2CA, 2CH) 1.9 TDI 4motion, VW Touran I (1T3) 2.0 TDI, VW Caddy III Estate (2KB, 2KJ, 2CB, 2CJ) 1.6 BiFuel, VW Caddy III Van (2KA, 2KH, 2CA, 2CH) 1.6 BiFuel, VW Caddy III Van (2KA, 2KH, 2CA, 2CH) 2.0 TDI 4motion, VW Caddy III Van (2KA, 2KH, 2CA, 2CH) 2.0 TDI, VW Caddy III Estate (2KB, 2KJ, 2CB, 2CJ) 2.0 TDI 16V 4motion, VW Caddy III Van (2KA, 2KH, 2CA, 2CH) 2.0 TDI 16V 4motion, VW Caddy III Estate (2KB, 2KJ, 2CB, 2CJ) 2.0 TDI, VW Caddy III Estate (2KB, 2KJ, 2CB, 2CJ) 2.0 TDI 16V 4motion, VW Caddy III Van (2KA, 2KH, 2CA, 2CH) 2.0 TDI 16V 4motion, VW Caddy III Estate (2KB, 2KJ, 2CB, 2CJ) 2.0 TDI, VW Touran I (1T1, 1T2) 1.6 FSI, VW Touran I (1T1, 1T2) 2.0 TDI, VW Touran I (1T1, 1T2) 1.6, VW Touran I (1T1, 1T2) 1.9 TDI, VW Touran I (1T1, 1T2) 2.0 TDI 16V, (+ 25)

The steps may slightly vary depending on the car design.











Replacement: windshield wipers – VW Caddy 3 Kombi. AUTODOC experts recommend:

- Always replace front wiper blades together. It will ensure efficient and uniform cleaning of the windshield.
- Don't confuse the wiper blades of the driver and passenger side.
- The replacement procedure for both wiper blades is identical.
- All work should be done with the engine stopped.

REPLACEMENT: WINDSHIELD WIPERS – VW CADDY 3 KOMBI. TAKE THE FOLLOWING STEPS:

Switch on the ignition. Pull the windscreen wiper stalk to the downward position.



2

1

Switch off the ignition. In the service mode, the wipers will be in the upper position.







3

Prepare the new windscreen wipers.



4

Pull the wiper arm away from the glass surface until it stops.



5

Turn the wiper blade by ninety degrees. Remove the blade from the wiper arm.



Replacement: windshield wipers – VW Caddy 3 Kombi. Tip:

• When replacing the wiper blade, take caution to prevent the spring-loaded wiper arm from hitting the glass.





6

Install the new wiper blade and carefully press the wiper arm down to the glass.



AUTODOC recommends:

• Don't touch the wiper blade at the working rubber edge to prevent damage to the graphite coating.

7

Switch on the ignition. Pull the windscreen wiper stalk to the downward position. By doing so, you will switch the windscreen wipers from the service mode to the operation mode.



Replacement: windshield wipers – VW Caddy 3 Kombi. AUTODOC experts recommend:

• Ensure that the blade rubber strip fits tightly to the glass along the entire length.




VIEW MORE TUTORIALS





AUTODOC – TOP QUALITY AND AFFORDABLE CAR PARTS ONLINE



A GREAT SELECTION OF SPARE PARTS FOR YOUR CAR

BUY SPARE PARTS FOR VW

WINDSHIELD WIPERS: A WIDE SELECTION



CHOOSE CAR PARTS FOR VW CADDY 3 KOMBI

WINDSHIELD WIPERS FOR VW: BUY NOW

WINDSHIELD WIPERS FOR VW CADDY 3 KOMBI: THE BEST DEALS & OFFERS

(i) **DISCLAIMER**:

The document contains only general recommendations that may be useful for you when you perform repair or replacement work. AUTODOC shall not be liable for any loss, injury, damage of property occurring in the repair or replacement process due to incorrect use or misinterpretation of the provided information.

AUTODOC shall not be liable for any possible mistakes and uncertainties in this guide. The information provided is for information purposes only and cannot replace advice from specialists.

AUTODOC shall not be liable for incorrect or hazardous usage of equipment, tools and car parts. AUTODOC strongly recommends to be careful and observe the safety rules when performing repair or replacement works. Remember: usage of low quality auto parts does not guarantee you the appropriate level of road safety.

© Copyright 2021 – All the contents of this website, in particular texts, photographs and graphics, are protected by copyright. All rights, including reproduction, publication, editing and translation rights, are reserved by AUTODOC GmbH.

C)