



How to change left
engine mounts on **BMW**
E39 touring –
replacement guide

VIDEO TUTORIAL

** Important!**

This replacement procedure can be used for:

BMW 5 Saloon (E39) 530d 3.0, BMW 5 Touring (E39) 530d 3.0, BMW 5 Saloon (E39) 525d 2.5, BMW 5 Touring (E39) 525d 2.5

The steps may slightly vary depending on the car design.

REPLACEMENT: ENGINE MOUNTS – BMW E39
TOURING. TOOLS YOU MIGHT NEED:



- Wire brush
- WD-40 spray
- All-purpose cleaning spray
- Copper grease
- Torque wrench
- Combination spanner #16
- Drive socket # 16
- Ratchet wrench
- Hydraulic transmission jack

BUY TOOLS

Replacement: engine mounts – BMW E39 touring. Tip from AUTODOC:

- All work should be done with the engine stopped.

REPLACEMENT: ENGINE MOUNTS – BMW E39 TOURING. TAKE THE FOLLOWING STEPS:


- 1 Lift the car using a jack or place it over an inspection pit.



- 2 Unscrew the upper fastener of the engine mount. Use a combination spanner #16.




- 3 Detach the vacuum hose from the engine mount.




4

Clean the engine mount fasteners. Use a wire brush. Use WD-40 spray.




5

Unscrew the lower fastener of the engine mount. Use a drive socket #16. Use a ratchet wrench.




6

Support the engine in the oil pan area. Use a hydraulic transmission jack.



7


Remove the engine mount.




Replacement: engine mounts – BMW E39 touring. AUTODOC experts recommend:

- Carefully check the other engine mounts and replace them if necessary.


8 Clean the mounting seat of the engine mount. Use a wire brush. Use WD-40 spray. Use all-purpose cleaning spray.



9 Install the engine mount to its mounting seat.



10 Remove the hydraulic transmission jack.



AUTODOC recommends:

- Replacement: engine mounts – BMW E39 touring. Lower the transmission jack smoothly, without jerks, to avoid damaging components and mechanisms.


- 11 Tighten the lower fastener of the engine mount. Use a drive socket #16. Use a torque wrench. Tighten it to 51 Nm torque.




- 12 Tighten the upper fastener of the engine mount. Use a drive socket #16. Use a torque wrench. Tighten it to 51 Nm torque.



- 13 Attach the vacuum hose to the engine mount.




- 14 Treat the engine mount fasteners. Use copper grease.



15

Lower the car.



WELL DONE! 

VIEW MORE TUTORIALS

AUTODOC – TOP QUALITY AND AFFORDABLE CAR PARTS ONLINE

AUTODOC MOBILE APP: GREAT DEALS AND CONVENIENT SHOPPING



+ AUTODOC

GET IT ON  **Google Play**

 **Download on the App Store**

Download

A GREAT SELECTION OF SPARE PARTS FOR YOUR CAR

BUY SPARE PARTS FOR BMW

ENGINE MOUNTS: A WIDE SELECTION

CHOOSE CAR PARTS FOR BMW E39 TOURING

ENGINE MOUNTS FOR BMW: BUY NOW

ENGINE MOUNTS FOR BMW E39 TOURING: THE BEST DEALS & OFFERS

DISCLAIMER:

The document contains only general recommendations that may be useful for you when you perform repair or replacement work. AUTODOC shall not be liable for any loss, injury, damage of property occurring in the repair or replacement process due to incorrect use or misinterpretation of the provided information.

AUTODOC shall not be liable for any possible mistakes and uncertainties in this guide. The information provided is for information purposes only and cannot replace advice from specialists.

AUTODOC shall not be liable for incorrect or hazardous usage of equipment, tools and car parts. AUTODOC strongly recommends to be careful and observe the safety rules when performing repair or replacement works. Remember: usage of low quality auto parts does not guarantee you the appropriate level of road safety.

© Copyright 2022 – All the contents of this website, in particular texts, photographs and graphics, are protected by copyright. All rights, including reproduction, publication, editing and translation rights, are reserved by AUTODOC GmbH.