



How to change rear
shock absorbers on **Audi**
A3 8PA – replacement
guide

VIDEO TUTORIAL




Important!

This replacement procedure can be used for:

AUDI A3 Hatchback (8P1) 1.6 E-Power, AUDI A3 Sportback (8PA) 1.6 E-Power, AUDI A3 Convertible (8P7) 1.4 TFSI, AUDI A3 Hatchback (8P1) 2.0 FSI, AUDI A3 Hatchback (8P1) 1.6, AUDI A3 Hatchback (8P1) 2.0 TDI 16V, AUDI A3 Hatchback (8P1) 1.9 TDI, AUDI A3 Hatchback (8P1) 2.0 TDI, AUDI A3 Hatchback (8P1) 3.2 V6 quattro, AUDI A3 Hatchback (8P1) 1.6 FSI, AUDI A3 Sportback (8PA) 1.6, AUDI A3 Sportback (8PA) 1.9 TDI, AUDI A3 Sportback (8PA) 1.6 FSI, AUDI A3 Sportback (8PA) 2.0 FSI, AUDI A3 Sportback (8PA) 3.2 V6 quattro, (+ 29)

The steps may slightly vary depending on the car design.

REPLACEMENT: SHOCK ABSORBERS – AUDI A3 8PA.
 TOOLS YOU MIGHT NEED:



- Wire brush
- WD-40 spray
- Brake cleaner
- Copper grease
- Combination spanner #18
- Drive socket # 16
- Drive socket # 18
- Torx bit T27
- Wheel impact socket #17
- Ratchet wrench
- Torque wrench
- Shock absorber socket #DD6
- Crow bar
- Vice
- Hydraulic transmission jack
- Wheel chock

BUY TOOLS

Replacement: shock absorbers – Audi A3 8PA. Professionals recommend:

- Both shock absorbers of the rear suspension should be replaced simultaneously.
- The replacement procedure is identical for the left and right shock absorbers of the rear suspension.
- All work should be done with the engine stopped.

REPLACEMENT: SHOCK ABSORBERS – AUDI A3 8PA. TAKE THE FOLLOWING STEPS:


1

Secure the wheels with chocks.




2

Loosen the wheel mounting bolts. Use wheel impact socket #17.



3

Raise the rear of the car and secure on supports.



4 Unscrew the wheel bolts.




Replacement: shock absorbers – Audi A3 8PA. Tip:

- To avoid injury, hold up the wheel when unscrewing the bolts.


5 Remove the wheel.



6 Clean the fasteners of the locker. Use a wire brush. Use WD-40 spray.



7 Unscrew the wheel arch cover fasteners. Use Torx T27.



8 Move the part aside.



9 Clean the shock absorber fasteners. Use a wire brush. Use WD-40 spray.



10 Unscrew the lower fastener of the shock absorber. Use a combination spanner #18. Use a drive socket #18. Use a ratchet wrench.




11 Support the arm. Use a hydraulic transmission jack.



12

Remove the fastening bolt.



13

Unscrew the upper fastener of the shock absorber. Use a drive socket #16. Use a ratchet wrench.




AUTODOC recommends:

- Audi A3 8PA – To avoid injury, hold the shock absorber while unscrewing the fastening bolts.

14


Remove the support from under the arm.



Replacement: shock absorbers – Audi A3 8PA. AUTODOC experts recommend:

- Lower the hydraulic transmission jack smoothly, without jerks, to avoid damaging assemblies and mechanisms.

15 Remove the shock absorber.




16 Grip the shock absorber in a vice.




17 Remove the protective cap of the shock absorber mount. Use a crowbar.



18 Clean the shock absorber rod fastener. Use a wire brush. Use WD-40 spray.



19 Remove the shock absorber piston rod fastening. Use a shock absorber socket DDN^o6. Use a drive socket #16. Use a ratchet wrench.



20

Remove the shock absorber mount, boot and bump stop.



Replacement: shock absorbers – Audi A3 8PA. Tip from AUTODOC:

- Thoroughly examine the shock absorber mount, dust boot, bump stop. Replace them if necessary.
- Before installing a new shock absorber you should pump it manually 3-5 times.

21

Install the mount, boot and bump stop onto a new shock absorber.




22


Screw the shock strut piston rod upper fastening. Use a shock absorber socket DDN#6. Use a drive socket #16. Use a torque wrench. Tighten it to 25 nm torque.



23 Treat the shock absorber rod fastener. Use copper grease.




24 Install the protective cap of the shock absorber mount.




25 Release the vice and take out the shock absorber.

26 Clean the shock absorber mounting seats. Use a wire brush. Use WD-40 spray.



27 Place the shock absorber in the wheel arch and secure it.



AUTODOC recommends:

- Important! Hold the shock absorber while screwing in the fastening bolts. Audi A3 8PA

28

Install the fastening bolt.



29

Screw in the lower fastener of the shock absorber. Use a combination spanner #18.




30

Support the arm. Use a hydraulic transmission jack.




31


Tighten the top shock absorber fastening. Use a drive socket #16. Use a torque wrench. Tighten it to 50 Nm torque.



32 Treat the shock absorber fasteners. Use copper grease.



33 Tighten the lower fastener of the shock absorber. Use a drive socket #18. Use a torque wrench. Tighten it to 120 Nm torque.



34 Remove the support from under the arm.



AUTODOC recommends:

- Audi A3 8PA – Do not lower the transmission jack sharply to avoid damaging components and mechanisms of the car.

35 Install the wheel arch cover to its mounting seat.



36 Screw in the fasteners. Use Torx T27.



37 Treat the shock absorber fasteners. Use copper grease.



38 Treat the surface where the brake disc contacts the wheel rim. Use copper grease.




39 Clean the brake disk surface. Use a brake cleaner.



Replacement: shock absorbers – Audi A3 8PA. Tip from AUTODOC experts:

- After applying the spray, wait a few minutes.


40 Install the wheel.




Replacement: shock absorbers – Audi A3 8PA. Tip:

- To avoid injury, hold up the wheel when screwing in the fastening bolts.

41 Screw in the wheel bolts. Use wheel impact socket #17.



42 Lower the car and working in a cross order, tighten the wheel bolts. Use wheel impact socket #17. Use a torque wrench. Tighten it to 120 Nm torque.



43

Remove the jacks and chocks.



WELL DONE! 

VIEW MORE TUTORIALS

AUTODOC – TOP QUALITY AND AFFORDABLE CAR PARTS ONLINE

AUTODOC MOBILE APP: GREAT DEALS AND CONVENIENT SHOPPING



+ AUTODOC

GET IT ON  **Google Play**

 **Download on the App Store**

Download

A GREAT SELECTION OF SPARE PARTS FOR YOUR CAR

BUY SPARE PARTS FOR AUDI

SHOCK ABSORBERS: A WIDE SELECTION

CHOOSE CAR PARTS FOR AUDI A3 8PA

SHOCK ABSORBERS FOR AUDI: BUY NOW

SHOCK ABSORBERS FOR AUDI A3 8PA: THE BEST DEALS & OFFERS

DISCLAIMER:

The document contains only general recommendations that may be useful for you when you perform repair or replacement work. AUTODOC shall not be liable for any loss, injury, damage of property occurring in the repair or replacement process due to incorrect use or misinterpretation of the provided information.

AUTODOC shall not be liable for any possible mistakes and uncertainties in this guide. The information provided is for information purposes only and cannot replace advice from specialists.

AUTODOC shall not be liable for incorrect or hazardous usage of equipment, tools and car parts. AUTODOC strongly recommends to be careful and observe the safety rules when performing repair or replacement works. Remember: usage of low quality auto parts does not guarantee you the appropriate level of road safety.

© Copyright 2023 – All the contents of this website, in particular texts, photographs and graphics, are protected by copyright. All rights, including reproduction, publication, editing and translation rights, are reserved by AUTODOC SE.