



How to change rear  
brake pads on **AUDI 100**  
**C3 Saloon (44, 44Q)** –  
replacement guide

## SIMILAR VIDEO TUTORIAL



This video shows the replacement procedure of a similar car part on another vehicle

### **Important!**

This replacement procedure can be used for:

AUDI 100 C3 Saloon (44, 44Q) 2.1, AUDI 100 C3 Saloon (44, 44Q) 2.2, AUDI 100 C3 Saloon (44, 44Q) 2.2 Turbo, AUDI 100 C3 Saloon (44, 44Q) 2.3 E, AUDI 100 C3 Saloon (44, 44Q) 1.8 quattro, AUDI 100 C3 Saloon (44, 44Q) 1.8 Cat quattro, AUDI 100 C3 Saloon (44, 44Q) 2.2 quattro, AUDI 100 C3 Saloon (44, 44Q) 2.2 E Turbo quattro, AUDI 100 C3 Saloon (44, 44Q) 2.3 E quattro, AUDI 100 C3 Saloon (44, 44Q) 2.3 quattro (NF), AUDI 100 C3 Saloon (44, 44Q) 2.2 E quattro, AUDI 100 C3 Saloon (44, 44Q) 2.2 Cat quattro, AUDI 100 C3 Saloon (44, 44Q) 2.2 CAT

The steps may slightly vary depending on the car design.

This tutorial was created based on the replacement procedure for a similar car part on: AUDI 80 B4 Saloon (8C2) 2.0

REPLACEMENT: BRAKE PADS – AUDI 100 C3 SALOON (44, 44Q). LIST OF THE TOOLS YOU'LL NEED:



- Wire brush
- WD-40 spray
- Brake cleaner
- Copper grease
- Anti-squeal paste
- High-temperature ceramic grease
- Torque wrench
- Combination spanner #13
- Combination spanner #15
- Wheel impact socket #17
- Brake caliper wind back tool
- Ratchet wrench
- Crow bar
- Wheel chock

[Buy tools](#)


Replacement: brake pads – AUDI 100 C3 Saloon (44, 44Q). Tip from AUTODOC:

- Perform the replacement of brake pads in complete set for each axis. This provides effective braking.
- The replacement procedure is identical for all brake pads on the same axle.
- All work should be done with the engine stopped.


**REPLACEMENT: BRAKE PADS – AUDI 100 C3 SALOON (44, 44Q).  
RECOMMENDED SEQUENCE OF STEPS:**

**1** Open the bonnet. Unscrew the brake fluid reservoir cap.

**2** Secure the wheels with chocks.



**3** Loosen the wheel mounting bolts. Use wheel impact socket #17.



**4** Raise the rear of the car and secure on supports.

5

Unscrew the wheel bolts.



AUTODOC recommends:

- Important! Hold the wheel while unscrewing the fastening bolts. AUDI 100 C3 Saloon (44, 44Q)

6

Remove the wheel.




7

Clean the brake caliper fasteners. Use a wire brush. Use a brake cleaner.

8

Unscrew the brake caliper fastening. Use a combination spanner #15. Use a combination spanner #13.



9

Spread the brake pads. Use a crowbar.



10

Remove the brake caliper.



### Replacement: brake pads – AUDI 100 C3 Saloon (44, 44Q). Tip:

- Tie the caliper to the suspension or to the body with a wire without disconnecting from the brake hose to prevent depressurization of the brake system.
- Make sure that the brake caliper is not hanging on the brake hose.
- Don't press the brake pedal after the brake caliper has been removed. As a result, the piston can fall out from the brake cylinder, and brake fluid leakage and depressurization of the system may occur.
- Check the brake caliper bracket, brake caliper guide pins and boots. Clean them. Replace, if necessary.

11

Remove the brake pads.



Replacement: brake pads – AUDI 100 C3 Saloon (44, 44Q). AUTODOC experts recommend:

- Measure the brake disc thickness. Upon reaching the wear limit the part must be replaced.

12

Clean the brake caliper bracket from dirt and dust. Use a wire brush. Use a brake cleaner.



13

Treat the brake pads in the area where their surface comes into contact with the brake caliper bracket. Use anti-squeal paste.





Replacement: brake pads – AUDI 100 C3 Saloon (44, 44Q). Tip from AUTODOC experts:

- Make sure the disc surface is clean before installing the pads.

14

Install new brake pads.



Replacement: brake pads – AUDI 100 C3 Saloon (44, 44Q). AUTODOC recommends:

- Make sure the pads are installed with linings facing the disc.

15

Treat the brake caliper piston. Use a brake cleaner.



Replacement: brake pads – AUDI 100 C3 Saloon (44, 44Q). AUTODOC experts recommend:

- After applying the spray, wait a few minutes.



16

Press in the brake caliper piston. Use brake caliper wind back tool.




17.1

Install the brake caliper and fix it.




17.2

Use a combination spanner #15. Use a combination spanner #13. Use a torque wrench. Tighten it to 35 Nm torque.



18

Treat the surface where the brake disc contacts the wheel rim. Use high-temperature ceramic grease.



19

Clean the brake disk surface. Use a brake cleaner.



**AUTODOC recommends:**

- Replacement: brake pads – AUDI 100 C3 Saloon (44, 44Q). After applying the spray, wait a few minutes.

20

Install the wheel.



Replacement: brake pads – AUDI 100 C3 Saloon (44, 44Q). Tip from AUTODOC experts:

- To avoid injury, hold up the wheel when screwing in the fastening bolts.

21

Screw in the wheel bolts. Use wheel impact socket #17.



- 22** Lower the car and working in a cross order, tighten the wheel bolts. Use wheel impact socket #17. Use a torque wrench. Tighten it to 120 nm torque.



- 23** Remove the jacks and chocks.

**AUTODOC recommends:**

- Important! Replacement: brake pads – AUDI 100 C3 Saloon (44, 44Q). Check the brake fluid level in the reservoir and top up if necessary.

- 24** Tighten the brake fluid reservoir cap. Close the hood.

**Replacement: brake pads – AUDI 100 C3 Saloon (44, 44Q). Tip:**

- Without starting the engine, press the brake pedal several times until you feel significant resistance.

**WELL DONE!** 

**VIEW MORE TUTORIALS**

# AUTODOC – TOP QUALITY AND AFFORDABLE CAR PARTS ONLINE

**AUTODOC MOBILE APP: GREAT DEALS AND CONVENIENT SHOPPING**



**AUTODOC**

GET IT ON  
 **Google Play**

Download on the  
 **App Store**

**Download**

**A GREAT SELECTION OF SPARE PARTS FOR YOUR CAR**

**BRAKE PADS: A WIDE SELECTION**

## **DISCLAIMER:**

The document contains only general recommendations that may be useful for you when you perform repair or replacement work. AUTODOC shall not be liable for any loss, injury, damage of property occurring in the repair or replacement process due to incorrect use or misinterpretation of the provided information.

AUTODOC shall not be liable for any possible mistakes and uncertainties in this guide. The information provided is for information purposes only and cannot replace advice from specialists.

AUTODOC shall not be liable for incorrect or hazardous usage of equipment, tools and car parts. AUTODOC strongly recommends to be careful and observe the safety rules when performing repair or replacement works. Remember: usage of low quality auto parts does not guarantee you the appropriate level of road safety.

© Copyright 2022 – All the contents of this website, in particular texts, photographs and graphics, are protected by copyright. All rights, including reproduction, publication, editing and translation rights, are reserved by AUTODOC GmbH.