




How to change  
serpentine belt on **AUDI**  
**A6 C6 Saloon (4F2)** –  
replacement guide

## SIMILAR VIDEO TUTORIAL



This video shows the replacement procedure of a similar car part on another vehicle

### Important!

This replacement procedure can be used for:

AUDI A6 C6 Saloon (4F2) 2.0 TFSI

The steps may slightly vary depending on the car design.

This tutorial was created based on the replacement procedure for a similar car part on: AUDI A4 B7 Saloon (8EC) 2.0 TFSI

REPLACEMENT: SERPENTINE BELT – AUDI A6 C6  
SALOON (4F2). TOOLS YOU'LL NEED:



- Combination spanner #17
- Fender cover

**Buy tools**

Replacement: serpentine belt – AUDI A6 C6 Saloon (4F2). Tip from AUTODOC experts:

- All work should be done with the engine stopped.

## REPLACEMENT: SERPENTINE BELT – AUDI A6 C6 SALOON (4F2). TAKE THE FOLLOWING STEPS:

1 Open the bonnet.

2 Use a fender protection cover to prevent damaging paintwork and plastic parts of the car.

3 Remove the engine cover.



### AUTODOC recommends:


- Replacement: serpentine belt – AUDI A6 C6 Saloon (4F2). Do not use excessive force when removing the part as this may damage it.

4 Pull aside the V-ribbed belt tensioner pulley. Use a combination spanner #17.



5

Remove the V-ribbed belt.



Replacement: serpentine belt – AUDI A6 C6 Saloon (4F2). AUTODOC recommends:


- Check the condition of the tensioner pulley and idler pulley. Replace them if necessary.

6

Return the tensioner pulley to its initial position. Use a combination spanner #17.

7

Install the V-ribbed belt.




Replacement: serpentine belt – AUDI A6 C6 Saloon (4F2). Tip:

- Make sure that the V-ribbed belt fits all pulleys snugly.

8

Pull aside the V-ribbed belt tensioner pulley. Use a combination spanner #17.

- 9 Place the V-ribbed belt on the tensioner pulley.




- 10 Return the tensioner pulley to its initial position. Use a combination spanner #17.



- 11 Run the engine for a few minutes. This is necessary in order to make sure that the component operates properly.

- 12 Shut off the engine.

- 13 Install the engine cover and secure it.



### AUTODOC recommends:

- Replacement: serpentine belt – AUDI A6 C6 Saloon (4F2). Do not use excessive force during installation. This may damage the part.
- Make sure the engine cover is properly seated. It should not be displaced with respect to the guiding fasteners.

14

Remove the fender protection cover.

15

Close the hood.

**WELL DONE!** [VIEW MORE TUTORIALS](#)

## AUTODOC – TOP QUALITY AND AFFORDABLE CAR PARTS ONLINE

**AUTODOC MOBILE APP: GREAT DEALS AND CONVENIENT SHOPPING**



**AUTODOC**

GET IT ON  
**Google Play**

Download on the  
**App Store**

**Download**

**A GREAT SELECTION OF SPARE PARTS FOR YOUR CAR**

**SERPENTINE BELT: A WIDE SELECTION**

### **ⓘ DISCLAIMER:**

The document contains only general recommendations that may be useful for you when you perform repair or replacement work. AUTODOC shall not be liable for any loss, injury, damage of property occurring in the repair or replacement process due to incorrect use or misinterpretation of the provided information.

AUTODOC shall not be liable for any possible mistakes and uncertainties in this guide. The information provided is for information purposes only and cannot replace advice from specialists.

AUTODOC shall not be liable for incorrect or hazardous usage of equipment, tools and car parts. AUTODOC strongly recommends to be careful and observe the safety rules when performing repair or replacement works. Remember: usage of low quality auto parts does not guarantee you the appropriate level of road safety.

© Copyright 2022 – All the contents of this website, in particular texts, photographs and graphics, are protected by copyright. All rights, including reproduction, publication, editing and translation rights, are reserved by AUTODOC GmbH.