



How to change rear strut
mount on **BMW Z1**
Roadster (E30) –
replacement guide

SIMILAR VIDEO TUTORIAL



This video shows the replacement procedure of a similar car part on another vehicle


i Important!

This replacement procedure can be used for:
BMW Z1 Roadster (E30) 2.5

The steps may slightly vary depending on the car design.

This tutorial was created based on the replacement procedure for a similar car part on: BMW 3 Convertible (E46) 318Ci 2.0

REPLACEMENT: STRUT MOUNT – BMW Z1 ROADSTER (E30). LIST OF THE TOOLS YOU'LL NEED:



- Wire brush
- WD-40 spray
- Copper grease
- Combination spanner #17
- Drive socket # 13
- Drive socket # 18
- Wheel impact socket #17
- Ratchet wrench
- Torque wrench
- Adjustable wrench
- Tap wrench
- Crow bar
- Vice
- Hydraulic transmission jack
- Wheel chock

[Buy tools](#)


Replacement: strut mount – BMW Z1 Roadster (E30). AUTODOC experts recommend:

- The replacement procedure is identical for the mounts of the right and left shock absorbers of the rear suspension.
- Both mounts of the rear shock struts should be replaced simultaneously.
- All work should be done with the engine stopped.

CARRY OUT REPLACEMENT IN THE FOLLOWING ORDER:

1 Press and hold the folding roof control switch. Hold the button pressed until you get access to the upper fasteners of the shock absorber.

2 Remove the shock strut mount caps. Use a crowbar.



3 Clean the fasteners of the shock absorber upper mount. Use WD-40 spray.



4

Loosen the upper fastener of the shock absorber. Use a drive socket #13. Use a ratchet wrench.




5

Secure the wheels with chocks.



6

Loosen the wheel mounting bolts. Use wheel impact socket #17.




7

Raise the rear of the car and secure on supports.

8

Unscrew the wheel bolts.



AUTODOC recommends:

- Warning! To avoid injury, hold the wheel while unscrewing the fastening bolts.
BMW Z1 Roadster (E30)


9

Remove the wheel.




10

Support the arm. Use a hydraulic transmission jack.




11

Clean the shock absorber fasteners. Use a wire brush. Use WD-40 spray.




12

Unscrew the lower fastener of the shock absorber. Use a drive socket #18. Use a tap wrench.



13

Unscrew the upper fastener of the shock absorber. Use a drive socket #13. Use a ratchet wrench.



Replacement: strut mount – BMW Z1 Roadster (E30). AUTODOC recommends:

- To avoid injuries, hold the shock absorber when undoing the fastening bolts.


14

Remove the fastening bolt.




15

Remove the shock absorber.



16

Grip the shock absorber in a vice.




17 Clean the shock absorber rod fastener. Use a wire brush.



18 Remove the shock absorber piston rod fastening. Use a combination spanner #17.



19 Release the vice and take out the shock absorber.




20 Remove the shock absorber mount, boot and bump stop.




Replacement: strut mount – BMW Z1 Roadster (E30). Tip from AUTODOC:

- Examine the shock absorber dust cap and the bump stop. Replace them if necessary.

21 Install the new mount, boot, and bump stop on the shock absorber.




22 Grip the shock absorber in a vice.




23 Screw the shock strut piston rod upper fastening. Use a combination spanner #17. Use an adjustable wrench. Use a torque wrench. Tighten it to 20 Nm torque.



24 Release the vice and take out the shock absorber.



25 Clean the shock absorber mounting seats. Use a wire brush. Use WD-40 spray.



26 Place the shock absorber in the wheel arch and secure it.



AUTODOC recommends:

- Important! Hold the shock absorber while screwing in the fastening bolts. BMW Z1 Roadster (E30)


27 Screw the upper fastener of the shock absorber. Use a drive socket #13.



28 Tighten the lower fastener of the shock absorber. Use a drive socket #18. Use a torque wrench. Tighten it to 100 Nm torque.



29 Remove the support from under the arm.



AUTODOC recommends:

- Replacement: strut mount – BMW Z1 Roadster (E30). Lower the transmission jack smoothly, without jerks, to avoid damaging components and mechanisms.

30 Clean the wheel rim mounting seat. Use a wire brush. Treat the contacting surface. Use copper grease.



31 Install the wheel.




Replacement: strut mount – BMW Z1 Roadster (E30). Professionals recommend:

- To avoid injury, hold up the wheel when screwing in the fastening bolts.

32 Screw in the wheel bolts. Use wheel impact socket #17.




33 Tighten the top shock absorber fastening. Use a drive socket #13. Use a torque wrench. Tighten it to 28 Nm torque.



34 Install the shock strut mount caps.




35 Lower the car and working in a cross order, tighten the wheel bolts. Use a torque wrench. Tighten it to 120 Nm torque.



36

Remove the jacks and chocks.



WELL DONE! 

[VIEW MORE TUTORIALS](#)

AUTODOC – TOP QUALITY AND AFFORDABLE CAR PARTS ONLINE

AUTODOC MOBILE APP: GREAT DEALS AND CONVENIENT SHOPPING

AUTODOC

GET IT ON
Google Play

Download on the
App Store

Download

A GREAT SELECTION OF SPARE PARTS FOR YOUR CAR

STRUT MOUNT: A WIDE SELECTION

(i) DISCLAIMER:

The document contains only general recommendations that may be useful for you when you perform repair or replacement work. AUTODOC shall not be liable for any loss, injury, damage of property occurring in the repair or replacement process due to incorrect use or misinterpretation of the provided information.

AUTODOC shall not be liable for any possible mistakes and uncertainties in this guide. The information provided is for information purposes only and cannot replace advice from specialists.

AUTODOC shall not be liable for incorrect or hazardous usage of equipment, tools and car parts. AUTODOC strongly recommends to be careful and observe the safety rules when performing repair or replacement works. Remember: usage of low quality auto parts does not guarantee you the appropriate level of road safety.

© Copyright 2022 – All the contents of this website, in particular texts, photographs and graphics, are protected by copyright. All rights, including reproduction, publication, editing and translation rights, are reserved by AUTODOC GmbH.