



How to change front ball
joint on **Opel Corsa S93** –
replacement guide

VIDEO TUTORIAL




i Important!

This replacement procedure can be used for:

OPEL Corsa A CC (S83) 1.0 (F08, M08, F68, M68), OPEL Corsa A CC (S83) 1.2 S (F08, M08, F68, M68), OPEL Corsa A CC (S83) 1.3 S (F08, M08, F68, M68), OPEL Corsa A CC (S83) 1.4 S (F08, M08, F68, M68), OPEL Corsa A CC (S83) 1.5 D (F08, M08, F68, M68), OPEL Corsa A CC (S83) 1.5 TD (F08, M08, F68, M68), OPEL Corsa A CC (S83) 1.2 (F08, M08, F68, M68), OPEL Corsa A CC (S83) 1.3 i (F08, M08, F68, M68), OPEL Corsa A CC (S83) 1.4 i (F08, M08, F68, M68), OPEL Corsa A CC (S83) 1.4 Si (F08, M08, F68, M68), OPEL Corsa A CC (S83) 1.6 GSI (F08, M08, F68, M68), OPEL Corsa B Hatchback (S93) 1.5 D (F08, F68, M68), OPEL Corsa B Hatchback (S93) 1.5 TD (F08, F68, M68), OPEL Corsa B Hatchback (S93) 1.2 i (X 12 SZ, C 12 NZ), OPEL Corsa B Hatchback (S93) 1.4 i (F08, F68, M68), (+ 23)

The steps may slightly vary depending on the car design.

REPLACEMENT: BALL JOINT – OPEL CORSA S93. LIST OF THE TOOLS YOU'LL NEED:



- Wire brush
- WD-40 spray
- Brake cleaner
- Copper grease
- Combination spanner #13
- Combination spanner #18
- Drive socket # 13
- Drive socket # 18
- Wheel impact socket #17
- Ratchet wrench
- Torque wrench
- Flat Screwdriver
- Crow bar
- Hammer
- Flat chisel
- Rubber mallet
- Ball joint puller
- Wheel chock

[BUY TOOLS](#)

Replacement: ball joint – Opel Corsa S93. AUTODOC experts recommend:

- The replacement procedure is identical for the left and right ball joints.
- All work should be done with the engine stopped.

REPLACEMENT: BALL JOINT – OPEL CORSA S93. USE THE FOLLOWING PROCEDURE:

1

Secure the wheels with chocks.



2

Loosen the wheel mounting bolts. Use wheel impact socket #17.



3

Raise the front of the car and secure on supports.

4

Unscrew the wheel bolts.



Replacement: ball joint – Opel Corsa S93. Tip:

- To avoid injury, hold up the wheel when unscrewing the bolts.

5

Remove the wheel.




6

Clean the fastener that connects the ball joint to the steering knuckle. Use a wire brush. Use WD-40 spray.



7

Unscrew the ball joint fastening to the steering knuckle. Use a combination spanner #13. Use a drive socket #13. Use a ratchet wrench.




8


Remove the fastening bolt. Use a hammer.




- 9** Unscrew the fastener connecting the ball joint to the suspension control arm. Use a combination spanner #18. Use a drive socket #18. Use a ratchet wrench.



- 10** Release the fastener connecting the ball joint to the steering knuckle. Use a flat metal-working chisel. Use a hammer.




- 11** Disconnect the ball joint from the steering knuckle. Use a ball joint puller.



- 12** Disconnect the spherical joint from the arm.


- 13** Remove the ball joint.



14 Remove the fastening bolts (2 pieces). Use a flat screwdriver.




15 Clean the ball joint mounting seat. Use a wire brush. Use WD-40 spray.



16 Install the fastening bolts (2 pieces).




17 Install a new ball joint.




Replacement: ball joint – Opel Corsa S93. AUTODOC experts recommend:

- Do not damage the ball joint cover.


- 18** Attach the ball joint to the control arm.



- 19** Tighten the ball joint fastener. Use a combination spanner #18. Use a drive socket #18. Use a torque wrench. Tighten it to 55 nm torque.




- 20** Connect the ball joint to the steering knuckle. Use a crowbar. Use a rubber mallet.



- 21** Install the fastening bolt.

- 22** Tighten the ball joint fastener. Use a combination spanner #13. Use a drive socket #13. Use a torque wrench. Tighten it to 30 nm torque.



- 23** Treat the fasteners of the ball joint. Use copper grease.

24

Treat the surface where the brake disc contacts the wheel rim. Use copper grease.



25

Clean the brake disk surface. Use a brake cleaner.



Replacement: ball joint – Opel Corsa S93. Tip from AUTODOC:

- After applying the spray, wait a few minutes.

26

Install the wheel.




AUTODOC recommends:

- Important! Hold the wheel while screwing in the fastening bolts. Opel Corsa S93


27

Screw in the wheel bolts. Use wheel impact socket #17.




28

Lower the car and working in a cross order, tighten the wheel bolts. Use wheel impact socket #17. Use a torque wrench. Tighten it to 110 Nm torque.



29

Remove the jacks and chocks.



WELL DONE! 

VIEW MORE TUTORIALS

AUTODOC – TOP QUALITY AND AFFORDABLE CAR PARTS ONLINE

AUTODOC MOBILE APP: GREAT DEALS AND CONVENIENT SHOPPING



+ AUTODOC

GET IT ON
 Google Play

 Download on the
App Store

Download

A GREAT SELECTION OF SPARE PARTS FOR YOUR CAR

BUY SPARE PARTS FOR OPEL

BALL JOINT: A WIDE SELECTION

CHOOSE CAR PARTS FOR OPEL CORSA S93

BALL JOINT FOR OPEL: BUY NOW

BALL JOINT FOR OPEL CORSA S93: THE BEST DEALS & OFFERS

DISCLAIMER:

The document contains only general recommendations that may be useful for you when you perform repair or replacement work. AUTODOC shall not be liable for any loss, injury, damage of property occurring in the repair or replacement process due to incorrect use or misinterpretation of the provided information.

AUTODOC shall not be liable for any possible mistakes and uncertainties in this guide. The information provided is for information purposes only and cannot replace advice from specialists.

AUTODOC shall not be liable for incorrect or hazardous usage of equipment, tools and car parts. AUTODOC strongly recommends to be careful and observe the safety rules when performing repair or replacement works. Remember: usage of low quality auto parts does not guarantee you the appropriate level of road safety.

© Copyright 2022 – All the contents of this website, in particular texts, photographs and graphics, are protected by copyright. All rights, including reproduction, publication, editing and translation rights, are reserved by AUTODOC GmbH.