

How to change front brake pads on FIAT Cinquecento Box Body / Hatchback (170) – replacement guide





SIMILAR VIDEO TUTORIAL



This video shows the replacement procedure of a similar car part on another vehicle

(i) Important!

This replacement procedure can be used for: FIAT Cinquecento Box Body / Hatchback (170) 1.1 iE (170AH), FIAT Cinquecento Box Body / Hatchback (170) 0.9 iE (170CF)

The steps may slightly vary depending on the car design.


This tutorial was created based on the replacement procedure for a similar car part on: FIAT Panda II Hatchback (169) 1.2





Ø

BOX BODY / HATCHBACK (170). LIST OF THE TOOLS YOU'LL NEED:



- Wire brush
- Nylon cleaning brush
- WD-40 spray
- All-purpose cleaning spray
- Brake cleaner
- Anti-squeal paste
- Copper grease
- Torque wrench

- Wheel impact socket #17
- Brake caliper wind back tool
- Crow bar
- Pin punch
- Hammer
- Round-nose pliers
- Wheel chock

Buy tools





Replacement: brake pads – FIAT Cinquecento Box Body / Hatchback (170). AUTODOC experts recommend:

- Perform the replacement of brake pads in complete set for each axis. This provides effective braking.
- The replacement procedure is identical for all brake pads on the same axle.
- Please note: all work on the car FIAT Cinquecento Box Body / Hatchback (170)
 should be done with the engine switched off.

CARRY OUT REPLACEMENT IN THE FOLLOWING ORDER:



Open the bonnet. Unscrew the brake fluid reservoir cap.



Secure the wheels with chocks.



3

Loosen the wheel mounting bolts. Use wheel impact socket #17.



4

Raise the front of the car and secure on supports.





Unscrew the wheel bolts.



AUTODOC recommends:

• Warning! To avoid injury, hold the wheel while unscrewing the fastening bolts. FIAT Cinquecento Box Body / Hatchback (170)



Remove the wheel.



7

Clean the brake caliper fasteners. Use a wire brush. Use WD-40 spray. Use all-purpose cleaning spray.







Spread the brake pads. Use a crowbar.



9

Remove the lock pin retainer clip. Use round-nose pliers.



10

Remove the brake caliper cotter pin. Use a pin punch. Use a hammer.



11

Lift the caliper up.







Replacement: brake pads – FIAT Cinquecento Box Body / Hatchback (170). Tip from AUTODOC experts:

- Don't press the brake pedal after the brake caliper has been removed. As a result, the piston can fall out from the brake cylinder, and brake fluid leakage and depressurization of the system may occur.
- Check the brake caliper bracket, brake caliper guide pins and boots. Clean them. Replace, if necessary.
- 12

Remove the brake pads.



Replacement: brake pads – FIAT Cinquecento Box Body / Hatchback (170). Tip from AUTODOC experts:

 Measure the brake disc thickness. Upon reaching the wear limit the part must be replaced.

13

Clean the brake caliper bracket from dirt and dust. Use a wire brush. Use all-purpose cleaning spray.







Treat the brake caliper piston. Use a nylon cleaning brush. Use a brake cleaner.



AUTODOC recommends:

 Replacement: brake pads – FIAT Cinquecento Box Body / Hatchback (170). After applying the spray, wait a few minutes.

15

Press in the brake caliper piston. Use brake caliper wind back tool.



16

Treat the brake pads in the area where their surface comes into contact with the brake caliper bracket. Use antisqueal paste.







Replacement: brake pads – FIAT Cinquecento Box Body / Hatchback (170). Tip:

• Make sure the disc surface is clean before installing the pads.

17

Install new brake pads.



Replacement: brake pads – FIAT Cinquecento Box Body / Hatchback (170). Tip from AUTODOC:

• Make sure the pads are installed with linings facing the disc.

18

Install the brake caliper and fix it.



19

Install the brake caliper cotter pin. Use a pin punch. Use a hammer.







Install the lock pin retainer clip. Use round-nose pliers.



21

Treat the surface where the brake disc contacts the wheel rim. Use copper grease.



22

Clean the brake disk surface. Use a brake cleaner.



AUTODOC recommends:

 Replacement: brake pads – FIAT Cinquecento Box Body / Hatchback (170). After applying the spray, wait a few minutes.

23

Install the wheel.







AUTODOC recommends:

- Important! Hold the wheel while screwing in the fastening bolts. FIAT Cinquecento Box Body / Hatchback (170)
- 24

Screw in the wheel bolts. Use wheel impact socket #17.



- 25
- Lower the car and working in a cross order, tighten the wheel bolts. Use wheel impact socket #17. Use a torque wrench. Tighten it to 98 Nm torque.



26

Remove the jacks and chocks.



Replacement: brake pads – FIAT Cinquecento Box Body / Hatchback (170). AUTODOC experts recommend:


• Check the brake fluid level in the expansion tank and refill if necessary.







Tighten the brake fluid reservoir cap.





VIEW MORE TUTORIALS





AUTODOC – TOP QUALITY AND AFFORDABLE CAR PARTS ONLINE



A GREAT SELECTION OF SPARE PARTS FOR YOUR CAR

BRAKE PADS: A WIDE SELECTION

(i) **DISCLAIMER**:

The document contains only general recommendations that may be useful for you when you perform repair or replacement work. AUTODOC shall not be liable for any loss, injury, damage of property occurring in the repair or replacement process due to incorrect use or misinterpretation of the provided information.

AUTODOC shall not be liable for any possible mistakes and uncertainties in this guide. The information provided is for information purposes only and cannot replace advice from specialists.

AUTODOC shall not be liable for incorrect or hazardous usage of equipment, tools and car parts. AUTODOC strongly recommends to be careful and observe the safety rules when performing repair or replacement works. Remember: usage of low quality auto parts does not guarantee you the appropriate level of road safety.

© Copyright 2022 – All the contents of this website, in particular texts, photographs and graphics, are protected by copyright. All rights, including reproduction, publication, editing and translation rights, are reserved by AUTODOC GmbH.