



How to change
serpentine belt on **FIAT**
Fiorino III Box Body /
Estate (225) –
replacement guide

SIMILAR VIDEO TUTORIAL



This video shows the replacement procedure of a similar car part on another vehicle

Important!

This replacement procedure can be used for:
FIAT Fiorino III Box Body / Estate (225) 1.3 D Multijet

The steps may slightly vary depending on the car design.

This tutorial was created based on the replacement procedure for a similar car part on: FIAT Grande Punto Hatchback (199) 1.3 D Multijet

REPLACEMENT: SERPENTINE BELT – FIAT FIORINO III
BOX BODY / ESTATE (225). TOOLS YOU'LL NEED:



- Combination spanner #15

- Fender cover

Buy tools

Replacement: serpentine belt – FIAT Fiorino III Box Body / Estate (225).
Professionals recommend:

- All work should be done with the engine stopped.

REPLACEMENT: SERPENTINE BELT – FIAT FIORINO III BOX BODY / ESTATE (225). TAKE THE FOLLOWING STEPS:

1 Open the hood.


2 Use a fender protection cover to prevent damaging paintwork and plastic parts of the car.

3 Lift the car using a jack or place it over an inspection pit.

4 Pull aside the V-ribbed belt tensioner pulley. Use a combination spanner #15.



5 Remove the V-ribbed belt.



6 Return the tensioner pulley to its initial position. Use a combination spanner #15.

Replacement: serpentine belt – FIAT Fiorino III Box Body / Estate (225).
AUTODOC recommends:


- Check the condition of the tensioner pulley and idler pulley. Replace them if necessary.

7

Pull aside the V-ribbed belt tensioner pulley. Use a combination spanner #15.

8

Install the V-ribbed belt.




Replacement: serpentine belt – FIAT Fiorino III Box Body / Estate (225).
AUTODOC experts recommend:


- Make sure that the V-ribbed belt fits all pulleys snugly.

9

Place the V-ribbed belt on the tensioner pulley.



10 Return the tensioner pulley to its initial position. Use a combination spanner #15.



11 Run the engine for a few minutes. This is necessary in order to make sure that the component operates properly.

12 Shut off the engine.

13 Lower the car.

14 Remove the fender protection cover.

15 Close the hood.

WELL DONE! 

VIEW MORE TUTORIALS

AUTODOC – TOP QUALITY AND AFFORDABLE CAR PARTS ONLINE

AUTODOC MOBILE APP: GREAT DEALS AND CONVENIENT SHOPPING

AUTODOC

GET IT ON
Google Play

Download on the
App Store

Download

A GREAT SELECTION OF SPARE PARTS FOR YOUR CAR

SERPENTINE BELT: A WIDE SELECTION

(i) DISCLAIMER:

The document contains only general recommendations that may be useful for you when you perform repair or replacement work. AUTODOC shall not be liable for any loss, injury, damage of property occurring in the repair or replacement process due to incorrect use or misinterpretation of the provided information.

AUTODOC shall not be liable for any possible mistakes and uncertainties in this guide. The information provided is for information purposes only and cannot replace advice from specialists.

AUTODOC shall not be liable for incorrect or hazardous usage of equipment, tools and car parts. AUTODOC strongly recommends to be careful and observe the safety rules when performing repair or replacement works. Remember: usage of low quality auto parts does not guarantee you the appropriate level of road safety.

© Copyright 2022 – All the contents of this website, in particular texts, photographs and graphics, are protected by copyright. All rights, including reproduction, publication, editing and translation rights, are reserved by AUTODOC GmbH.