



How to change rear  
shock absorbers on **FIAT  
Stilo Multi Wagon (192)** –  
replacement guide

## SIMILAR VIDEO TUTORIAL



This video shows the replacement procedure of a similar car part on another vehicle

### Important!


This replacement procedure can be used for:

FIAT Stilo Multi Wagon (192) 1.6 16V, FIAT Stilo Multi Wagon (192) 1.8 16V, FIAT Stilo Multi Wagon (192) 1.9 JTD, FIAT Stilo Multi Wagon (192) 1.4 16V, FIAT Stilo Multi Wagon (192) 1.9 D Multijet, FIAT Stilo Multi Wagon (192) 1.9 D Multijet (192DXT1B), FIAT Stilo Multi Wagon (192) 1.9 D

The steps may slightly vary depending on the car design.

This tutorial was created based on the replacement procedure for a similar car part on: FIAT Bravo II Hatchback (198) 1.6 D Multijet

**REPLACEMENT: SHOCK ABSORBERS – FIAT STILO  
MULTI WAGON (192). TOOLS YOU'LL NEED:**



- Wire brush
- WD-40 spray
- Copper grease
- Combination spanner #17
- Drive socket # 19
- Wheel impact socket #17
- Torque wrench
- Tap wrench
- Locking pliers
- Hydraulic transmission jack
- Wheel chock

**Buy tools**


Replacement: shock absorbers – FIAT Stilo Multi Wagon (192). AUTODOC experts recommend:

- Both shock struts of the rear suspension should be replaced simultaneously.
- The replacement procedure is identical for the left and right shock struts of the rear suspension.
- Please note: all work on the car – FIAT Stilo Multi Wagon (192) – should be done with the engine switched off.

## CARRY OUT REPLACEMENT IN THE FOLLOWING ORDER:

**1** Open the boot lid.


**2** Remove the mount cap from the shock absorber upper fastener.



**3** Loosen the upper fastener of the shock absorber. Use a combination spanner #17. Use locking pliers.



**4** Secure the wheels with chocks.



**5** Loosen the wheel mounting bolts. Use wheel impact socket #17.



**6** Raise the rear of the car and secure on supports.


**7** Unscrew the wheel bolts.




Replacement: shock absorbers – FIAT Stilo Multi Wagon (192). AUTODOC recommends:

- To avoid injury, hold up the wheel when unscrewing the bolts.

**8** Remove the wheel.




**9** Support the rear suspension beam. Use a hydraulic transmission jack.



**10** Clean the shock absorber fasteners. Use a wire brush. Use WD-40 spray.



**11** Unscrew the lower fastener of the shock absorber. Use a drive socket #19. Use a tap wrench.




**12** Unscrew the upper fastener of the shock absorber.



**13** Remove the fastening bolt. Use a drive socket #19.



**14** Remove the shock absorber.




**15** Remove the shock absorber dust cap and the bump stop.

**Replacement: shock absorbers – FIAT Stilo Multi Wagon (192). Tip:**


- Examine the shock absorber dust cap and the bump stop. Replace them if necessary.
- Before installing a new shock absorber you should pump it manually 3-5 times.

**16** Install the dust sleeve and the bump stop on the new shock absorber.


**17** Place the shock absorber in the wheel arch and fasten it.




**18** Install the fastening bolt.




**19** Screw in the lower fastener of the shock absorber. Use a drive socket #19.



**20** Raise the hydraulic transmission jack by 10-15 cm.




**21** Tighten the lower fastener of the shock absorber. Use a drive socket #19. Use a torque wrench. Tighten it to 110 Nm torque.





**22**

Remove the mounting from under the rear axle beam.




**AUTODOC recommends:**

- Replacement: shock absorbers – FIAT Stilo Multi Wagon (192). Lower the transmission jack smoothly, without jerks, to avoid damaging components and mechanisms.

**23**

Install the wheel.




**Replacement: shock absorbers – FIAT Stilo Multi Wagon (192). Tip:**

- To avoid injury, hold up the wheel when screwing in the fastening bolts.

**24**


Screw in the wheel bolts. Use wheel impact socket #17.




**25** Lower the car and working in a cross order, tighten the wheel bolts. Use a torque wrench. Tighten it to 120 Nm torque.




**26** Remove the jacks and chocks.




**27** Tighten the top shock absorber fastening. Use a combination spanner #17. Use locking pliers. Use a torque wrench. Tighten it to 25 Nm torque.



**28** Treat the shock absorber fasteners. Use copper grease.



**29** Install the mount cap on the shock absorber upper fastener.



30

Close the lid of the luggage compartment.

**WELL DONE!** 

**VIEW MORE TUTORIALS**

# AUTODOC – TOP QUALITY AND AFFORDABLE CAR PARTS ONLINE

**AUTODOC MOBILE APP: GREAT DEALS AND CONVENIENT SHOPPING**



**+ AUTODOC**

GET IT ON  
**Google Play**

 Download on the  
**App Store**

**Download**

**A GREAT SELECTION OF SPARE PARTS FOR YOUR CAR**

**SHOCK ABSORBERS: A WIDE SELECTION**

## **DISCLAIMER:**

The document contains only general recommendations that may be useful for you when you perform repair or replacement work. AUTODOC shall not be liable for any loss, injury, damage of property occurring in the repair or replacement process due to incorrect use or misinterpretation of the provided information.

AUTODOC shall not be liable for any possible mistakes and uncertainties in this guide. The information provided is for information purposes only and cannot replace advice from specialists.

AUTODOC shall not be liable for incorrect or hazardous usage of equipment, tools and car parts. AUTODOC strongly recommends to be careful and observe the safety rules when performing repair or replacement works. Remember: usage of low quality auto parts does not guarantee you the appropriate level of road safety.

© Copyright 2022 – All the contents of this website, in particular texts, photographs and graphics, are protected by copyright. All rights, including reproduction, publication, editing and translation rights, are reserved by AUTODOC GmbH.