



How to change engine  
thermostat on **FORD**  
**MONDEO III Estate**  
**(BWY)** – replacement  
guide

## SIMILAR VIDEO TUTORIAL



This video shows the replacement procedure of a similar car part on another vehicle

### Important!


This replacement procedure can be used for:

FORD MONDEO III Estate (BWY) 1.8 16V, FORD MONDEO III Estate (BWY) 2.0 16V,  
FORD MONDEO III Estate (BWY) 1.8 Sci

The steps may slightly vary depending on the car design.

This tutorial was created based on the replacement procedure for a similar car part on: FORD MONDEO III Saloon (B4Y) 2.0 16V

REPLACEMENT: ENGINE THERMOSTAT – FORD MONDEO III ESTATE (BWY). TOOLS YOU NEED:



- All-purpose cleaning spray
- Electronic spray
- Sealant
- Torque wrench
- Drive socket # 8
- Drive socket # 10
- Ratchet wrench
- Seal scraper
- Flat screwdriver
- Funnel
- Fluid container
- Clic-R collar pliers

**Buy tools**

Replacement: engine thermostat – FORD MONDEO III Estate (BWY). AUTODOC experts recommend:

- Check the condition of the coolant every time you replace the thermostat. Change the coolant if necessary.
- All work should be done with the engine stopped.

## REPLACEMENT: ENGINE THERMOSTAT – FORD MONDEO III ESTATE (BWY). TAKE THE FOLLOWING STEPS:


1

Open the bonnet.



2

Remove the engine cover.




AUTODOC recommends:

- Replacement: engine thermostat – FORD MONDEO III Estate (BWY). Do not use excessive force when removing the part as this may damage it.


**3** Unscrew the radiator grille fastener.




**4** Remove the radiator grille.




**5** Remove the retainers of the right headlight.




**6** Remove the right headlight.



**7** Detach the connector of the right headlight.



**8** Unscrew the fastener of the power steering pipe bracket. Use a drive socket #10. Use a ratchet wrench.




**9** Unscrew the coolant reservoir cap.




**10** Lift the car using a jack or place it over an inspection pit.



**11** Prepare a container for fluids.




**12** Clean the coolant drain plug. Use all-purpose cleaning spray.



**13**

Unscrew the coolant drain plug. Use a flat screwdriver.



**14**

Drain the coolant from the engine.



**Replacement: engine thermostat – FORD MONDEO III Estate (BWY).  
Professionals recommend:**

- Caution! The coolant can be very hot.
- Wear gloves to prevent contact with hot liquid.
- All work should be done with the engine stopped.
- Wait until the coolant has completely flowed out of the drain hole.

**15**

Screw in the coolant drain plug. Use a flat screwdriver.




**16** Lower the car.




**17** Loosen the clamps of the coolant hoses. Use clic-R collar pliers.




**18** Detach the clamps of the coolant hoses.



**19** Disconnect the coolant hoses from the thermostat housing.



**20** Clean the thermostat housing. Use all-purpose cleaning spray.





21

Unscrew the thermostat housing fasteners. Use a drive socket #8. Use a ratchet wrench.



22

Remove the thermostat housing together with the thermostat.




Replacement: engine thermostat – FORD MONDEO III Estate (BWY). Tip from AUTODOC:

- Do not apply excessive force when removing the part. Otherwise you may damage it.

23


Clean the mounting seats of the thermostat housing. Use all-purpose cleaning spray. Use a seal scraper.



**24** Clean the thermostat housing. Use all-purpose cleaning spray.




**25** Treat the thermostat housing. Use a sealant.



**26** Install the new thermostat housing together with the thermostat.



**27** Tighten the thermostat housing fasteners. Use a drive socket #8. Use a torque wrench. Tighten it to 6 Nm torque.



**28** Connect the coolant hoses to the thermostat housing.




**29** Attach the clamps of the coolant hoses. Use clic-R collar pliers.




**30** Screw on the fastener of the power steering pipe bracket.



**31** Treat the connector of the right headlight. Use dielectric grease.




**32** Attach the connector of the right headlight.




**33** Install the right headlight.



**34** Install the retainers of the right headlight.



**35** Install the radiator grille.




**36** Screw in the fastener of the radiator grille.



**37** Remove the coolant reservoir cap.



**38** Insert the funnel.



**39**

Pour coolant in the coolant reservoir.




**Replacement: engine thermostat – FORD MONDEO III Estate (BWY). AUTODOC recommends:**

- Only use the coolant recommended by the manufacturer.
- The coolant level should be at the MAX mark.
- Wait until the air goes out of the system.

**40**

Run the engine for a few minutes. This should be done in order to remove residual air from the cooling system and to check if the components are operating correctly.



**41**

Shut off the engine.

**42**


Check the coolant level. If necessary, top up to the required level.

**43**

Install the coolant reservoir cap.


44

Screw on the coolant reservoir cap.



45

Install the engine cover and secure it.




**AUTODOC recommends:**

- Replacement: engine thermostat – FORD MONDEO III Estate (BWY). To avoid damaging the part during installation, do not use excessive force.

46

Close the hood.



**WELL DONE!** 

**VIEW MORE TUTORIALS**

## AUTODOC – TOP QUALITY AND AFFORDABLE CAR PARTS ONLINE

**AUTODOC MOBILE APP: GREAT DEALS AND CONVENIENT SHOPPING**



**+ AUTODOC**

GET IT ON  
**Google Play**

Download on the  
**App Store**

**Download**

**A GREAT SELECTION OF SPARE PARTS FOR YOUR CAR**

**ENGINE THERMOSTAT: A WIDE SELECTION**

### **i DISCLAIMER:**

The document contains only general recommendations that may be useful for you when you perform repair or replacement work. AUTODOC shall not be liable for any loss, injury, damage of property occurring in the repair or replacement process due to incorrect use or misinterpretation of the provided information.

AUTODOC shall not be liable for any possible mistakes and uncertainties in this guide. The information provided is for information purposes only and cannot replace advice from specialists.

AUTODOC shall not be liable for incorrect or hazardous usage of equipment, tools and car parts. AUTODOC strongly recommends to be careful and observe the safety rules when performing repair or replacement works. Remember: usage of low quality auto parts does not guarantee you the appropriate level of road safety.

© Copyright 2022 – All the contents of this website, in particular texts, photographs and graphics, are protected by copyright. All rights, including reproduction, publication, editing and translation rights, are reserved by AUTODOC GmbH.