- AUTODOC CLUB

How to change air filter on **FORD TOURNEO COURIER Kombi** – replacement guide



SIMILAR VIDEO TUTORIAL




This video shows the replacement procedure of a similar car part on another vehicle

(i) Important!

This replacement procedure can be used for: FORD TOURNEO COURIER Kombi 1.0 EcoBoost, FORD TOURNEO COURIER Kombi 1.5 TDCi, FORD TOURNEO COURIER Kombi 1.6 TDCi

The steps may slightly vary depending on the car design.

This tutorial was created based on the replacement procedure for a similar car part on: FORD Fiesta Mk6 Hatchback (JA8, JR8) 1.6 TDCi



REPLACEMENT: AIR FILTER – FORD TOURNEO COURIER KOMBI. TOOLS YOU NEED:

O

4

+ AUTODOC CLUB



Replacement: air filter – FORD TOURNEO COURIER Kombi. AUTODOC experts recommend:

- Follow the terms, recommendations and requirements of the part operation provided by the manufacturer.
- Please note: all work on the car FORD TOURNEO COURIER Kombi should be done with the engine switched off.

CARRY OUT REPLACEMENT IN THE FOLLOWING ORDER:



Use a fender protection cover to prevent damaging paintwork and plastic parts of the car.



Undo the fastening screws of the air filter cover. Use a drive socket #10. Use a ratchet wrench.



4

Take off the filter lid.

Open the bonnet.





AUTODOC recommends:

 Replacement: air filter – FORD TOURNEO COURIER Kombi. Do not use excessive force when removing the part as this may damage it.



Remove the filter element from the filter housing.



6

Cover the air intake hose with a microfibre towel to prevent dust and dirt from getting into the system.



7

Clean the air filter cover and housing.



Replacement: air filter – FORD TOURNEO COURIER Kombi. Tip:

• Before cleaning the air filter cover and housing, cover the air duct parts, mass airflow sensor (if available), throttle valve with a clean cloth.

+ AUTODOC CLUB



8

Remove the microfibre towel from the air intake hose.



9

Insert a new filter element into the filter housing. Make sure that the filter edge fits tight to the housing.



AUTODOC recommends:

- Replacement: air filter FORD TOURNEO COURIER Kombi. Be sure to position the filtering element correctly. Avoid misalignment.
- Take care to only use quality filters.
- During installation, make sure to prevent dust and dirt from getting into the air filter housing.

10

Reinstall the air filter cover. Fasten it.





AUTODOC recommends:

 Replacement: air filter – FORD TOURNEO COURIER Kombi. Do not use excessive force during installation. This may damage the fasteners.

11

Screw in the fastening screws of the air filter cover. Use a drive socket #10. Use a ratchet wrench.



12

13

Remove the fender protection cover.

Close the hood.



VIEW MORE TUTORIALS



AUTODOC – TOP QUALITY AND AFFORDABLE CAR PARTS ONLINE



A GREAT SELECTION OF SPARE PARTS FOR YOUR CAR

AIR FILTER: A WIDE SELECTION

(i) **DISCLAIMER**:

The document contains only general recommendations that may be useful for you when you perform repair or replacement work. AUTODOC shall not be liable for any loss, injury, damage of property occurring in the repair or replacement process due to incorrect use or misinterpretation of the provided information.

AUTODOC shall not be liable for any possible mistakes and uncertainties in this guide. The information provided is for information purposes only and cannot replace advice from specialists.

AUTODOC shall not be liable for incorrect or hazardous usage of equipment, tools and car parts. AUTODOC strongly recommends to be careful and observe the safety rules when performing repair or replacement works. Remember: usage of low quality auto parts does not guarantee you the appropriate level of road safety.

© Copyright 2023 – All the contents of this website, in particular texts, photographs and graphics, are protected by copyright. All rights, including reproduction, publication, editing and translation rights, are reserved by AUTODOC SE.