



How to change engine
thermostat on **FORD**
Transit Mk6 Tourneo –
replacement guide

SIMILAR VIDEO TUTORIAL



This video shows the replacement procedure of a similar car part on another vehicle

Important!

This replacement procedure can be used for:
FORD TRANSIT TOURNEO 2.2 TDCi, FORD TRANSIT TOURNEO 2.2

The steps may slightly vary depending on the car design.

This tutorial was created based on the replacement procedure for a similar car part on: FORD Transit Mk6 Box (V347, V348, FA) 2.2 TDCi

REPLACEMENT: ENGINE THERMOSTAT – FORD TRANSIT MK6 TOURNEO. TOOLS YOU MIGHT NEED:



- Wire brush
- All-purpose cleaning spray
- T25 Torx bit
- T30 Torx bit
- Ratchet wrench
- U-joint socket extension
- Slotted screwdriver
- Funnel
- Hose clamp pliers
- Fluid drain pan
- Paper towels
- Fender cover

[Buy tools](#)

Replacement: engine thermostat – FORD Transit Mk6 Tourneo. AUTODOC experts recommend:

- All the work should be carried out with the engine cooled down and ignition switched off.

REPLACEMENT: ENGINE THERMOSTAT – FORD TRANSIT MK6 TOURNEO. TAKE THE FOLLOWING STEPS:

1 Open the bonnet.

2 Use a fender protection cover to avoid damaging the paintwork and plastic parts of the car.

3 Unscrew the coolant reservoir cap.



4 Lift the vehicle using a vehicle lift or place it over an inspection pit.

5 Prepare a fluid drain pan.



6 Unscrew the coolant drain plug. Use a slotted screwdriver.




7 Drain the coolant.




Replacement: engine thermostat – FORD Transit Mk6 Tourneo. AUTODOC recommends:

- Wait until the coolant has completely flowed out of the drain hole.

8 Screw in the coolant drain plug. Use a slotted screwdriver.




- 9 Loosen the coolant hose clamp. Use hose clamp pliers.




- 10 Detach the coolant hose and plug it with a paper towel.




- 11 Clean the fasteners of the thermostat housing cover. Use a wire brush. Use an all-purpose cleaning spray.



- 12 Unscrew the fasteners of the thermostat housing cover. Use a T25 Torx bit. Use a U-joint socket extension. Use a ratchet wrench.




13 Remove the fastening bolts.



14 Remove the thermostat housing cover.



15 Remove the thermostat.



16 Clean the mounting seat of the thermostat housing cover. Use an all-purpose cleaning spray.



17 Install a new thermostat.




18 Install the thermostat housing cover.




19 Install the fastening bolts.



20 Tighten the fasteners of the thermostat housing cover. Use a T30 Torx bit. Use a U-joint socket extension. Use a torque wrench. Tightening torque: 10 N·m.




21 Remove the towel from the coolant hose and reattach it. Use hose clamp pliers.



22

Remove the coolant reservoir cap.




23

Insert the funnel.



24

Pour coolant into the reservoir.



Warning!

- Only use the coolant recommended by the manufacturer.
- The coolant level should be at the MAX mark on the reservoir.
- Wait until the air goes out of the system.

25 Put the coolant reservoir cap back on and tighten it.



26 Run the engine for a few minutes. This should be done in order to remove residual air from the cooling system and to check that the components are operating correctly and there are no leaks.

27 Shut off the engine and let it cool down.

28 Top up the coolant to the MAX mark without exceeding it.

29 Remove the fender cover.


30 Close the bonnet.

WELL DONE! 

VIEW MORE TUTORIALS

AUTODOC – TOP QUALITY AND AFFORDABLE CAR PARTS ONLINE

AUTODOC MOBILE APP: GREAT DEALS AND CONVENIENT SHOPPING



+ AUTODOC

GET IT ON
Google Play

Download on the
App Store

Download

A GREAT SELECTION OF SPARE PARTS FOR YOUR CAR

ENGINE THERMOSTAT: A WIDE SELECTION

DISCLAIMER:

The document contains only general recommendations that may be useful for you when you perform repair or replacement work. AUTODOC shall not be liable for any loss, injury, damage of property occurring in the repair or replacement process due to incorrect use or misinterpretation of the provided information.

AUTODOC shall not be liable for any possible mistakes and uncertainties in this guide. The information provided is for information purposes only and cannot replace advice from specialists.

AUTODOC shall not be liable for incorrect or hazardous usage of equipment, tools and car parts. AUTODOC strongly recommends to be careful and observe the safety rules when performing repair or replacement works. Remember: usage of low quality auto parts does not guarantee you the appropriate level of road safety.

© Copyright 2024 – All the contents of this website, in particular texts, photographs and graphics, are protected by copyright. All rights, including reproduction, publication, editing and translation rights, are reserved by AUTODOC SE.