



How to change rear anti
roll bar links on
**MERCEDES-BENZ C-
Class Coupe (CL203)** –
replacement guide

SIMILAR VIDEO TUTORIAL



This video shows the replacement procedure of a similar car part on another vehicle

Important!

This replacement procedure can be used for:


MERCEDES-BENZ C-Class Coupe (CL203) C 180 (203.735), MERCEDES-BENZ C-Class Coupe (CL203) C 200 Kompressor (203.745), MERCEDES-BENZ C-Class Coupe (CL203) C 220 CDI (203.706), MERCEDES-BENZ C-Class Coupe (CL203) C 230 Kompressor (203.747), MERCEDES-BENZ C-Class Coupe (CL203) C 180 Kompressor (203.746), MERCEDES-BENZ C-Class Coupe (CL203) C 200 Kompressor (203.742), MERCEDES-BENZ C-Class Coupe (CL203) C 230 Kompressor (203.740), MERCEDES-BENZ C-Class Coupe (CL203) C 32 AMG Kompressor (203.765), MERCEDES-BENZ C-Class Coupe (CL203) C 30 CDI AMG (203.718), MERCEDES-BENZ C-Class Coupe (CL203) C 320 (203.764), MERCEDES-BENZ C-Class Coupe (CL203) C 200 CGI Kompressor (203.743), MERCEDES-BENZ C-Class Coupe (CL203) C 200 CDI (203.707), MERCEDES-BENZ C-Class Coupe (CL203) C 220 CDI (203.708), MERCEDES-BENZ C-Class Coupe (CL203) C 350 (203.756), MERCEDES-BENZ C-Class Coupe (CL203) C 230 (203.752), (+ 3)

The steps may slightly vary depending on the car design.

Please note that this tutorial was created based on the replacement procedure for this car part on a car with a similar design.

This tutorial was created based on the replacement procedure for a similar car part on: MERCEDES-BENZ C-Class Saloon (W203) C 240 (203.061)

REPLACEMENT: ANTI ROLL BAR LINKS – MERCEDES-BENZ C-CLASS COUPE (CL203). TOOLS YOU NEED:



- Wire brush
- WD-40 spray
- Brake cleaner
- Copper grease
- Torque wrench
- Combination spanner #11
- Combination spanner #16
- Drive socket # E14
- Drive socket # 16
- Wheel impact socket #17
- Ratchet wrench
- Hydraulic transmission jack
- Wheel chock

Buy tools

Replacement: anti roll bar links – MERCEDES-BENZ C-Class Coupe (CL203).
Tip from AUTODOC experts:

- Replace the stabiliser links on MERCEDES-BENZ C-Class Coupe (CL203) in pairs.
- The replacement procedure is identical for both stabiliser links on the same axle.
- All work should be done with the engine stopped.

REPLACEMENT: ANTI ROLL BAR LINKS – MERCEDES-BENZ C-CLASS COUPE (CL203). USE THE FOLLOWING PROCEDURE:

1 Secure the wheels with chocks.

2 Loosen the wheel mounting bolts. Use wheel impact socket #17.



3 Raise the rear of the car and secure on supports.

4 Unscrew the wheel bolts.



AUTODOC recommends:

- Important! Hold the wheel while unscrewing the fastening bolts. MERCEDES-BENZ C-Class Coupe (CL203)

5

Remove the wheel.




6

Clean the stabiliser link fasteners. Use a wire brush. Use WD-40 spray.




7


Unscrew the fastener connecting the stabilizer link to the stabilizer bar. Use a combination spanner #11. Use a drive socket #16. Use a ratchet wrench.



- 8** Unscrew the fasteners connecting the stabilizer link to the steering knuckle. Use a drive socket #E14. Use a ratchet wrench.




- 9** Remove the stabilizer rod.



Replacement: anti roll bar links – MERCEDES-BENZ C-Class Coupe (CL203).
Professionals recommend:

- Examine stabiliser bushes. Replace them if needed.

- 10** Clean the mounting seats of the stabiliser link. Use a wire brush. Use WD-40 spray.




11

Install a new rod, tighten the fasteners. Use a combination spanner #16. Use a drive socket #E14. Use a ratchet wrench.




12

Support the rear control arm. Use a hydraulic transmission jack.



13

Tighten the fasteners connecting the stabilizer link to the steering knuckle. Use a drive socket #E14. Use a torque wrench. Tighten it to 40 Nm torque.



14

Tighten the fastener connecting the stabilizer link to the stabilizer bar. Use a combination spanner #11. Use a drive socket #16. Use a torque wrench. Tighten it to 40 Nm torque.




15 Remove the support from under the rear control arm.



AUTODOC recommends:

- Replacement: anti roll bar links – MERCEDES-BENZ C-Class Coupe (CL203). Lower the transmission jack smoothly, without jerks, to avoid damaging components and mechanisms.

16 Treat all joints of the stabiliser link. Use copper grease.



17 Treat the surface where the brake disc contacts the wheel rim. Use copper grease.



18

Clean the brake disk surface. Use a brake cleaner.



Replacement: anti roll bar links – MERCEDES-BENZ C-Class Coupe (CL203).

Tip:

- After applying the spray, wait a few minutes.

19

Install the wheel.



AUTODOC recommends:

- Warning! To avoid injury, hold the wheel while screwing in the fastening bolts on the car. MERCEDES-BENZ C-Class Coupe (CL203)

20


Screw in the wheel bolts. Use wheel impact socket #17.



- 21** Lower the car and working in a cross order, tighten the wheel bolts. Use wheel impact socket #17. Use a torque wrench. Tighten it to 110 nm torque.



- 22** Remove the jacks and chocks.



WELL DONE! 

VIEW MORE TUTORIALS

AUTODOC – TOP QUALITY AND AFFORDABLE CAR PARTS ONLINE

AUTODOC MOBILE APP: GREAT DEALS AND CONVENIENT SHOPPING



+ AUTODOC

GET IT ON
Google Play

 Download on the
App Store

Download

A GREAT SELECTION OF SPARE PARTS FOR YOUR CAR

ANTI ROLL BAR LINKS: A WIDE SELECTION

DISCLAIMER:

The document contains only general recommendations that may be useful for you when you perform repair or replacement work. AUTODOC shall not be liable for any loss, injury, damage of property occurring in the repair or replacement process due to incorrect use or misinterpretation of the provided information.

AUTODOC shall not be liable for any possible mistakes and uncertainties in this guide. The information provided is for information purposes only and cannot replace advice from specialists.

AUTODOC shall not be liable for incorrect or hazardous usage of equipment, tools and car parts. AUTODOC strongly recommends to be careful and observe the safety rules when performing repair or replacement works. Remember: usage of low quality auto parts does not guarantee you the appropriate level of road safety.

© Copyright 2022 – All the contents of this website, in particular texts, photographs and graphics, are protected by copyright. All rights, including reproduction, publication, editing and translation rights, are reserved by AUTODOC GmbH.