



How to change front anti  
roll bar links on  
**MERCEDES-BENZ CLC**  
**(CL203)** – replacement  
guide

### SIMILAR VIDEO TUTORIAL



This video shows the replacement procedure of a similar car part on another vehicle

#### **Important!**


This replacement procedure can be used for:

MERCEDES-BENZ CLC (CL203) CLC 180 Kompressor (203.746), MERCEDES-BENZ CLC (CL203) CLC 200 Kompressor (203.741), MERCEDES-BENZ CLC (CL203) CLC 230 (203.752), MERCEDES-BENZ CLC (CL203) CLC 350 (203.756), MERCEDES-BENZ CLC (CL203) CLC 200 CDI (203.707), MERCEDES-BENZ CLC (CL203) CLC 220 CDI (203.708), MERCEDES-BENZ CLC (CL203) CLC 250, MERCEDES-BENZ CLC (CL203) CLC 160 (203.731)

The steps may slightly vary depending on the car design.

This tutorial was created based on the replacement procedure for a similar car part on: MERCEDES-BENZ C-Class Saloon (W203) C 240 (203.061)

REPLACEMENT: ANTI ROLL BAR LINKS – MERCEDES-BENZ CLC (CL203). TOOLS YOU MIGHT NEED:



- Wire brush
- WD-40 spray
- Brake cleaner
- Copper grease
- Torque wrench
- Combination spanner #7
- Combination spanner #17
- Drive socket # 16
- Drive socket # 17
- Wheel impact socket #17
- Ratchet wrench
- Wheel chock

**Buy tools**


Replacement: anti roll bar links – MERCEDES-BENZ CLC (CL203). AUTODOC recommends:

- Replace the stabiliser links on MERCEDES-BENZ CLC (CL203) in pairs.
- The replacement procedure is identical for both stabiliser links on the same axle.
- Warning! Shut down the engine before starting any work – MERCEDES-BENZ CLC (CL203).

**CARRY OUT REPLACEMENT IN THE FOLLOWING ORDER:**

**1** Secure the wheels with chocks.

**2** Loosen the wheel mounting bolts. Use wheel impact socket #17.



**3** Raise the front of the car and secure on supports.

**4** Unscrew the wheel bolts.



Replacement: anti roll bar links – MERCEDES-BENZ CLC (CL203). Tip:

- To avoid injury, hold up the wheel when unscrewing the bolts.


**5** Remove the wheel.



**6** Clean the stabiliser link fasteners. Use a wire brush. Use WD-40 spray.




**7** Unscrew the fastener connecting the stabilizer link to the shock strut. Use a drive socket #16. Use a ratchet wrench.



- 8 Unscrew the fastener connecting the stabilizer link to the stabilizer bar. Use a drive socket #16. Use a ratchet wrench.



- 9 Remove the stabilizer rod.




Replacement: anti roll bar links – MERCEDES-BENZ CLC (CL203). Tip from AUTODOC:

- Examine stabiliser bushes. Replace them if needed.

- 10 Clean the mounting seats of the stabiliser link. Use a wire brush. Use WD-40 spray.




- 11** Install a new rod, tighten the fasteners. Use a combination spanner #17. Use a combination spanner #7. Use a drive socket #17. Use a ratchet wrench.




- 12** Tighten the fastener connecting the stabilizer link to the shock strut. Use a drive socket #17. Use a torque wrench. Tighten it to 60 Nm torque.



- 13** Tighten the fastener connecting the stabilizer link to the stabilizer bar. Use a drive socket #17. Use a torque wrench. Tighten it to 60 Nm torque.



- 14** Treat all joints of the stabiliser link. Use copper grease.





**15**

Treat the surface where the brake disc contacts the wheel rim. Use copper grease.



**16**

Clean the brake disk surface. Use a brake cleaner.



**AUTODOC recommends:**

- Replacement: anti roll bar links – MERCEDES-BENZ CLC (CL203). After applying the spray, wait a few minutes.

**17**

Install the wheel.



**AUTODOC recommends:**

- Warning! To avoid injury, hold the wheel while screwing in the fastening bolts on the car. MERCEDES-BENZ CLC (CL203)



**18** Screw in the wheel bolts. Use wheel impact socket #17.



**19** Lower the car and working in a cross order, tighten the wheel bolts. Use wheel impact socket #17. Use a torque wrench. Tighten it to 110 nm torque.



**20** Remove the jacks and chocks.



**WELL DONE!** 

**VIEW MORE TUTORIALS**

# AUTODOC – TOP QUALITY AND AFFORDABLE CAR PARTS ONLINE

**AUTODOC MOBILE APP: GREAT DEALS AND CONVENIENT SHOPPING**



**+ AUTODOC**

GET IT ON  
**Google Play**

Download on the  
**App Store**

**Download**

**A GREAT SELECTION OF SPARE PARTS FOR YOUR CAR**

**ANTI ROLL BAR LINKS: A WIDE SELECTION**

## **DISCLAIMER:**

The document contains only general recommendations that may be useful for you when you perform repair or replacement work. AUTODOC shall not be liable for any loss, injury, damage of property occurring in the repair or replacement process due to incorrect use or misinterpretation of the provided information.

AUTODOC shall not be liable for any possible mistakes and uncertainties in this guide. The information provided is for information purposes only and cannot replace advice from specialists.

AUTODOC shall not be liable for incorrect or hazardous usage of equipment, tools and car parts. AUTODOC strongly recommends to be careful and observe the safety rules when performing repair or replacement works. Remember: usage of low quality auto parts does not guarantee you the appropriate level of road safety.

© Copyright 2022 – All the contents of this website, in particular texts, photographs and graphics, are protected by copyright. All rights, including reproduction, publication, editing and translation rights, are reserved by AUTODOC GmbH.