



How to change rear
windshield wipers on
MERCEDES-BENZ VITO
Bus (W639) –
replacement guide

SIMILAR VIDEO TUTORIAL



This video shows the replacement procedure of a similar car part on another vehicle

Important!

This replacement procedure can be used for:

MERCEDES-BENZ VITO Bus (W639) 119 (639.701, 639.703, 639.705), MERCEDES-BENZ VITO Bus (W639) 111 CDI (639.701, 639.703, 639.705), MERCEDES-BENZ VITO Bus (W639) 115 CDI (639.701, 639.703, 639.705), MERCEDES-BENZ VITO Bus (W639) 122 (639.701, 639.703, 639.705), MERCEDES-BENZ VITO Bus (W639) 109 CDI (639.701), MERCEDES-BENZ VITO Bus (W639) 123 (639.701), MERCEDES-BENZ VITO Bus (W639) 109 CDI (639.701, 639.703), MERCEDES-BENZ VITO Bus (W639) 109 CDI 4x4 (639.701), MERCEDES-BENZ VITO Bus (W639) 126 (639.701, 639.703, 639.705), MERCEDES-BENZ VITO Bus (W639) 111 CDI 4x4 (639.701, 639.703, 639.705), MERCEDES-BENZ VITO Bus (W639) 115 CDI 4x4 (639.701, 639.705), MERCEDES-BENZ VITO Bus (W639) 120 CDI (639.701, 639.703, 639.705), MERCEDES-BENZ VITO Bus (W639) 123 (639.701, 639.703, 639.705)

The steps may slightly vary depending on the car design.

This tutorial was created based on the replacement procedure for a similar car part on: MERCEDES-BENZ A-Class (W168) A 160 (168.033, 168.133)

Replacement: windshield wipers – MERCEDES-BENZ VITO Bus (W639).
AUTODOC recommends:

- All work should be done with the engine stopped.

REPLACEMENT: WINDSHIELD WIPERS – MERCEDES-BENZ VITO BUS (W639). RECOMMENDED SEQUENCE OF STEPS:

1 Prepare the new windscreen wipers.



2 Pull the wiper arm away from the glass surface until it stops.



3 Turn the wiper blade by ninety degrees.



4

Press the clip.



5

Remove the blade from the wiper arm.




Replacement: windshield wipers – MERCEDES-BENZ VITO Bus (W639).
AUTODOC experts recommend:

- When replacing the wiper blade, take caution to prevent the spring-loaded wiper arm from hitting the glass.

6

Install the new wiper blade and carefully press the wiper arm down to the glass.



Replacement: windshield wipers – MERCEDES-BENZ VITO Bus (W639). Tip from AUTODOC:

- Don't touch the wiper blade at the working rubber edge to prevent damage to the graphite coating.
- Ensure that the blade rubber strip fits tightly to the glass along the entire length.


7

Switch on the ignition.



8

After installation check the wipers performance.



WELL DONE! 

[VIEW MORE TUTORIALS](#)

AUTODOC – TOP QUALITY AND AFFORDABLE CAR PARTS ONLINE

AUTODOC MOBILE APP: GREAT DEALS AND CONVENIENT SHOPPING



+ AUTODOC

GET IT ON
 **Google Play**

 **Download on the App Store**

Download

A GREAT SELECTION OF SPARE PARTS FOR YOUR CAR

WINDSHIELD WIPERS: A WIDE SELECTION

DISCLAIMER:

The document contains only general recommendations that may be useful for you when you perform repair or replacement work. AUTODOC shall not be liable for any loss, injury, damage of property occurring in the repair or replacement process due to incorrect use or misinterpretation of the provided information.

AUTODOC shall not be liable for any possible mistakes and uncertainties in this guide. The information provided is for information purposes only and cannot replace advice from specialists.

AUTODOC shall not be liable for incorrect or hazardous usage of equipment, tools and car parts. AUTODOC strongly recommends to be careful and observe the safety rules when performing repair or replacement works. Remember: usage of low quality auto parts does not guarantee you the appropriate level of road safety.

© Copyright 2023 – All the contents of this website, in particular texts, photographs and graphics, are protected by copyright. All rights, including reproduction, publication, editing and translation rights, are reserved by AUTODOC SE.