




How to change rear anti  
roll bar links on **Ford**  
**Mondeo Mk3 saloon** –  
replacement guide

## VIDEO TUTORIAL



### Important!

This replacement procedure can be used for:

FORD MONDEO III Saloon (B4Y) 1.8 16V, FORD MONDEO III Saloon (B4Y) 2.5 V6 24V, FORD MONDEO III Saloon (B4Y) 2.0 16V DI / TDDi / TDCi, FORD MONDEO III Saloon (B4Y) 2.0 16V TDDi / TDCi, FORD MONDEO III (B5Y) 1.8 16V, FORD MONDEO III (B5Y) 2.0 16V, FORD MONDEO III (B5Y) 2.5 V6 24V, FORD MONDEO III (B5Y) 2.0 16V DI / TDDi / TDCi, FORD MONDEO III (B5Y) 2.0 16V TDDi / TDCi, FORD MONDEO III (B5Y) 2.0 TDCi, FORD MONDEO III Saloon (B4Y) 2.0 TDCi, FORD MONDEO III (B5Y) ST220, FORD MONDEO III Saloon (B4Y) ST220, FORD MONDEO III (B5Y) 1.8 SCi, FORD MONDEO III Saloon (B4Y) 1.8 SCi, (+ 4)

The steps may slightly vary depending on the car design.

REPLACEMENT: ANTI ROLL BAR LINKS – FORD  
MONDEO MK3 SALOON. PROFESSIONALS  
RECOMMEND:



- Wire brush
- WD-40 spray
- Brake cleaner
- Copper grease
- Torque wrench
- Combination spanner #16
- Combination spanner #17
- Combination spanner #19
- Drive socket # 17
- HEX bit No.H6
- Wheel impact socket #19
- Ratchet wrench
- Wheel chock

**BUY TOOLS**

**AUTODOC recommends:**

- Replace the stabiliser links on Ford Mondeo Mk3 saloon in pairs.
- The replacement procedure is identical for both stabiliser links on the same axle.
- Please note: all work on the car – Ford Mondeo Mk3 saloon – should be done with the engine switched off.


**CARRY OUT REPLACEMENT IN THE FOLLOWING ORDER:**

**1** Secure the wheels with chocks.

**2** Loosen the wheel mounting bolts. Use wheel impact socket #19.



**3** Raise the rear of the car and secure on supports.



4

Unscrew the wheel bolts.




**AUTODOC recommends:**

- Important! Hold the wheel while unscrewing the fastening bolts. Ford Mondeo Mk3 saloon

5

Remove the wheel.



6

Clean the stabiliser link fasteners. Use a wire brush. Use WD-40 spray.




7


Unscrew the fastener connecting the stabilizer link to the shock strut. Use a drive socket #17. Use a ratchet wrench.



- 8** Unscrew the fastener connecting the stabilizer link to the stabilizer bar. Use a combination spanner #16. Use a combination spanner #17.




- 9** Remove the stabiliser link.




Replacement: anti roll bar links – Ford Mondeo Mk3 saloon. Tip from AUTODOC experts:

- Examine stabiliser bushes. Replace them if needed.

- 10** Clean the mounting seats of the stabiliser link. Use a wire brush. Use WD-40 spray.




**11** Install a new rod, tighten the fasteners. Use a combination spanner #19. Use HEX No.H6.




**12** Tighten the fastener connecting the stabilizer link to the shock strut. Use a combination spanner #19. Use a drive socket #19. Use HEX No.H6. Use a torque wrench. Tighten it to 48 Nm torque.



**13** Tighten the fastener connecting the stabilizer link to the stabilizer bar. Use a combination spanner #19. Use a drive socket #19. Use HEX No.H6. Use a torque wrench. Tighten it to 48 Nm torque.



**14** Treat all joints of the stabiliser link. Use copper grease.




**15** Clean the wheel rim mounting seat. Use a wire brush.

**16** Treat the surface where the brake disc contacts the wheel rim. Use copper grease.




**17** Clean the brake disk surface. Use a brake cleaner.



**AUTODOC recommends:**

- Replacement: anti roll bar links – Ford Mondeo Mk3 saloon. After applying the spray, wait a few minutes.

**18** Install the wheel.




**AUTODOC recommends:**

- Warning! To avoid injury, hold the wheel while screwing in the fastening bolts on the car. Ford Mondeo Mk3 saloon




**19**

Screw in the wheel bolts. Use wheel impact socket #19.




**20**

Lower the car and working in a cross order, tighten the wheel bolts. Use wheel impact socket #19. Use a torque wrench. Tighten it to 90 Nm torque.



**21**

Remove the jacks and chocks.



**WELL DONE!** 

**VIEW MORE TUTORIALS**

# AUTODOC – TOP QUALITY AND AFFORDABLE CAR PARTS ONLINE

**AUTODOC MOBILE APP: GREAT DEALS AND CONVENIENT SHOPPING**



**+ AUTODOC**

GET IT ON  **Google Play**

 **Download on the App Store**

**Download**

**A GREAT SELECTION OF SPARE PARTS FOR YOUR CAR**

**BUY SPARE PARTS FOR FORD**

**ANTI ROLL BAR LINKS: A WIDE SELECTION**

**CHOOSE CAR PARTS FOR FORD MONDEO MK3 SALOON**

**ANTI ROLL BAR LINKS FOR FORD: BUY NOW**

**ANTI ROLL BAR LINKS FOR FORD MONDEO MK3 SALOON:  
THE BEST DEALS & OFFERS**

### **DISCLAIMER:**

The document contains only general recommendations that may be useful for you when you perform repair or replacement work. AUTODOC shall not be liable for any loss, injury, damage of property occurring in the repair or replacement process due to incorrect use or misinterpretation of the provided information.

AUTODOC shall not be liable for any possible mistakes and uncertainties in this guide. The information provided is for information purposes only and cannot replace advice from specialists.

AUTODOC shall not be liable for incorrect or hazardous usage of equipment, tools and car parts. AUTODOC strongly recommends to be careful and observe the safety rules when performing repair or replacement works. Remember: usage of low quality auto parts does not guarantee you the appropriate level of road safety.

© Copyright 2022 – All the contents of this website, in particular texts, photographs and graphics, are protected by copyright. All rights, including reproduction, publication, editing and translation rights, are reserved by AUTODOC GmbH.