



How to change rear
shock absorbers on

PEUGEOT 206+

**Hatchback (2L, 2M) –
replacement guide**

SIMILAR VIDEO TUTORIAL



This video shows the replacement procedure of a similar car part on another vehicle

Important!


This replacement procedure can be used for:

PEUGEOT 206+ Hatchback (2L, 2M) 1.4 i, PEUGEOT 206+ Hatchback (2L, 2M) 1.1, PEUGEOT 206+ Hatchback (2L, 2M) 1.4 HDi eco 70, PEUGEOT 206+ Hatchback (2L, 2M) 1.1 LPG

The steps may slightly vary depending on the car design.

This tutorial was created based on the replacement procedure for a similar car part on: PEUGEOT 206 Hatchback (2A/C) 1.6

REPLACEMENT: SHOCK ABSORBERS – PEUGEOT 206+ HATCHBACK (2L, 2M). LIST OF THE TOOLS YOU'LL NEED:



- Wire brush
- WD-40 spray
- Brake cleaner
- Copper grease
- Combination spanner #19
- Combination spanner #21
- Drive socket # 19
- Drive socket # 21
- Wheel impact socket #19
- Ratchet wrench
- Torque wrench
- Tap wrench
- Hydraulic transmission jack
- Wheel chock


Buy tools

Replacement: shock absorbers – PEUGEOT 206+ Hatchback (2L, 2M).
Professionals recommend:

- Both shock absorbers of the rear suspension should be replaced simultaneously.
- The replacement procedure is identical for the left and right shock absorbers of the rear suspension.
- All work should be done with the engine stopped.

REPLACEMENT: SHOCK ABSORBERS – PEUGEOT 206+ HATCHBACK (2L, 2M). RECOMMENDED SEQUENCE OF STEPS:

1 Secure the wheels with chocks.



2 Loosen the wheel mounting bolts. Use wheel impact socket #19.



3 Raise the rear of the car and secure on supports.


4 Unscrew the wheel bolts.




AUTODOC recommends:

- Important! Hold the wheel while unscrewing the fastening bolts. PEUGEOT 206+ Hatchback (2L, 2M)


5 Remove the wheel.



6 Clean the shock absorber fasteners. Use a wire brush. Use WD-40 spray.



7 Unscrew the upper fastener of the shock absorber. Use a combination spanner #19. Use a drive socket #19. Use a ratchet wrench.



8 Remove the fastening bolt.


9 Unscrew the lower fastener of the shock absorber. Use a drive socket #21. Use a tap wrench.



Replacement: shock absorbers – PEUGEOT 206+ Hatchback (2L, 2M).
AUTODOC recommends:


- To avoid injuries, hold the shock absorber when undoing the fastening bolts.

10 Support the rear suspension beam. Use a hydraulic transmission jack.



11 Remove the fastening bolt.

12 Remove the shock absorber.




Replacement: shock absorbers – PEUGEOT 206+ Hatchback (2L, 2M). Tip from AUTODOC experts:

- Before installing a new shock absorber you should pump it manually 3-5 times.

13

Place the shock absorber in the wheel arch and secure it.



AUTODOC recommends:

- Important! Hold the shock absorber while screwing in the fastening bolts. PEUGEOT 206+ Hatchback (2L, 2M)

14

Install the fastening bolts.




15

Screw in the lower fastener of the shock absorber. Use a combination spanner #21. Use a drive socket #21. Use a ratchet wrench.



- 16** Screw the upper fastener of the shock absorber. Use a combination spanner #19. Use a drive socket #19. Use a ratchet wrench.



- 17** Raise the hydraulic transmission jack by 10-15 cm.



- 18** Tighten the top shock absorber fastening. Use a combination spanner #19. Use a drive socket #19. Use a torque wrench. Tighten it to 70 Nm torque.



- 19** Tighten the lower fastener of the shock absorber. Use a combination spanner #21. Use a drive socket #21. Use a torque wrench. Tighten it to 150 Nm torque.



20

Remove the mounting from under the rear axle beam.




AUTODOC recommends:

- Replacement: shock absorbers – PEUGEOT 206+ Hatchback (2L, 2M). Lower the transmission jack smoothly, without jerks, to avoid damaging components and mechanisms.


21

Treat the shock absorber fasteners. Use copper grease.




22

Treat the surface where the brake disc contacts the wheel rim. Use copper grease.



23

Clean the brake disk surface. Use a brake cleaner.



Replacement: shock absorbers – PEUGEOT 206+ Hatchback (2L, 2M).
 AUTODOC experts recommend:

- After applying the spray, wait a few minutes.

24

Install the wheel.




AUTODOC recommends:

- Warning! To avoid injury, hold the wheel while screwing in the fastening bolts on the car. PEUGEOT 206+ Hatchback (2L, 2M)

25

Screw in the wheel bolts. Use wheel impact socket #19.



26

Lower the car and working in a cross order, tighten the wheel bolts. Use a torque wrench. Tighten it to 100 Nm torque.



27

Remove the jacks and chocks.



WELL DONE! 

VIEW MORE TUTORIALS

AUTODOC – TOP QUALITY AND AFFORDABLE CAR PARTS ONLINE

AUTODOC MOBILE APP: GREAT DEALS AND CONVENIENT SHOPPING



+ AUTODOC

GET IT ON
Google Play

 Download on the
App Store

Download

A GREAT SELECTION OF SPARE PARTS FOR YOUR CAR

SHOCK ABSORBERS: A WIDE SELECTION

DISCLAIMER:

The document contains only general recommendations that may be useful for you when you perform repair or replacement work. AUTODOC shall not be liable for any loss, injury, damage of property occurring in the repair or replacement process due to incorrect use or misinterpretation of the provided information.

AUTODOC shall not be liable for any possible mistakes and uncertainties in this guide. The information provided is for information purposes only and cannot replace advice from specialists.

AUTODOC shall not be liable for incorrect or hazardous usage of equipment, tools and car parts. AUTODOC strongly recommends to be careful and observe the safety rules when performing repair or replacement works. Remember: usage of low quality auto parts does not guarantee you the appropriate level of road safety.

© Copyright 2022 – All the contents of this website, in particular texts, photographs and graphics, are protected by copyright. All rights, including reproduction, publication, editing and translation rights, are reserved by AUTODOC GmbH.