



How to change front
brake pads on **PEUGEOT**
406 Coupe –
replacement guide

SIMILAR VIDEO TUTORIAL



This video shows the replacement procedure of a similar car part on another vehicle

Important!

This replacement procedure can be used for:

PEUGEOT 406 Coupe 2.0 16V, PEUGEOT 406 Coupe 2.2 HDI, PEUGEOT 406 Coupe 2.2

The steps may slightly vary depending on the car design.

This tutorial was created based on the replacement procedure for a similar car part on: PEUGEOT 406 Saloon 2.2

**REPLACEMENT: BRAKE PADS – PEUGEOT 406 COUPE.
TOOLS YOU NEED:**



- Wire brush
- WD-40 spray
- Brake cleaner
- Anti-squeal paste
- Copper grease
- High-temperature ceramic grease
- Combination spanner #13
- Combination spanner #17
- Wheel impact socket #19
- Ratchet wrench
- Torque wrench
- Brake caliper wind back tool
- Crow bar
- Wheel chock

Buy tools

Replacement: brake pads – PEUGEOT 406 Coupe. AUTODOC recommends:

- Perform the replacement of brake pads in complete set for each axis. This provides effective braking.
- The replacement procedure is identical for all brake pads on the same axle.
- All work should be done with the engine stopped.


REPLACEMENT: BRAKE PADS – PEUGEOT 406 COUPE. TAKE THE FOLLOWING STEPS:

1 Open the bonnet. Unscrew the brake fluid reservoir cap.

2 Secure the wheels with chocks.




3 Loosen the wheel mounting bolts. Use wheel impact socket #19.



4 Raise the front of the car and secure on supports.


5 Unscrew the wheel bolts.



AUTODOC recommends:


- Warning! To avoid injury, hold the wheel while unscrewing the fastening bolts.
PEUGEOT 406 Coupe

6 Remove the wheel.




7 Clean the brake caliper fasteners. Use a wire brush. Use WD-40 spray.

8 Unscrew the brake caliper fasteners. Use a combination spanner #13. Use a combination spanner #17.



9 Remove the fastening bolts (2 pieces).

10 Disconnect the brake pad wear sensor plug.




11 Disconnect the brake pad wear sensor wire.

12 Spread the brake pads. Use a crowbar.



13 Remove the brake caliper. Use a crowbar.




Replacement: brake pads – PEUGEOT 406 Coupe. Professionals recommend:

- Tie the caliper to the suspension or to the body with a wire without disconnecting from the brake hose to prevent depressurization of the brake system.
- Make sure that the brake caliper is not hanging on the brake hose.
- Don't press the brake pedal after the brake caliper has been removed. As a result, the piston can fall out from the brake cylinder, and brake fluid leakage and depressurization of the system may occur.
- Check the brake caliper bracket, brake caliper guide pins and boots. Clean them. Replace, if necessary.

14


Remove the brake pads. Use a crowbar.



Replacement: brake pads – PEUGEOT 406 Coupe. AUTODOC recommends:

- Measure the brake disc thickness. Upon reaching the wear limit the part must be replaced.

15 Clean the brake caliper bracket from dirt and dust. Use a wire brush. Use a brake cleaner.




16 Treat the brake pads in the area where their surface comes into contact with the brake caliper bracket. Use anti-squeal paste.



Replacement: brake pads – PEUGEOT 406 Coupe. Professionals recommend:

- Make sure the disc surface is clean before installing the pads.

17 Install new brake pads.



Replacement: brake pads – PEUGEOT 406 Coupe. Tip:

- Make sure the pads are installed with linings facing the disc.


18 Treat the brake caliper piston. Use a brake cleaner.



19 Press in the brake caliper piston. Use brake caliper wind back tool.



20 Install the brake caliper and fix it.




21 Install the fastening bolts (2 pieces).

22 Tighten the brake caliper fasteners. Use a combination spanner #13. Use a combination spanner #17. Use a torque wrench. Tighten it to 30 Nm torque.



23 Connect the brake pad wear sensor wire.


24 Connect the brake pad wear sensor plug.



25 Treat the surface where the brake disc contacts the wheel rim. Use high-temperature ceramic grease.



26 Clean the brake disk surface. Use a brake cleaner.



AUTODOC recommends:

- Replacement: brake pads – PEUGEOT 406 Coupe. After applying the spray, wait a few minutes.

27 Install the wheel.



AUTODOC recommends:

- Warning! To avoid injury, hold the wheel while screwing in the fastening bolts on the car. PEUGEOT 406 Coupe


28

Screw in the wheel bolts. Use wheel impact socket #19.



29

Lower the car and working in a cross order, tighten the wheel bolts. Use wheel impact socket #19. Use a torque wrench. Tighten it to 90 nm torque.



30

Remove the jacks and chocks.



Replacement: brake pads – PEUGEOT 406 Coupe. AUTODOC experts recommend:

- Check the brake fluid level in the expansion tank and refill if necessary.

31 Tighten the brake fluid reservoir cap. Close the hood.

Replacement: brake pads – PEUGEOT 406 Coupe. Tip from AUTODOC:

- Without starting the engine, press the brake pedal several times until you feel significant resistance.

WELL DONE! 

[VIEW MORE TUTORIALS](#)

AUTODOC – TOP QUALITY AND AFFORDABLE CAR PARTS ONLINE

AUTODOC MOBILE APP: GREAT DEALS AND CONVENIENT SHOPPING



+ AUTODOC

GET IT ON
Google Play

Download on the
App Store

Download

A GREAT SELECTION OF SPARE PARTS FOR YOUR CAR

BRAKE PADS: A WIDE SELECTION

DISCLAIMER:

The document contains only general recommendations that may be useful for you when you perform repair or replacement work. AUTODOC shall not be liable for any loss, injury, damage of property occurring in the repair or replacement process due to incorrect use or misinterpretation of the provided information.

AUTODOC shall not be liable for any possible mistakes and uncertainties in this guide. The information provided is for information purposes only and cannot replace advice from specialists.

AUTODOC shall not be liable for incorrect or hazardous usage of equipment, tools and car parts. AUTODOC strongly recommends to be careful and observe the safety rules when performing repair or replacement works. Remember: usage of low quality auto parts does not guarantee you the appropriate level of road safety.

© Copyright 2023 – All the contents of this website, in particular texts, photographs and graphics, are protected by copyright. All rights, including reproduction, publication, editing and translation rights, are reserved by AUTODOC SE.