



How to change rear
brake pads on **PEUGEOT**
406 Coupe –
replacement guide

SIMILAR VIDEO TUTORIAL



This video shows the replacement procedure of a similar car part on another vehicle

Important!

This replacement procedure can be used for:

PEUGEOT 406 Coupe 3.0 V6 24V, PEUGEOT 406 Coupe 3.0 V6, PEUGEOT 406 Coupe 2.0 16V, PEUGEOT 406 Coupe 2.2 HDI, PEUGEOT 406 Coupe 2.2, PEUGEOT 406 Coupe 3.0 24V

The steps may slightly vary depending on the car design.

This tutorial was created based on the replacement procedure for a similar car part on: PEUGEOT 406 Saloon 2.2

REPLACEMENT: BRAKE PADS – PEUGEOT 406 COUPE.
LIST OF THE TOOLS YOU'LL NEED:



- Wire brush
- WD-40 spray
- Brake cleaner
- Anti-squeal paste
- Anti-squeal paste
- Wheel impact socket #19
- Torque wrench
- Round-nose pliers
- Hammer
- Pin punch
- Crow bar
- Wheel chock

Buy tools

Replacement: brake pads – PEUGEOT 406 Coupe. AUTODOC recommends:

- Replace the brake disks on the car PEUGEOT 406 Coupe in complete set for each axis. Regardless of the state of components. This will ensure even braking.
- Perform the replacement of brake pads in complete set for each axis. This provides effective braking.
- The replacement procedure is identical for all brake pads on the same axle.
- Please note: all work on the car – PEUGEOT 406 Coupe – should be done with the engine switched off.

CARRY OUT REPLACEMENT IN THE FOLLOWING ORDER:

1 Open the bonnet. Unscrew the brake fluid reservoir cap.

2 Secure the wheels with chocks.



3 Loosen the wheel mounting bolts. Use wheel impact socket #19.



4 Raise the rear of the car and secure on supports.


5 Unscrew the wheel bolts.




AUTODOC recommends:

- Warning! To avoid injury, hold the wheel while unscrewing the fastening bolts.
PEUGEOT 406 Coupe

6 Remove the wheel.



7 Remove the retaining springs of the brake pads. Use round-nose pliers.




8 Remove the brake pads retaining clips. Use a pin punch. Use a hammer.



9 Spread the brake pads. Use a crowbar.


10 Remove the brake pads. Use a crowbar. Use a pin punch.



Replacement: brake pads – PEUGEOT 406 Coupe. Professionals recommend:

- Measure the brake disc thickness. Upon reaching the wear limit the part must be replaced.

11 Treat the brake pads in the area where their surface comes into contact with the brake caliper bracket. Use anti-squeal paste.




Replacement: brake pads – PEUGEOT 406 Coupe. Tip from AUTODOC:

- Make sure the disc surface is clean before installing the pads.

12

Install new brake pads.




Replacement: brake pads – PEUGEOT 406 Coupe. AUTODOC recommends:


- Make sure the pads are installed with linings facing the disc.

13


Install the brake pads retaining clips. Use a crowbar. Use a hammer.



14 Install the retaining springs of the brake pads. Use round-nose pliers.



15 Treat the surface where the brake disc contacts the wheel rim. Use high-temperature ceramic grease.




16 Clean the brake disk surface. Use a brake cleaner.



AUTODOC recommends:

- Replacement: brake pads – PEUGEOT 406 Coupe. After applying the spray, wait a few minutes.

17 Install the wheel.



AUTODOC recommends:

- Warning! To avoid injury, hold the wheel while screwing in the fastening bolts on the car. PEUGEOT 406 Coupe

18

Screw in the wheel bolts. Use wheel impact socket #19.



19

Lower the car and working in a cross order, tighten the wheel bolts. Use wheel impact socket #19. Use a torque wrench. Tighten it to 90 nm torque.



20

Remove the jacks and chocks.



Replacement: brake pads – PEUGEOT 406 Coupe. Tip from AUTODOC experts:

- Check the brake fluid level in the expansion tank and refill if necessary.

21 Tighten the brake fluid reservoir cap. Close the hood.

Replacement: brake pads – PEUGEOT 406 Coupe. Tip from AUTODOC:

- Without starting the engine, press the brake pedal several times until you feel significant resistance.

WELL DONE! 

[VIEW MORE TUTORIALS](#)

AUTODOC – TOP QUALITY AND AFFORDABLE CAR PARTS ONLINE

AUTODOC MOBILE APP: GREAT DEALS AND CONVENIENT SHOPPING



+ AUTODOC

GET IT ON
Google Play

Download on the
App Store

Download

A GREAT SELECTION OF SPARE PARTS FOR YOUR CAR

BRAKE PADS: A WIDE SELECTION

DISCLAIMER:

The document contains only general recommendations that may be useful for you when you perform repair or replacement work. AUTODOC shall not be liable for any loss, injury, damage of property occurring in the repair or replacement process due to incorrect use or misinterpretation of the provided information.

AUTODOC shall not be liable for any possible mistakes and uncertainties in this guide. The information provided is for information purposes only and cannot replace advice from specialists.

AUTODOC shall not be liable for incorrect or hazardous usage of equipment, tools and car parts. AUTODOC strongly recommends to be careful and observe the safety rules when performing repair or replacement works. Remember: usage of low quality auto parts does not guarantee you the appropriate level of road safety.

© Copyright 2023 – All the contents of this website, in particular texts, photographs and graphics, are protected by copyright. All rights, including reproduction, publication, editing and translation rights, are reserved by AUTODOC SE.