



How to change front anti
roll bar links on **Hyundai**
Santa Fe CM –
replacement guide

VIDEO TUTORIAL



Important!

This replacement procedure can be used for:

HYUNDAI SANTA FÉ II (CM) 3.3, HYUNDAI ix55 3.0 V6 CRDi 4WD, HYUNDAI SANTA FÉ II (CM) 3.5 4x4, HYUNDAI SANTA FÉ II (CM) 2.0 CRDi, HYUNDAI SANTA FÉ II (CM) 2.4, HYUNDAI SANTA FÉ II (CM) 2.0 CRDi 4x4, HYUNDAI SANTA FÉ II (CM) 2.7 4x4, HYUNDAI SANTA FÉ II (CM) 2.7, HYUNDAI SANTA FÉ II (CM) 2.2 CRDi, HYUNDAI SANTA FÉ II (CM) 2.2 CRDi 4x4, HYUNDAI SANTA FÉ II (CM) 2.7 V6 GLS, HYUNDAI SANTA FÉ II (CM) 2.7 V6 GLS 4x4, HYUNDAI SANTA FÉ II (CM) 2.2 CRDi GLS, HYUNDAI SANTA FÉ II (CM) 2.2 CRDi GLS 4x4, HYUNDAI SANTA FÉ II (CM) 3.3 Dynamic 4x4, (+ 8)

The steps may slightly vary depending on the car design.

REPLACEMENT: ANTI ROLL BAR LINKS – HYUNDAI SANTA FE CM. LIST OF THE TOOLS YOU'LL NEED:



- Wire brush
- WD-40 spray
- Brake cleaner
- Copper grease
- Torque wrench
- Combination spanner #17
- Drive socket # 17
- Wheel impact socket #21
- Ratchet wrench
- Wheel chock

BUY TOOLS

AUTODOC recommends:

- Replace the stabiliser links on Hyundai Santa Fe CM in pairs.
- The replacement procedure is identical for both stabiliser links on the same axle.
- Please note: all work on the car – Hyundai Santa Fe CM – should be done with the engine switched off.

CARRY OUT REPLACEMENT IN THE FOLLOWING ORDER:


1 Secure the wheels with chocks.



2 Loosen the wheel mounting bolts. Use wheel impact socket #21.



3 Raise the front of the car and secure on supports.



4

Unscrew the wheel bolts.



AUTODOC recommends:

- Warning! To avoid injury, hold the wheel while unscrewing the fastening bolts.
Hyundai Santa Fe CM

5

Remove the wheel.




6


Clean the stabiliser link fasteners. Use a wire brush. Use WD-40 spray.

7


Unscrew the fastener connecting the stabilizer link to the shock strut. Use a drive socket #17. Use a ratchet wrench.



- 8** Unscrew the fastener connecting the stabilizer link to the stabilizer bar. Use a drive socket #17. Use a ratchet wrench.



- 9** Remove the stabiliser link.




Replacement: anti roll bar links – Hyundai Santa Fe CM. Professionals recommend:

- Examine stabiliser bushes. Replace them if needed.


- 10** Clean the mounting seats of the stabiliser link. Use a wire brush. Use WD-40 spray.




11 Install a new rod, tighten the fasteners.




12 Tighten the fastener connecting the stabilizer link to the stabilizer bar. Use a combination spanner #17. Use a drive socket #17. Use a torque wrench. Tighten it to 65 Nm torque.




13 Tighten the fastener connecting the stabilizer link to the shock strut. Use a combination spanner #17. Use a drive socket #17. Use a torque wrench. Tighten it to 65 Nm torque.




14 Treat all joints of the stabiliser link. Use copper grease.



15 Treat the surface where the brake disc contacts the wheel rim. Use copper grease.



16 Clean the brake disk surface. Use a brake cleaner.



AUTODOC recommends:

- Replacement: anti roll bar links – Hyundai Santa Fe CM. After applying the spray, wait a few minutes.

17 Install the wheel.




AUTODOC recommends:

- Warning! To avoid injury, hold the wheel while screwing in the fastening bolts on the car. Hyundai Santa Fe CM


18 Screw in the wheel bolts. Use wheel impact socket #21.



19 Lower the car and working in a cross order, tighten the wheel bolts. Use wheel impact socket #21. Use a torque wrench. Tighten it to 108 Nm torque.



20 Remove the jacks and chocks.



WELL DONE! 

VIEW MORE TUTORIALS

AUTODOC – TOP QUALITY AND AFFORDABLE CAR PARTS ONLINE

AUTODOC MOBILE APP: GREAT DEALS AND CONVENIENT SHOPPING



+ AUTODOC

GET IT ON
Google Play

Download on the
App Store

Download

A GREAT SELECTION OF SPARE PARTS FOR YOUR CAR

BUY SPARE PARTS FOR HYUNDAI

ANTI ROLL BAR LINKS: A WIDE SELECTION

CHOOSE CAR PARTS FOR HYUNDAI SANTA FE CM

ANTI ROLL BAR LINKS FOR HYUNDAI: BUY NOW

**ANTI ROLL BAR LINKS FOR HYUNDAI SANTA FE CM: THE
BEST DEALS & OFFERS**

DISCLAIMER:

The document contains only general recommendations that may be useful for you when you perform repair or replacement work. AUTODOC shall not be liable for any loss, injury, damage of property occurring in the repair or replacement process due to incorrect use or misinterpretation of the provided information.

AUTODOC shall not be liable for any possible mistakes and uncertainties in this guide. The information provided is for information purposes only and cannot replace advice from specialists.

AUTODOC shall not be liable for incorrect or hazardous usage of equipment, tools and car parts. AUTODOC strongly recommends to be careful and observe the safety rules when performing repair or replacement works. Remember: usage of low quality auto parts does not guarantee you the appropriate level of road safety.

© Copyright 2023 – All the contents of this website, in particular texts, photographs and graphics, are protected by copyright. All rights, including reproduction, publication, editing and translation rights, are reserved by AUTODOC GmbH.