+ AUTODOC CLUB

How to change serpentine belt on **SEAT Alhambra (710, 711)** – replacement guide







SIMILAR VIDEO TUTORIAL



This video shows the replacement procedure of a similar car part on another vehicle

(i) Important!

This replacement procedure can be used for: SEAT Alhambra (710, 711) 2.0 TDI, SEAT Alhambra (710, 711) 2.0 TDI 4Drive

The steps may slightly vary depending on the car design.

This tutorial was created based on the replacement procedure for a similar car part on: VW Passat Saloon (362) 2.0 TDI

CLUB.AUTODOC.CO.UK 1–7









REPLACEMENT: SERPENTINE BELT – SEAT ALHAMBRA (710, 711). LIST OF THE TOOLS YOU'LL NEED:



- Torque wrench
- Combination spanner #16
- Wheel impact socket #17
- Fender cover
- Wheel chock

Buy tools

CLUB.AUTODOC.CO.UK 2-7







Replacement: serpentine belt – SEAT Alhambra (710, 711). AUTODOC experts recommend:

• All work should be done with the engine stopped.

CARRY OUT REPLACEMENT IN THE FOLLOWING ORDER:

- Open the bonnet.
- Use a fender protection cover to prevent damaging paintwork and plastic parts of the car.
- Secure the wheels with chocks.
- Loosen the wheel mounting bolts. Use wheel impact socket #17.
- Lift the car using a jack or place it over an inspection pit.
- 6 Unscrew the wheel bolts.

AUTODOC recommends:

- Warning! To avoid injury, hold the wheel while unscrewing the fastening bolts.
 SEAT Alhambra (710, 711)
- 7 Remove the wheel.

CLUB.AUTODOC.CO.UK 3-7







Pull aside the V-ribbed belt tensioner pulley. Use a combination spanner #16.



Remove the V-ribbed belt.



Return the tensioner pulley to its initial position. Use a combination spanner #16.

Replacement: serpentine belt – SEAT Alhambra (710, 711). Professionals recommend:

- Check the condition of the tensioner pulley and idler pulley. Replace them if necessary.
- Pull aside the V-ribbed belt tensioner pulley. Use a combination spanner #16.
- 12 Install the V-ribbed belt.



CLUB.AUTODOC.CO.UK 4–7





Replacement: serpentine belt – SEAT Alhambra (710, 711). Tip:

- Make sure that the V-ribbed belt fits all pulleys snugly.
- Return the tensioner pulley to its initial position. Use a combination spanner #16.



14 Install the wheel.

AUTODOC recommends:

- To avoid injury, hold up the wheel when screwing in the fastening bolts.
- Screw in the wheel bolts. Use wheel impact socket #17.
- Lower the car and working in a cross order, tighten the wheel bolts. Use wheel impact socket #17. Use a torque wrench. Tighten it to 120 Nm torque.
- Remove the jacks and chocks.
- Run the engine for a few minutes. This is necessary in order to make sure that the component operates properly.
- Shut off the engine.
- Remove the fender protection cover.

CLUB.AUTODOC.CO.UK 5-7







21

Close the hood.



VIEW MORE TUTORIALS

CLUB.AUTODOC.CO.UK 6-7





AUTODOC — TOP QUALITY AND AFFORDABLE CAR PARTS ONLINE



A GREAT SELECTION OF SPARE PARTS FOR YOUR CAR

SERPENTINE BELT: A WIDE SELECTION

(i) DISCLAIMER:

The document contains only general recommendations that may be useful for you when you perform repair or replacement work. AUTODOC shall not be liable for any loss, injury, damage of property occurring in the repair or replacement process due to incorrect use or misinterpretation of the provided information.

AUTODOC shall not be liable for any possible mistakes and uncertainties in this guide. The information provided is for information purposes only and cannot replace advice from specialists.

AUTODOC shall not be liable for incorrect or hazardous usage of equipment, tools and car parts. AUTODOC strongly recommends to be careful and observe the safety rules when performing repair or replacement works. Remember: usage of low quality auto parts does not guarantee you the appropriate level of road safety.

© Copyright 2022 – All the contents of this website, in particular texts, photographs and graphics, are protected by copyright. All rights, including reproduction, publication, editing and translation rights, are reserved by AUTODOC GmbH.

CLUB.AUTODOC.CO.UK 7-7