



How to change front
strut mount on **SKODA**
Citigo – replacement
guide

SIMILAR VIDEO TUTORIAL



This video shows the replacement procedure of a similar car part on another vehicle


i Important!

This replacement procedure can be used for:
SKODA Citigo 1.0, SKODA Citigo 1.0 CNG

The steps may slightly vary depending on the car design.

This tutorial was created based on the replacement procedure for a similar car part on: SKODA Octavia I Hatchback (1U2) 1.6

REPLACEMENT: STRUT MOUNT – SKODA CITIGO.
TOOLS YOU'LL NEED:



- Wire brush
- WD-40 spray
- Brake cleaner
- Copper grease
- High-temperature ceramic grease
- Torque wrench
- HEX bit No.H6.
- Combination spanner #18
- Drive socket # 16
- Drive socket # 18
- Drive socket # 20.6
- Wheel impact socket #17
- Ratchet wrench
- Hydraulic strut spring compressor
- Hammer
- Rubber mallet
- Hydraulic transmission jack
- Fender cover
- Wheel chock

[Buy tools](#)


Replacement: strut mount – SKODA Citigo. Tip from AUTODOC experts:

- The replacement procedure is identical for the mounts of the left and right shock struts of the front suspension.
- All mounts of the front shock struts should be replaced simultaneously.
- All work should be done with the engine stopped.

REPLACEMENT: STRUT MOUNT – SKODA CITIGO. TAKE THE FOLLOWING STEPS:


1

Secure the wheels with chocks.



2

Loosen the wheel mounting bolts. Use wheel impact socket #17.



3

Raise the front of the car and secure on supports.

4 Unscrew the wheel bolts.



AUTODOC recommends:


- Warning! To avoid injury, hold the wheel while unscrewing the fastening bolts.
SKODA Citigo

5 Remove the wheel.



6 Clean the stabiliser link fasteners. Use a wire brush. Use WD-40 spray.

7 Unscrew the fastener connecting the stabilizer link to the control arm. Use a drive socket #16. Use a ratchet wrench.



8 Remove the fastening bolt.

9 Remove the stabilizer rod.


10

Clean the lower fastener connecting the suspension strut to the steering knuckle. Use a wire brush. Use WD-40 spray.




11

Unscrew the lower fastener connecting the shock strut to the steering knuckle. Use a combination spanner #18. Use a drive socket #18. Use a ratchet wrench.



12

Remove the fastening bolt.




13

Disconnect the ABS sensor wiring.



14

Disconnect the steering knuckle from the shock absorber strut. Use a rubber mallet.



15

Lower the car.

16

Open the bonnet.

17

Use a fender protection cover to prevent damaging paintwork and plastic parts of the car.

18

Clean the upper fastener of the suspension strut mount. Use a wire brush. Use WD-40 spray.



19


Loosen the upper fastener of the shock strut mount. Use a drive socket #20.6. Use a ratchet wrench.



AUTODOC recommends:

- SKODA Citigo – To avoid injury, hold the suspension strut while unscrewing the fastening bolts.

20 Remove the suspension strut.



21 Set the shock absorber strut on the spring compressor tool.



Replacement: strut mount – SKODA Citigo. AUTODOC recommends:


- Note that when using a spring compressor, spring coils need to be securely gripped, compressing the spring on the opposite sides.
- Ensure the correct position of the spring in the retainer.
- Make sure that the spring coils tightly entered the lock handles.

22 Compress the spring.




23

Treat the shock strut rod. Use a wire brush. Use WD-40 spray.




24

Remove the strut piston rod nut. Use a drive socket #20.6. Use a ratchet wrench.




25

Remove the top strut mount.



26

Install a new top shock strut mount.



- 27** Tighten the shock strut piston rod nut. Use a drive socket #20.6. Use HEX No.H6. Use a torque wrench. Tighten it to 60 Nm torque.




Replacement: strut mount – SKODA Citigo. Tip:

- Check to make sure the spring is positioned correctly. Avoid its misalignment.


- 28** Decompress the spring.

- 29** Treat the shock strut rod. Use copper grease.

- 30** Remove the assembled shock strut.



- 31** Install the shock strut into the wheel arch.



AUTODOC recommends:

- Warning! To avoid injury, hold the wheel while screwing in the fastening bolts on the car. SKODA Citigo

32 Tighten the upper fastener of the shock absorber strut mount. Use a drive socket #20.6. Use a torque wrench. Tighten it to 60 Nm torque.



33 Treat the upper fastener of the suspension strut mount. Use copper grease.

34 Remove the fender protection cover.


35 Close the hood.

36 Raise the front of the car and secure on supports.

37 Treat the mounting seats of the shock strut. Use a wire brush. Use WD-40 spray.



38 Fix the shock absorber strut on the steering knuckle.



39

Prop up the steering knuckle. Use a hydraulic transmission jack.



40

Install the fastening bolt. Use a hammer.

41


Remove the support from under the steering knuckle.

AUTODOC recommends:

- SKODA Citigo – Do not lower the transmission jack sharply to avoid damaging components and mechanisms of the car.

42

Tighten the lower fasteners of the suspension strut. Use a combination spanner #18. Use a drive socket #18. Use a torque wrench. Tighten it to 60 Nm torque.+90°




43

Install the transverse stabilizer link.

44

Install the rod fastening to the stabilizer and tighten it. Use a drive socket #16. Use a torque wrench. Tighten it to 15 Nm torque.+90°



45 Connect the ABS sensor wiring.



46 Treat the surface where the brake disc contacts the wheel rim. Use high-temperature ceramic grease.




47 Clean the brake disk surface. Use a brake cleaner.



AUTODOC recommends:

- Replacement: strut mount – SKODA Citigo. After applying the spray, wait a few minutes.

48 Install the wheel.



AUTODOC recommends:

- Important! Hold the wheel while screwing in the fastening bolts. SKODA Citigo


49

Screw in the wheel bolts. Use wheel impact socket #17.




50

Lower the car and working in a cross order, tighten the wheel bolts. Use wheel impact socket #17. Use a torque wrench. Tighten it to 120 Nm torque.



51

Remove the jacks and chocks.



WELL DONE! 

[VIEW MORE TUTORIALS](#)

AUTODOC – TOP QUALITY AND AFFORDABLE CAR PARTS ONLINE

AUTODOC MOBILE APP: GREAT DEALS AND CONVENIENT SHOPPING

AUTODOC

GET IT ON
Google Play

Download on the
App Store

Download

A GREAT SELECTION OF SPARE PARTS FOR YOUR CAR

STRUT MOUNT: A WIDE SELECTION

(i) DISCLAIMER:

The document contains only general recommendations that may be useful for you when you perform repair or replacement work. AUTODOC shall not be liable for any loss, injury, damage of property occurring in the repair or replacement process due to incorrect use or misinterpretation of the provided information.

AUTODOC shall not be liable for any possible mistakes and uncertainties in this guide. The information provided is for information purposes only and cannot replace advice from specialists.

AUTODOC shall not be liable for incorrect or hazardous usage of equipment, tools and car parts. AUTODOC strongly recommends to be careful and observe the safety rules when performing repair or replacement works. Remember: usage of low quality auto parts does not guarantee you the appropriate level of road safety.

© Copyright 2022 – All the contents of this website, in particular texts, photographs and graphics, are protected by copyright. All rights, including reproduction, publication, editing and translation rights, are reserved by AUTODOC GmbH.