



How to change rear
shock absorbers on
SKODA SUPERB (3T4) –
replacement guide

SIMILAR VIDEO TUTORIAL



This video shows the replacement procedure of a similar car part on another vehicle

i Important!

This replacement procedure can be used for:

SKODA SUPERB (3T4) 1.8 TSI, SKODA SUPERB (3T4) 1.8 TSI 4x4, SKODA SUPERB (3T4) 2.0 TSI, SKODA SUPERB (3T4) 1.6 TDI, SKODA SUPERB (3T4) 2.0 TDI 16V 4x4, SKODA SUPERB (3T4) 1.4 TSI, SKODA SUPERB (3T4) 1.9 TDI, SKODA SUPERB (3T4) 2.0 TDI, SKODA SUPERB (3T4) 3.6 FSI 4x4, SKODA SUPERB (3T4) 2.0 TDI 4x4, SKODA SUPERB (3T4) 2.0 TDI 16V

The steps may slightly vary depending on the car design.

This tutorial was created based on the replacement procedure for a similar car part on: SKODA Octavia II Combi (1Z5) 1.8 TSI

REPLACEMENT: SHOCK ABSORBERS – SKODA SUPERB (3T4). TOOLS YOU MIGHT NEED:



- Wire brush
- WD-40 spray
- Brake cleaner
- Copper grease
- Combination spanner #18
- Drive socket # 16
- Drive socket # 17
- Drive socket # 18
- Drive socket # 21
- Torx bit T25
- Wheel impact socket #17
- Ratchet wrench
- Torque wrench
- Tap wrench
- Shock absorber socket #DD6
- Shock absorber socket #DD8
- Vice
- Crow bar
- Hydraulic transmission jack
- Wheel chock

Buy tools

Replacement: shock absorbers – SKODA SUPERB (3T4). Tip:

- Both shock absorbers of the rear suspension should be replaced simultaneously.
- The replacement procedure is identical for the left and right shock absorbers of the rear suspension.
- All work should be done with the engine stopped.

REPLACEMENT: SHOCK ABSORBERS – SKODA SUPERB (3T4). USE THE FOLLOWING PROCEDURE:

1 Secure the wheels with chocks.




2 Loosen the wheel mounting bolts. Use wheel impact socket #17.



3 Raise the rear of the car and secure on supports.

4

Unscrew the wheel bolts.



Replacement: shock absorbers – SKODA SUPERB (3T4). Tip from AUTODOC:

- To avoid injury, hold up the wheel when unscrewing the bolts.


5

Remove the wheel.



6

Clean the fasteners of the locker. Use a wire brush. Use WD-40 spray.




7

Unscrew and remove the wheel arch cover fasteners. Use Torx T25. Use a ratchet wrench.




8

Clean the shock absorber fasteners. Use a wire brush. Use WD-40 spray.



9

Clean all joints of the arm. Use a wire brush. Use WD-40 spray.



10

Make a mark on the camber adjustment bolt.




- 11** Unscrew the arm fastening to the beam. Use a combination spanner #18. Use a drive socket #18. Use a ratchet wrench.




- 12** Clean all joints of the arm. Use a wire brush. Use WD-40 spray.




- 13** Unscrew the fastener connecting the control arm to the rear knuckle. Use a combination spanner #18 (2 pieces).



- 14** Support the arm. Use a hydraulic transmission jack.



15 Remove the fastening bolt. Use a combination spanner #18. Use a crowbar.




16 Remove the support from under the arm.




Replacement: shock absorbers – SKODA SUPERB (3T4). AUTODOC recommends:

- Lower the hydraulic transmission jack smoothly, without jerks, to avoid damaging assemblies and mechanisms.


17 Pull down the suspension control arm. Take out the spring.




18 Clean the shock absorber fasteners. Use a wire brush. Use WD-40 spray.




19 Unscrew the lower fastener of the shock absorber. Use a drive socket #21. Use a tap wrench.



20 Unscrew the upper fastener of the shock absorber. Use a drive socket #16. Use a ratchet wrench.




21 Remove the fastening bolts.



AUTODOC recommends:

- SKODA SUPERB (3T4) – To avoid injury, hold the shock absorber while unscrewing the fastening bolts.

22 Remove the shock absorber.



23 Grip the shock absorber in a vice.



24 Remove the protective cap of the shock absorber mount. Use a crowbar.



25 Clean the shock absorber rod fastener. Use a wire brush. Use WD-40 spray.



26 Remove the shock absorber piston rod fastening. Use a shock absorber socket DDN^o6. Use a drive socket #17. Use a ratchet wrench.




27 Remove the shock absorber mount, boot and bump stop.


AUTODOC recommends:

- Replacement: shock absorbers – SKODA SUPERB (3T4). Carefully inspect the mount, the boot, and the bump stop of the shock absorber. Replace if necessary.
- Before installing a new shock absorber you should pump it manually 3-5 times.


28 Install the mount, boot and bump stop onto a new shock absorber.



29 Tighten the shock absorber rod nut. Use a shock absorber socket DDN#8. Use a drive socket #16. Use a torque wrench. Tighten it to 25 nm torque.



30 Treat the shock absorber rod fastener. Use copper grease.



31 Install the protective cap of the shock absorber mount.



32 Release the vice and take out the shock absorber.

33 Clean the shock absorber mounting seats. Use a wire brush. Use WD-40 spray.



34 Place the shock absorber in the wheel arch and secure it.




AUTODOC recommends:

- Important! Hold the shock absorber while screwing in the fastening bolts. SKODA SUPERB (3T4)

35 Install the fastening bolt.



36 Screw the upper fastener of the shock absorber. Use a drive socket #16. Use a ratchet wrench.




37 Tighten the top shock absorber fastening. Use a drive socket #16. Use a torque wrench. Tighten it to 50 Nm torque.+45°




AUTODOC recommends:

- Important! Be sure to use new fasteners.


38 Treat the shock absorber fasteners. Use copper grease.



39 Install and tighten the wheel arch cover fasteners. Use Torx T25. Use a ratchet wrench.




40 Install the fastening bolt.




41 Screw in the lower fastener of the shock absorber. Use a drive socket #21. Use a ratchet wrench.




42 Clean the coil spring mounting seats. Use a wire brush. Use WD-40 spray.



43 Install the coil spring together with the rubber mounts into the mounting seats.




44 Clean the mounting seats and the thread of the suspension arm. Use a wire brush. Use WD-40 spray.




45 Support the arm. Use a hydraulic transmission jack. Use a crowbar.




46 Install the fastening bolt.



47 Adjust the position of the alignment bolt according to the mark.



48 Screw in the fastener connecting the control arm to the subframe. Use a drive socket #18. Use a ratchet wrench.



49 Remove the support from under the arm.




AUTODOC recommends:

- Replacement: shock absorbers – SKODA SUPERB (3T4). Lower the transmission jack smoothly, without jerks, to avoid damaging components and mechanisms.

50 Screw in the fastener connecting the control arm to the subframe. Use a combination spanner #18 (2 pieces).

51 Support the arm. Use a hydraulic transmission jack.



- 52** Tighten the lower fastener of the shock absorber. Use a drive socket #21. Use a torque wrench. Tighten it to 130 Nm torque.+90°



AUTODOC recommends:

- Important! Be sure to use new fasteners.

- 53** Screw in the fastener that connects the control arm to the rear knuckle. Use a combination spanner #18 (2 pieces).




- 54** Tighten the fastener connecting the suspension arm to the rear knuckle. Use a combination spanner #18. Use a drive socket #18. Use a torque wrench. Tighten it to 90 Nm torque.+90°



AUTODOC recommends:

- Important! Be sure to use new fasteners.

55 Tighten the arm fastening to the beam. Use a combination spanner #18. Use a drive socket #18. Use a torque wrench. Tighten it to 95 nm torque.




56 Remove the support from under the arm.



AUTODOC recommends:


- SKODA SUPERB (3T4) – Do not lower the transmission jack sharply to avoid damaging components and mechanisms of the car.

57 Treat the shock absorber fasteners. Treat all joints of the arm. Use copper grease.



58

Treat the surface where the brake disc contacts the wheel rim. Use copper grease.



59

Clean the brake disk surface. Use a brake cleaner.



Replacement: shock absorbers – SKODA SUPERB (3T4). Tip from AUTODOC experts:

- After applying the spray, wait a few minutes.

60

Install the wheel.




61

Screw in the wheel bolts. Use wheel impact socket #17.




62

Lower the car and working in a cross order, tighten the wheel bolts. Use wheel impact socket #17. Use a torque wrench. Tighten it to 120 Nm torque.

**63**

Remove the jacks and chocks.



WELL DONE! 

VIEW MORE TUTORIALS

AUTODOC – TOP QUALITY AND AFFORDABLE CAR PARTS ONLINE

AUTODOC MOBILE APP: GREAT DEALS AND CONVENIENT SHOPPING



+ AUTODOC

GET IT ON
Google Play

 Download on the
App Store

Download

A GREAT SELECTION OF SPARE PARTS FOR YOUR CAR

SHOCK ABSORBERS: A WIDE SELECTION

DISCLAIMER:

The document contains only general recommendations that may be useful for you when you perform repair or replacement work. AUTODOC shall not be liable for any loss, injury, damage of property occurring in the repair or replacement process due to incorrect use or misinterpretation of the provided information.

AUTODOC shall not be liable for any possible mistakes and uncertainties in this guide. The information provided is for information purposes only and cannot replace advice from specialists.

AUTODOC shall not be liable for incorrect or hazardous usage of equipment, tools and car parts. AUTODOC strongly recommends to be careful and observe the safety rules when performing repair or replacement works. Remember: usage of low quality auto parts does not guarantee you the appropriate level of road safety.

© Copyright 2023 – All the contents of this website, in particular texts, photographs and graphics, are protected by copyright. All rights, including reproduction, publication, editing and translation rights, are reserved by AUTODOC SE.