



How to change track rod
end on **VOLVO XC70**
Cross Country (295) –
replacement guide

SIMILAR VIDEO TUTORIAL



This video shows the replacement procedure of a similar car part on another vehicle

Important!

This replacement procedure can be used for:

VOLVO XC70 Cross Country (295) 2.4 T XC AWD, VOLVO XC70 Cross Country (295) 2.4 D5 XC AWD, VOLVO XC70 Cross Country (295) 2.5 T XC AWD, VOLVO XC70 Cross Country (295) 2.4 D5 AWD

The steps may slightly vary depending on the car design.

This tutorial was created based on the replacement procedure for a similar car part on: VOLVO XC90 I (275) 2.4 D5

**REPLACEMENT: TRACK ROD END – VOLVO XC70
CROSS COUNTRY (295). LIST OF THE TOOLS YOU'LL
NEED:**



- Wire brush
- WD-40 spray
- Brake cleaner
- Copper grease
- Combination spanner #13
- Combination spanner #19
- Combination spanner #21
- Wheel impact socket #19
- Ratchet wrench
- Torque wrench
- Adjustable wrench
- Vernier caliper
- Wheel chock

Buy tools

Replacement: track rod end – VOLVO XC70 Cross Country (295). AUTODOC experts recommend:

- Replace tie rod ends in pairs.
- The replacement procedure is identical for the right and left tie rod ends.
- Please note: all work on the car – VOLVO XC70 Cross Country (295) – should be done with the engine switched off.

CARRY OUT REPLACEMENT IN THE FOLLOWING ORDER:


1

Secure the wheels with chocks.



2

Loosen the wheel mounting bolts. Use wheel impact socket #19.



3

Raise the front of the car and secure on supports.

4

Unscrew the wheel bolts.



AUTODOC recommends:

- Warning! To avoid injury, hold the wheel while unscrewing the fastening bolts.
VOLVO XC70 Cross Country (295)


5

Remove the wheel.



6


When deinstalling, mark or measure the precise position of the ball joint on the track rod, or count the number of turns in order to prevent misalignment afterward. Use a vernier caliper.



7 Clean the fastener connecting the tie rod end to the steering knuckle. Use a wire brush. Use WD-40 spray.




8 Unscrew the end fastening nut to the steering knuckle. Use a combination spanner #19. Use an adjustable wrench.




9 Clean the lock nut that connects the tie rod to the tie rod end. Use a wire brush. Use WD-40 spray.


10 Loosen the lock nut securing the tie rod end to the tie rod. Use a combination spanner #21.




11 Disconnect the tie rod end from the steering knuckle.




12 Screw the end out of the tie rod. Use a combination spanner #13.



13 Clean the mounting seats of the tie rod end. Use a wire brush. Use WD-40 spray.



14 Screw on a new tie rod end.




Replacement: track rod end – VOLVO XC70 Cross Country (295).
Professionals recommend:

- While installing the steering rod end remember to make the same number of turns or to leave the same length of thread showing as per your measurements.

15 Connect the tie rod end to the steering knuckle.


- 16** Tighten the fastening nut connecting the tie rod end to the steering knuckle. Use an adjustable wrench. Use a combination spanner #19. Use a torque wrench. Tighten it to 50 Nm torque.+35°



AUTODOC recommends:

- Important! Be sure to use new fasteners.

- 17** Tighten the tie rod end locknut. Use a combination spanner #21. Use a torque wrench. Tighten it to 70 nm torque.



- 18** Treat all tie rod end connections. Use copper grease.



19

Treat the surface where the brake disc contacts the wheel rim. Use copper grease.



20

Clean the brake disk surface. Use a brake cleaner.



AUTODOC recommends:

- Replacement: track rod end – VOLVO XC70 Cross Country (295). After applying the spray, wait a few minutes.

21

Install the wheel.



AUTODOC recommends:

- Warning! To avoid injury, hold the wheel while screwing in the fastening bolts on the car. VOLVO XC70 Cross Country (295)

22 Screw in the wheel bolts. Use wheel impact socket #19.




23 Lower the car and working in a cross order, tighten the wheel bolts. Use wheel impact socket #19. Use a torque wrench. Tighten it to 140 nm torque.



Replacement: track rod end – VOLVO XC70 Cross Country (295).
Professionals recommend:

- Check and adjust wheel alignment if necessary.

24 Remove the jacks and chocks.



WELL DONE! 

VIEW MORE TUTORIALS

AUTODOC – TOP QUALITY AND AFFORDABLE CAR PARTS ONLINE

AUTODOC MOBILE APP: GREAT DEALS AND CONVENIENT SHOPPING



+ AUTODOC

GET IT ON
 **Google Play**

 **Download on the App Store**

Download

A GREAT SELECTION OF SPARE PARTS FOR YOUR CAR

TRACK ROD END: A WIDE SELECTION

DISCLAIMER:

The document contains only general recommendations that may be useful for you when you perform repair or replacement work. AUTODOC shall not be liable for any loss, injury, damage of property occurring in the repair or replacement process due to incorrect use or misinterpretation of the provided information.

AUTODOC shall not be liable for any possible mistakes and uncertainties in this guide. The information provided is for information purposes only and cannot replace advice from specialists.

AUTODOC shall not be liable for incorrect or hazardous usage of equipment, tools and car parts. AUTODOC strongly recommends to be careful and observe the safety rules when performing repair or replacement works. Remember: usage of low quality auto parts does not guarantee you the appropriate level of road safety.

© Copyright 2023 – All the contents of this website, in particular texts, photographs and graphics, are protected by copyright. All rights, including reproduction, publication, editing and translation rights, are reserved by AUTODOC SE.