+ AUTODOC CLUB

How to change rear coil springs on **VW PASSAT Variant (3B5)** –

replacement guide







SIMILAR VIDEO TUTORIAL



This video shows the replacement procedure of a similar car part on another vehicle

i Important!

This replacement procedure can be used for:

VW PASSAT Variant (3B5) 1.6, VW PASSAT Variant (3B5) 1.8, VW PASSAT Variant (3B5) 1.8 T, VW PASSAT Variant (3B5) 2.3 VR5, VW PASSAT Variant (3B5) 2.8 V6, VW PASSAT Variant (3B5) 1.9 TDI, VW PASSAT Variant (3B5) 2.5 TDI, VW PASSAT Variant (3B5) 2.0

The steps may slightly vary depending on the car design.

This tutorial was created based on the replacement procedure for a similar car part on: VW PASSAT Variant (3B6) 1.9 TDI


CLUB.AUTODOC.CO.UK 1–11







REPLACEMENT: COIL SPRINGS – VW PASSAT VARIANT (3B5). TOOLS YOU NEED:



- Wire brush
- WD-40 spray
- Brake cleaner
- Copper grease
- Drive socket # 16
- Combination spanner #16

- Wheel impact socket #17
- Ratchet wrench
- Torque wrench
- Hydraulic transmission jack
- Wheel chock

Buy tools

CLUB.AUTODOC.CO.UK 2-11







Replacement: coil springs – VW PASSAT Variant (3B5). AUTODOC recommends:

- Both shock absorbers of the rear suspension should be replaced simultaneously.
- The replacement procedure is identical for the left and right shock absorbers of the rear suspension.
- Please note: all work on the car VW PASSAT Variant (3B5) should be done
 with the engine switched off.

CARRY OUT REPLACEMENT IN THE FOLLOWING ORDER:

Secure the wheels with chocks.



Loosen the wheel mounting bolts. Use wheel impact socket #17.



Raise the rear of the car and secure on supports.

CLUB.AUTODOC.CO.UK 3-11







4 Unscrew the wheel bolts.



AUTODOC recommends:

• Important! Hold the wheel while unscrewing the fastening bolts. VW PASSAT Variant (3B5)

Remove the wheel.

6



Clean the shock absorber fasteners. Use a wire brush. Use WD-40 spray.



Support the rear suspension beam. Use a hydraulic transmission jack.



CLUB.AUTODOC.CO.UK 4-11







Unscrew the lower fastener of the shock absorber. Use a combination spanner #16. Use a drive socket #16. Use a ratchet wrench.



9 Remove the fastening bolt.

10



Remove the mounting from under the rear axle beam.



AUTODOC recommends:

• Replacement: coil springs – VW PASSAT Variant (3B5). Lower the transmission jack smoothly, without jerks, to avoid damaging components and mechanisms.

CLUB.AUTODOC.CO.UK 5-11







Support the rear suspension beam. Use a hydraulic transmission jack.



- Unscrew the lower fastener of the shock absorber. Use a combination spanner #16. Use a drive socket #16. Use a ratchet wrench.
 - 13 Remove the fastening bolt.
 - Remove the mounting from under the rear axle beam.



AUTODOC recommends:

- VW PASSAT Variant (3B5) Do not lower the transmission jack sharply to avoid damaging components and mechanisms of the car.
- Take out the spring.



CLUB.AUTODOC.CO.UK 6-11







Clean the coil spring mounting seats. Use a wire brush. Use WD-40 spray.



Install the coil spring together with the rubber mounts into the mounting seats.



Support the rear suspension beam. Use a hydraulic transmission jack.



19

Tighten the lower fastener of the shock absorber. Use a combination spanner #16. Use a drive socket #16. Use a torque wrench. Tighten it to 50 Nm torque.+90°



AUTODOC recommends:

• Important! Be sure to use new fasteners.

CLUB.AUTODOC.CO.UK 7-11







Remove the mounting from under the rear axle beam.

AUTODOC recommends:

- Replacement: coil springs VW PASSAT Variant (3B5). Lower the transmission jack smoothly, without jerks, to avoid damaging components and mechanisms.
- Support the rear suspension beam. Use a hydraulic transmission jack.
- Tighten the lower fastener of the shock absorber. Use a combination spanner #16. Use a drive socket #16. Use a torque wrench. Tighten it to 50 Nm torque.+90°

AUTODOC recommends:

- Important! Be sure to use new fasteners.
- Treat the shock absorber fasteners. Use copper grease.



Remove the mounting from under the rear axle beam.



CLUB.AUTODOC.CO.UK 8-11








AUTODOC recommends:

• VW PASSAT Variant (3B5) – Do not lower the transmission jack sharply to avoid damaging components and mechanisms of the car.





Clean the brake disk surface. Use a brake cleaner.



AUTODOC recommends:

 Replacement: coil springs – VW PASSAT Variant (3B5). After applying the spray, wait a few minutes.

27 Install the wheel.



CLUB.AUTODOC.CO.UK 9-11







AUTODOC recommends:

 Warning! To avoid injury, hold the wheel while screwing in the fastening bolts on the car. VW PASSAT Variant (3B5)

Screw in the wheel bolts. Use wheel impact socket #17.



Lower the car and working in a cross order, tighten the wheel bolts. Use a torque wrench. Tighten it to 120 nm torque.



Remove the jacks and chocks.

30






VIEW MORE TUTORIALS

CLUB.AUTODOC.CO.UK 10-11









A GREAT SELECTION OF SPARE PARTS FOR YOUR CAR

COIL SPRINGS: A WIDE SELECTION

① DISCLAIMER:

The document contains only general recommendations that may be useful for you when you perform repair or replacement work. AUTODOC shall not be liable for any loss, injury, damage of property occurring in the repair or replacement process due to incorrect use or misinterpretation of the provided information.

AUTODOC shall not be liable for any possible mistakes and uncertainties in this guide. The information provided is for information purposes only and cannot replace advice from specialists.

AUTODOC shall not be liable for incorrect or hazardous usage of equipment, tools and car parts. AUTODOC strongly recommends to be careful and observe the safety rules when performing repair or replacement works. Remember: usage of low quality auto parts does not guarantee you the appropriate level of road safety.

© Copyright 2023 – All the contents of this website, in particular texts, photographs and graphics, are protected by copyright. All rights, including reproduction, publication, editing and translation rights, are reserved by AUTODOC SE.

CLUB.AUTODOC.CO.UK 11-11