



How to change front  
brake pads on **VW POLO**  
**VIVO Hatchback** –  
replacement guide

## SIMILAR VIDEO TUTORIAL



This video shows the replacement procedure of a similar car part on another vehicle

### Important!

This replacement procedure can be used for:

VW POLO VIVO Hatchback 1.6 16V, VW POLO VIVO Hatchback 1.4

The steps may slightly vary depending on the car design.

This tutorial was created based on the replacement procedure for a similar car part on: VW Polo Saloon (602, 604, 612, 614) 1.6

REPLACEMENT: BRAKE PADS – VW POLO VIVO HATCHBACK. LIST OF THE TOOLS YOU'LL NEED:



- Wire brush
- Nylon cleaning brush
- WD-40 spray
- Brake cleaner
- Anti-squeal paste
- Copper grease
- Drive socket # 12
- Wheel impact socket #17
- Ratchet wrench
- Torque wrench
- Brake caliper wind back tool
- Crow bar
- Wheel chock


**Buy tools**

Replacement: brake pads – VW POLO VIVO Hatchback. AUTODOC recommends:


- Perform the replacement of brake pads in complete set for each axis. This provides effective braking.
- The replacement procedure is identical for all brake pads on the same axle.
- All work should be done with the engine stopped.

**REPLACEMENT: BRAKE PADS – VW POLO VIVO HATCHBACK. RECOMMENDED SEQUENCE OF STEPS:**


**1** Open the bonnet. Unscrew the brake fluid reservoir cap.



**2** Secure the wheels with chocks.



**3** Loosen the wheel mounting bolts. Use wheel impact socket #17.



**4** Raise the front of the car and secure on supports.

**5** Unscrew the wheel bolts.



Replacement: brake pads – VW POLO VIVO Hatchback. AUTODOC experts recommend:

- To avoid injury, hold up the wheel when unscrewing the bolts.

**6** Remove the wheel.



**7** Clean the brake caliper fasteners. Use a wire brush. Use WD-40 spray.



8

Unscrew the brake caliper fastening. Use a drive socket #12. Use a ratchet wrench.



9

Spread the brake pads. Use a crowbar.



10

Remove the brake caliper.



Replacement: brake pads – VW POLO VIVO Hatchback. Professionals recommend:

- Tie the caliper to the suspension or to the body with a wire without disconnecting from the brake hose to prevent depressurization of the brake system.
- Make sure that the brake caliper is not hanging on the brake hose.
- Don't press the brake pedal after the brake caliper has been removed. As a result, the piston can fall out from the brake cylinder, and brake fluid leakage and depressurization of the system may occur.
- Check the brake caliper bracket, brake caliper guide pins and boots. Clean them. Replace, if necessary.

11

Remove the brake pads.



Replacement: brake pads – VW POLO VIVO Hatchback. Tip from AUTODOC:

- Measure the brake disc thickness. Upon reaching the wear limit the part must be replaced.

12

Clean the brake caliper bracket from dirt and dust. Use a wire brush. Use a brake cleaner.



**AUTODOC recommends:**

- Replacement: brake pads – VW POLO VIVO Hatchback. After applying the spray, wait a few minutes.

13

Treat the brake caliper piston. Use a nylon cleaning brush. Use a brake cleaner.



**Replacement: brake pads – VW POLO VIVO Hatchback. Tip from AUTODOC experts:**

- After applying the spray, wait a few minutes.




**14**

Press in the brake caliper piston. Use brake caliper wind back tool.



**15**

Treat the brake pads in the area where their surface comes into contact with the brake caliper bracket. Use anti-squeal paste.




**Replacement: brake pads – VW POLO VIVO Hatchback. Tip:**

- Make sure the disc surface is clean before installing the pads.

**16**


Install new brake pads.




**Replacement: brake pads – VW POLO VIVO Hatchback. AUTODOC recommends:**

- Make sure the pads are installed with linings facing the disc.


**17** Install the brake caliper and fix it. Use a drive socket #12. Use a torque wrench. Tighten it to 30 Nm torque.



**18** Treat the surface where the brake disc contacts the wheel rim. Use copper grease.




**19** Clean the brake disk surface. Use a brake cleaner.



Replacement: brake pads – VW POLO VIVO Hatchback. AUTODOC experts recommend:

- After applying the spray, wait a few minutes.

**20** Install the wheel.



Replacement: brake pads – VW POLO VIVO Hatchback. Tip from AUTODOC:

- To avoid injury, hold up the wheel when screwing in the fastening bolts.

21

Screw in the wheel bolts. Use wheel impact socket #17.




22

Lower the car and working in a cross order, tighten the wheel bolts. Use wheel impact socket #17. Use a torque wrench. Tighten it to 120 Nm torque.



23


Remove the jacks and chocks.



**AUTODOC recommends:**

- Important! Replacement: brake pads – VW POLO VIVO Hatchback. Check the brake fluid level in the reservoir and top up if necessary.

**24** Tighten the brake fluid reservoir cap.



**AUTODOC recommends:**

- VW POLO VIVO Hatchback – Press the brake pedal several times with the engine shut down until you feel the resistance built up.

**25** Close the hood.

**Replacement: brake pads – VW POLO VIVO Hatchback. Professionals recommend:**

- Slow down smoothly for first 150-200 km after the brake pads replacement. Avoid unnecessary and sharp braking to a stop.

**WELL DONE!** 

**VIEW MORE TUTORIALS**

# AUTODOC – TOP QUALITY AND AFFORDABLE CAR PARTS ONLINE

**AUTODOC MOBILE APP: GREAT DEALS AND CONVENIENT SHOPPING**



**+ AUTODOC**

GET IT ON  
 **Google Play**

Download on the  
 **App Store**

**Download**

**A GREAT SELECTION OF SPARE PARTS FOR YOUR CAR**

**BRAKE PADS: A WIDE SELECTION**

## **DISCLAIMER:**

The document contains only general recommendations that may be useful for you when you perform repair or replacement work. AUTODOC shall not be liable for any loss, injury, damage of property occurring in the repair or replacement process due to incorrect use or misinterpretation of the provided information.

AUTODOC shall not be liable for any possible mistakes and uncertainties in this guide. The information provided is for information purposes only and cannot replace advice from specialists.

AUTODOC shall not be liable for incorrect or hazardous usage of equipment, tools and car parts. AUTODOC strongly recommends to be careful and observe the safety rules when performing repair or replacement works. Remember: usage of low quality auto parts does not guarantee you the appropriate level of road safety.

© Copyright 2023 – All the contents of this website, in particular texts, photographs and graphics, are protected by copyright. All rights, including reproduction, publication, editing and translation rights, are reserved by AUTODOC SE.