AUTODOC
Expert in auto parts!

How to replace a fuel filter on Audi 80 B4

Carry out replacement in the following order:

Ensure adequate ventilation of the workplace. Fuel vapors are poisonous.

1

Lift the car and set it on jack stands.

2.1



Loosen the fuel supply lines fastening to the fuel filter.

2.2

3.1



Disconnect the fuel supply lines from the fuel filter.

3.2



4.1



4.2

Unscrew the fuel filter bracket fastening bolts.

5.1

5.2

Remove the fuel filter

6.1

6.2

Install a new fuel filter.

6.3



7.1



Tighten the fuel filter bracket fastening bolts.

7.2



8.1

Connect the fuel supply lines to the fuel filter and tighten the fasteners.

8.2



8.3



8.4

We hope that this information have been useful for you!

Video tutorials

Watch our detailed video guides about your Audi 80 B4 repair on our youtube channel. Watch video guides.

AutoDoc online

Highest quality fuel filters for your car Audi 80 B4 are available on AutoDoc. Go to the website.

How to replace a fuel filter on Audi 80 B4

AUTODOC — TOP QUALITY AND AFFORDABLE CAR PARTS ONLINE

QUALITY AUTO PARTS

AUDI

FUEL FILTERS



AUDI 80 B4

FUEL FILTERS FOR AUDI

FUEL FILTERS FOR AUDI 80 B4

Disclaimer:

The document contains only general recommendations that may be useful for you when you perform repair or replacement works. AutoDoc shall not be liable for any loss, injury, damage of property, acquired in the repair or replacement process due to incorrect usage or misinterpretation of the provided information.

AutoDoc shall not be liable for any possible mistakes and uncertainties in this guide. The information provided is for informative purposes only and cannot replace advice from specialists.

AutoDoc shall not be liable for incorrect or hazardous usage of equipment, tools and car parts. AutoDoc strongly recommends to be careful and observe the safety rules when performing repair or replacement works. Remember: usage of low quality auto parts does not guarantee you the appropriate level of road safety.

AUTODOC IN SOCIAL MEDIA