


How to change fuel filter on **BMW E36** – replacement guide





VIDEO TUTORIAL




(i) Important!

This replacement procedure can be used for:

BMW 3 Saloon (E36) 316i 1.6, BMW 3 Saloon (E36) 318is 1.8, BMW 3 Coupe (E36) 318is 1.8, BMW 3 Saloon (E36) 320i 2.0, BMW 3 Coupe (E36) 320i 2.0, BMW 3 Saloon (E36) 325i 2.5, BMW 3 Coupe (E36) 325i 2.5, BMW 5 Saloon (E34) 530i 3.0 V8, BMW 5 Saloon (E34) 540i 4.0 V8, BMW 5 Touring (E34) 530i 3.0 V8, BMW 3 Convertible (E36) 325i 2.5, BMW 3 Coupe (E36) 316i 1.6, BMW 5 Touring (E34) 540i 4.0, BMW 3 Convertible (E36) 318i 1.8, (+ 64)

The steps may slightly vary depending on the car design.





Ø





Replacement: fuel filter – BMW E36. Tip from AUTODOC:

• Ensure adequate ventilation of the workplace. Fuel vapors are poisonous.

• All work should be done with the engine stopped.

REPLACEMENT: FUEL FILTER – BMW E36. TAKE THE FOLLOWING STEPS:



Open the fuel door.





Unscrew the fuel filler cap.





Secure the wheels with chocks.







Lift the car using a jack or place it over an inspection pit.



5

Unscrew the fasteners of the plastic car body protective cover. Use a drive socket #8. Use a drive socket #10. Use a ratchet wrench.



6

Remove the plastic car body protective cover.



7

Loosen the fastening clamps of the fuel filter pipes. Use a drive socket #7. Use a ratchet wrench.







Detach the tubes from the fuel filter.



9

Unscrew the fuel filter bracket. Use a drive socket #10. Use a ratchet wrench.



10

Prepare a container for fluids.



11

Clean the fuel lines. Use a nylon cleaning brush. Use all-purpose cleaning spray.








Disconnect the fuel supply lines from the fuel filter.



13

Remove the fuel filter.



Replacement: fuel filter – BMW E36. AUTODOC recommends:

• Be careful! Fuel may leak from the filter housing and hoses.




Install a new fuel filter.









• Take care to only use quality filters.



Connect the fuel lines to the new fuel filter.



16

Tighten the fastening clamps of the fuel filter pipes. Use a drive socket #7. Use a ratchet wrench.



17

Clean the fuel lines. Use all-purpose cleaning spray.







Screw in the fuel filter mounting bracket. Use a drive socket #10. Use a ratchet wrench.




19

Attach the pipe to the fuel filter.

20

Reinstall the plastic car body protective cover.



21

Screw in the fasteners of the plastic car body protective cover. Use a drive socket #8. Use a drive socket #10. Use a ratchet wrench.



22

Lower the car.







Remove the jacks and chocks.

24

Tighten the fuel filler cap.



25

Close the fuel door.



Replacement: fuel filter - BMW E36. AUTODOC experts recommend:

• Before starting off, switch the ignition on and off several times. This should be done to activate the fuel pump to make it pump fuel through the fuel system.

26

Run the engine for a few minutes. This is necessary in order to make sure that the component operates properly.










Shut off the engine.






VIEW MORE TUTORIALS





AUTODOC – TOP QUALITY AND AFFORDABLE CAR PARTS ONLINE



A GREAT SELECTION OF SPARE PARTS FOR YOUR CAR

BUY SPARE PARTS FOR BMW

FUEL FILTER: A WIDE SELECTION



CHOOSE CAR PARTS FOR BMW E36

FUEL FILTER FOR BMW: BUY NOW

FUEL FILTER FOR BMW E36: THE BEST DEALS & OFFERS

(i) **DISCLAIMER**:

The document contains only general recommendations that may be useful for you when you perform repair or replacement work. AUTODOC shall not be liable for any loss, injury, damage of property occurring in the repair or replacement process due to incorrect use or misinterpretation of the provided information.

AUTODOC shall not be liable for any possible mistakes and uncertainties in this guide. The information provided is for information purposes only and cannot replace advice from specialists.

AUTODOC shall not be liable for incorrect or hazardous usage of equipment, tools and car parts. AUTODOC strongly recommends to be careful and observe the safety rules when performing repair or replacement works. Remember: usage of low quality auto parts does not guarantee you the appropriate level of road safety.

© Copyright 2022 – All the contents of this website, in particular texts, photographs and graphics, are protected by copyright. All rights, including reproduction, publication, editing and translation rights, are reserved by AUTODOC GmbH.

(၀)