+ AUTODOC CLUB

How to change fuel filter on **Ford Mondeo BWY** – replacement guide







VIDEO TUTORIAL



(i) Important!

This replacement procedure can be used for:

FORD MONDEO III Saloon (B4Y) 1.8 16V, FORD MONDEO III Saloon (B4Y) 2.0 16V, FORD MONDEO III Saloon (B4Y) 2.5 V6 24V, FORD MONDEO III (B5Y) 1.8 16V, FORD MONDEO III Estate (BWY) 1.8 16V, FORD MONDEO III (B5Y) 2.0 16V, FORD MONDEO III Estate (BWY) 2.0 16V, FORD MONDEO III (B5Y) 2.5 V6 24V, FORD MONDEO III Estate (BWY) 2.5 V6 24V, FORD MONDEO III (B5Y) ST220, FORD MONDEO III Saloon (B4Y) ST220, FORD MONDEO III Estate (BWY) ST220, FORD MONDEO III (B5Y) 1.8 SCi, FORD MONDEO III Estate (BWY) 1.8 SCi, FORD MONDEO III Saloon (B4Y) 1.8 SCi, FORD MONDEO III Saloon (B4Y) 1.8 SCi, (+10)

The steps may slightly vary depending on the car design.


CLUB.AUTODOC.CO.UK 1–9







REPLACEMENT: FUEL FILTER – FORD MONDEO BWY. TOOLS YOU MIGHT NEED:



- Nylon cleaning brush
- All-purpose cleaning spray
- Drive socket #8
- Ratchet wrench
- Torque wrench

- Flat Screwdriver
- Round-nose pliers
- Fuel line pliers
- Fluid container

BUY TOOLS

CLUB.AUTODOC.CO.UK 2–9







Replacement: fuel filter - Ford Mondeo BWY. AUTODOC recommends:

- Ensure adequate ventilation of the workplace. Fuel vapors are poisonous.
- All work should be done with the engine stopped.

REPLACEMENT: FUEL FILTER – FORD MONDEO BWY. USE THE FOLLOWING PROCEDURE:

Lift the car using a jack or place it over an inspection pit.



Clean the fasteners of the fuel supply lines. Use a nylon cleaning brush. Use all-purpose cleaning spray.



3 Prepare a container for fluids.



CLUB.AUTODOC.CO.UK 3–9







Squeeze the clips and detach the fuel supply lines from the fuel filter housing. Use round-nose pliers. Use a flat screwdriver.



Replacement: fuel filter – Ford Mondeo BWY. Tip:

- Be careful! Fuel may leak from the filter housing and hoses.
- Unscrew the fuel filter bracket fixing bolts. Use a drive socket #8. Use a ratchet wrench.



6 Remove the fuel filter together with its bracket.



CLUB.AUTODOC.CO.UK 4–9







7 Unscrew the fuel filter bracket. Use a drive socket #8. Use a ratchet wrench.



Remove the fuel filter.



Install a new fuel filter.



AUTODOC recommends:

- Make sure that the fuel filter is positioned correctly. Consider the fuel flow direction mark.
- During installation, take care to prevent dust and dirt from getting into the fuel filter housing.
- Ford Mondeo BWY It's important to only use high-quality filters.

CLUB.AUTODOC.CO.UK 5–9







Screw in the fuel filter mounting bracket. Use a drive socket #8. Use a ratchet wrench.



Install the new fuel filter together with its bracket.



Screw the fixing bolts of the fuel filter bracket. Use a drive socket #8. Use a torque wrench. Tighten it to 9 nm torque.



Connect the fuel lines to the fuel filter and lock the fastening clips.



Take the fluid container away from under the fuel filter.

CLUB.AUTODOC.CO.UK 6-9







15

Lower the car.

Replacement: fuel filter – Ford Mondeo BWY. AUTODOC experts recommend:

• Before starting off, switch the ignition on and off several times. This should be done to activate the fuel pump to make it pump fuel through the fuel system.

Run the engine for a few minutes. This is necessary in order to make sure that the component operates properly.



Shut off the engine.

Replacement: fuel filter - Ford Mondeo BWY. Tip from AUTODOC:

 To protect the environment from pollution, be sure to dispose of the used filters at special collection points.




VIEW MORE TUTORIALS

CLUB.AUTODOC.CO.UK 7-9





AUTODOC — TOP QUALITY AND AFFORDABLE CAR PARTS ONLINE



A GREAT SELECTION OF SPARE PARTS FOR YOUR CAR

BUY SPARE PARTS FOR FORD

FUEL FILTER: A WIDE SELECTION

CLUB.AUTODOC.CO.UK 8-9





CHOOSE CAR PARTS FOR FORD MONDEO BWY

FUEL FILTER FOR FORD: BUY NOW

FUEL FILTER FOR FORD MONDEO BWY: THE BEST DEALS & OFFERS

① DISCLAIMER:

The document contains only general recommendations that may be useful for you when you perform repair or replacement work. AUTODOC shall not be liable for any loss, injury, damage of property occurring in the repair or replacement process due to incorrect use or misinterpretation of the provided information.

AUTODOC shall not be liable for any possible mistakes and uncertainties in this guide. The information provided is for information purposes only and cannot replace advice from specialists.

AUTODOC shall not be liable for incorrect or hazardous usage of equipment, tools and car parts. AUTODOC strongly recommends to be careful and observe the safety rules when performing repair or replacement works. Remember: usage of low quality auto parts does not guarantee you the appropriate level of road safety.

© Copyright 2023 – All the contents of this website, in particular texts, photographs and graphics, are protected by copyright. All rights, including reproduction, publication, editing and translation rights, are reserved by AUTODOC SE.

CLUB.AUTODOC.CO.UK 9-9