+ AUTODOC CLUB

How to change front anti roll bar links on **Peugeot 407 saloon** – replacement guide







VIDEO TUTORIAL



(i) Important!

This replacement procedure can be used for:

PEUGEOT 407 Saloon 2.0, PEUGEOT 407 Saloon 2.2, PEUGEOT 407 Saloon 3.0, PEUGEOT 407 Saloon 2.0 HDi 135, PEUGEOT 407 Saloon 1.8, PEUGEOT 407 SW 1.8, PEUGEOT 407 SW 2.0, PEUGEOT 407 SW 2.2, PEUGEOT 407 SW 3.0, PEUGEOT 407 SW 1.6 HDi 110, PEUGEOT 407 SW 2.0 HDi 135, PEUGEOT 407 Coupe 2.2 16V, PEUGEOT 407 Coupe 3.0 V6, PEUGEOT 407 Coupe 2.7 HDi, PEUGEOT 407 SW 1.8 16V, (+ 12)

The steps may slightly vary depending on the car design.

CLUB.AUTODOC.CO.UK 1-10







REPLACEMENT: ANTI ROLL BAR LINKS – PEUGEOT 407 SALOON. LIST OF THE TOOLS YOU'LL NEED:



- Wire brush
- WD-40 spray
- Copper grease
- Brake cleaner
- Combination spanner #18
- Combination spanner #24
- Torx bit T40
- HEX bit no.H6.

- Wheel impact socket #19
- Ratchet wrench
- Torque wrench
- Pin punch
- Hammer
- Crow bar
- Wheel chock

BUY TOOLS

CLUB.AUTODOC.CO.UK 2-10







Replacement: anti roll bar links – Peugeot 407 saloon. AUTODOC experts recommend:

- Replace the stabiliser links on Peugeot 407 in pairs.
- The replacement procedure is identical for both stabiliser links on the same axle.
- All work should be done with the engine stopped.

REPLACEMENT: ANTI ROLL BAR LINKS – PEUGEOT 407 SALOON. USE THE FOLLOWING PROCEDURE:

1 Secure the wheels with chocks.



Loosen the wheel mounting bolts. Use wheel impact socket #19.



Raise the front of the car and secure on supports.

CLUB.AUTODOC.CO.UK 3-10







4 Unscrew the wheel bolts.



Replacement: anti roll bar links – Peugeot 407 saloon. Tip:

- To avoid injury, hold up the wheel when unscrewing the bolts.
- Remove the wheel.



- 6 Clean the stabiliser link fasteners. Use a wire brush. Use WD-40 spray.
- Unscrew the fastener connecting the stabilizer link to the stabilizer bar. Use a combination spanner #18. Use HEX No.H6. Use a ratchet wrench.



CLUB.AUTODOC.CO.UK 4–10







Unscrew the fastener connecting the stabilizer bar with the control arm. Use a combination spanner #24. Use Torx T40. Use a ratchet wrench.



- 9 Remove the fastening nut.
- Remove the stabilizer rod. Use a pin punch. Use a hammer.



- Clean the mounting seats of the stabiliser link. Use a wire brush. Use WD-40 spray.
- Install a new rod, tighten the fasteners. Use a crowbar.



Tighten the fastener connecting the stabilizer link to the stabilizer bar. Use a combination spanner #18. Use HEX No.H6. Use a torque wrench. Tighten it to 85 Nm torque.



CLUB.AUTODOC.CO.UK 5-10







- 14 Install the fastening nut.
- Tighten the fastener connecting the stabilizer bar with the control arm. Use a combination spanner #24. Use Torx T40. Use a torque wrench. Tighten it to 205 Nm torque.



Treat all joints of the stabiliser link. Use copper grease.



Treat the surface where the brake disc contacts the wheel rim. Use copper grease.



Clean the brake disk surface. Use a brake cleaner.



CLUB.AUTODOC.CO.UK 6-10







Replacement: anti roll bar links – Peugeot 407 saloon. Tip from AUTODOC:

• After applying the spray, wait a few minutes.

19

Install the wheel.



AUTODOC recommends:

 Important! Hold the wheel while screwing in the fastening bolts. Peugeot 407 saloon

20

Screw in the wheel bolts. Use wheel impact socket #19.



21

Lower the car and working in a cross order, tighten the wheel bolts. Use wheel impact socket #19. Use a torque wrench. Tighten it to 100 nm torque.



CLUB.AUTODOC.CO.UK 7-10







22

Remove the jacks and chocks.







VIEW MORE TUTORIALS

8-10 CLUB.AUTODOC.CO.UK





AUTODOC — TOP QUALITY AND AFFORDABLE CAR PARTS ONLINE



A GREAT SELECTION OF SPARE PARTS FOR YOUR CAR

BUY SPARE PARTS FOR PEUGEOT

ANTI ROLL BAR LINKS: A WIDE SELECTION

CLUB.AUTODOC.CO.UK 9-10







ANTI ROLL BAR LINKS FOR PEUGEOT: BUY NOW

ANTI ROLL BAR LINKS FOR PEUGEOT 407 SALOON: THE BEST DEALS & OFFERS

① DISCLAIMER:

The document contains only general recommendations that may be useful for you when you perform repair or replacement work. AUTODOC shall not be liable for any loss, injury, damage of property occurring in the repair or replacement process due to incorrect use or misinterpretation of the provided information.

AUTODOC shall not be liable for any possible mistakes and uncertainties in this guide. The information provided is for information purposes only and cannot replace advice from specialists.

AUTODOC shall not be liable for incorrect or hazardous usage of equipment, tools and car parts. AUTODOC strongly recommends to be careful and observe the safety rules when performing repair or replacement works. Remember: usage of low quality auto parts does not guarantee you the appropriate level of road safety.

© Copyright 2023 – All the contents of this website, in particular texts, photographs and graphics, are protected by copyright. All rights, including reproduction, publication, editing and translation rights, are reserved by AUTODOC GmbH.

CLUB.AUTODOC.CO.UK 10-10