



How to change air filter
on **Alfa Romeo 147 937** –
replacement guide

VIDEO TUTORIAL



Important!

This replacement procedure can be used for:

ALFA ROMEO GT (937) 2.0 JTS, ALFA ROMEO 147 (937) 2.0 16V T.SPARK, ALFA ROMEO 147 (937) 1.6 16V T.SPARK, ALFA ROMEO 147 (937) 1.6 16V T.SPARK ECO, ALFA ROMEO GT (937) 1.8 TS, ALFA ROMEO 147 (937) 1.6 LPG (937BXB1A), ALFA ROMEO 147 (937) 1.6 LPG (937AXA1A)

The steps may slightly vary depending on the car design.

REPLACEMENT: AIR FILTER – ALFA ROMEO 147 937.
TOOLS YOU NEED:



• Microfibre towel

• Fender cover


BUY TOOLS

Replacement: air filter – Alfa Romeo 147 937. Tip from AUTODOC:


- Follow the terms, recommendations and requirements of the part operation provided by the manufacturer.
- Please note: all work on the car – Alfa Romeo 147 937 – should be done with the engine switched off.

CARRY OUT REPLACEMENT IN THE FOLLOWING ORDER:

1 Open the hood.




2 Use a fender protection cover to prevent damaging paintwork and plastic parts of the car.



3 Remove the air filter housing retaining spring.



4 Take off the filter lid.




AUTODOC recommends:

- Replacement: air filter – Alfa Romeo 147 937. Do not use excessive force when removing the part as this may damage it.

5 Remove the filter element from the filter housing.



6 Clean the air filter cover and housing.




AUTODOC recommends:

- Before cleaning the air filter cover and housing, cover the air duct parts, mass airflow sensor (if available), throttle valve with a clean cloth.

7

Insert a new filter element into the filter housing. Make sure that the filter edge fits tight to the housing.



Replacement: air filter – Alfa Romeo 147 937. Tip from AUTODOC experts:

- Check out the correct location of the filter element. Do not skew.
- Attention! Use quality filters – Alfa Romeo 147 937.
- During installation, make sure to prevent dust and dirt from getting into the air filter housing.

8


Reinstall the air filter cover. Fasten it.




AUTODOC recommends:

- Replacement: air filter – Alfa Romeo 147 937. Do not use excessive force during installation. This may damage the part.

9 Install the air filter housing retaining spring.



10 Remove the fender protection cover.



11 Close the hood.



WELL DONE! 

VIEW MORE TUTORIALS

AUTODOC – TOP QUALITY AND AFFORDABLE CAR PARTS ONLINE

AUTODOC MOBILE APP: GREAT DEALS AND CONVENIENT SHOPPING



+ AUTODOC

GET IT ON  **Google Play**

 **Download on the App Store**

Download

A GREAT SELECTION OF SPARE PARTS FOR YOUR CAR

BUY SPARE PARTS FOR ALFA ROMEO

AIR FILTER: A WIDE SELECTION

CHOOSE CAR PARTS FOR ALFA ROMEO 147 937

AIR FILTER FOR ALFA ROMEO: BUY NOW

AIR FILTER FOR ALFA ROMEO 147 937: THE BEST DEALS & OFFERS

DISCLAIMER:

The document contains only general recommendations that may be useful for you when you perform repair or replacement work. AUTODOC shall not be liable for any loss, injury, damage of property occurring in the repair or replacement process due to incorrect use or misinterpretation of the provided information.

AUTODOC shall not be liable for any possible mistakes and uncertainties in this guide. The information provided is for information purposes only and cannot replace advice from specialists.

AUTODOC shall not be liable for incorrect or hazardous usage of equipment, tools and car parts. AUTODOC strongly recommends to be careful and observe the safety rules when performing repair or replacement works. Remember: usage of low quality auto parts does not guarantee you the appropriate level of road safety.

© Copyright 2023 – All the contents of this website, in particular texts, photographs and graphics, are protected by copyright. All rights, including reproduction, publication, editing and translation rights, are reserved by AUTODOC SE.