


How to change glass for wing mirror on **Opel Astra H saloon** – replacement guide





VIDEO TUTORIAL



i Important!

This replacement procedure can be used for:

OPEL Astra H Caravan (A04) 1.4 (L35), OPEL Astra H Van (L70) 1.7 CDTI (L70), OPEL Astra H Van (L70) 1.9 CDTI (L70), OPEL Astra H Van (L70) 1.9 CDTI 16V (L70), OPEL Astra H Van (L70) 1.3 CDTI (L70), OPEL Astra H GTC (A04) 1.4 (L08), OPEL Astra H Hatchback (A04) 1.4 LPG (L48), OPEL Astra H Hatchback (A04) 1.4 (L48), OPEL Astra H Hatchback (A04) 1.8 (L48), OPEL Astra H Hatchback (A04) 1.7 CDTI (L48), OPEL Astra H Hatchback (A04) 2.0 Turbo (L48), OPEL Astra H Hatchback (A04) 1.9 CDTI (L48), OPEL Astra H Caravan (A04) 1.6 (L35), OPEL Astra H Caravan (A04) 1.8 (L35), (+29)

The steps may slightly vary depending on the car design.

CLUB.AUTODOC.CO.UK 1–7





REPLACEMENT: GLASS FOR WING MIRROR – OPEL ASTRA H SALOON. TOOLS YOU MIGHT NEED:



Electronic spray

Plastic trim tool

BUY TOOLS

CLUB.AUTODOC.CO.UK 2-7







Replacement: glass for wing mirror – Opel Astra H saloon. AUTODOC experts recommend:

- The replacement procedure is identical for the right and left side mirror glass.
- Please note: all work on the car Opel Astra H saloon should be done with the engine switched off.

CARRY OUT REPLACEMENT IN THE FOLLOWING ORDER:

Tilt the mirror glass out of the housing.



Carefully release the mirror glass from its attachment. Use a plastic trim tool.



Remove the mirror glass.

2



CLUB.AUTODOC.CO.UK 3-7





AUTODOC recommends:

 Replacement: glass for wing mirror – Opel Astra H saloon. To avoid damaging the part when removing it, do not use excessive force.

4 Detach the mirror heating connectors.



Treat the mirror heating connectors. Use dielectric grease.



6 Attach the mirror heating connectors.



Install the new mirror glass. Make sure you hear a click indicating that it is locked in place.



CLUB.AUTODOC.CO.UK 4-7







AUTODOC recommends:

- Replacement: glass for wing mirror Opel Astra H saloon. Do not use excessive force during installation. This may damage the part.
- Make sure the mirror glass is positioned correctly. It should be aligned with the locking tabs on the housing.

Clean the mirror glass.



- Switch on the ignition. This is necessary in order to make sure that the component operates properly.
- 10 Switch off the ignition.




VIEW MORE TUTORIALS

CLUB.AUTODOC.CO.UK 5–7





AUTODOC — TOP QUALITY AND AFFORDABLE CAR PARTS ONLINE



A GREAT SELECTION OF SPARE PARTS FOR YOUR CAR

BUY SPARE PARTS FOR OPEL

GLASS FOR WING MIRROR: A WIDE SELECTION

CLUB.AUTODOC.CO.UK 6-7





CHOOSE CAR PARTS FOR OPEL ASTRA H SALOON

GLASS FOR WING MIRROR FOR OPEL: BUY NOW

GLASS FOR WING MIRROR FOR OPEL ASTRA H SALOON: THE BEST DEALS & OFFERS

① DISCLAIMER:

The document contains only general recommendations that may be useful for you when you perform repair or replacement work. AUTODOC shall not be liable for any loss, injury, damage of property occurring in the repair or replacement process due to incorrect use or misinterpretation of the provided information.

AUTODOC shall not be liable for any possible mistakes and uncertainties in this guide. The information provided is for information purposes only and cannot replace advice from specialists.

AUTODOC shall not be liable for incorrect or hazardous usage of equipment, tools and car parts. AUTODOC strongly recommends to be careful and observe the safety rules when performing repair or replacement works. Remember: usage of low quality auto parts does not guarantee you the appropriate level of road safety.

© Copyright 2022 – All the contents of this website, in particular texts, photographs and graphics, are protected by copyright. All rights, including reproduction, publication, editing and translation rights, are reserved by AUTODOC GmbH.

CLUB.AUTODOC.CO.UK 7–7